




TECH BRIEFS

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING



Sensor
Innovations

Tech East Highlights

Advances in Data Acquisition

Photonics Tech Briefs

JOHN F. KENNEDY
SPACE CENTER LIBRARY
DOCUMENTS DEPARTMENT
CIRCULATION COPY

-1-

ID1/LIBRARY-E
RM. 1533
KSC HQS

www.nasatech.com

Measure Anything.

With Measurement Ready tools from National Instruments, you can create a personal solution that takes any measurement – quickly, accurately, and in real-time.

- ✓ Data acquisition
- ✓ Signal conditioning
- ✓ Distributed I/O
- ✓ Image acquisition
- ✓ Machine vision/inspection
- ✓ Servo and stepper motion control
- ✓ Thermocouple and RTD sensors
- ✓ On-board real-time processing
- ✓ Sound and vibration

Automate Everything.

From turnkey applications to enterprise-wide solutions, use LabVIEW™ and our other industry-leading measurement and automation software to:

- ✓ Automate your measurements
- ✓ Increase measurement performance
- ✓ Simplify hardware integration
- ✓ Reduce development time
- ✓ Lower costs

Choose National Instruments – get the flexibility to create any automated measurement solution.



www.ni.com/daq (800) 327-9894

Tel: (512) 794-0100 • Fax: (512) 683-9300 • info@ni.com

For More Information Circle No. 500

Microsoft Certified
Solution Provider

OPC
FOUNDATION
MEMBER



Call for your **FREE**
DAQ Designer™ 99 system
configuration software

BUY ONLINE!



© Copyright 1999 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

www.omega.com
e-mail: info@omega.com

omega.com™


One Omega Drive, P.O. Box 4047
Stamford CT 06907-0047



To Request Your
DILBERT® Deck Card Pack, Dial:
1-(203)-329-1268

Get Your Dilbert Card Deck **Circle No. 575**

DILBERT® by Scott Adams



3/15/95 DILBERT © United Feature Syndicate, Inc.



3/15/95 DILBERT © United Feature Syndicate, Inc.



3/15/95 DILBERT © United Feature Syndicate, Inc.

Dilbert Deck No.5 Available

**HOT OFF
THE PRESS!**

21ST Century™ Edition

HARDBOUND
1200 Pages



HANDBOOKS
on CD™

THE DATA ACQUISITION SYSTEMS HANDBOOK™

21ST CENTURY™ EDITION

**NEW
FREE!**

For Free Literature
and Free CD-ROM
Call between 8:30 and 5:00
DIAL 1-203-359-7874

OMEGA Universal Guide
to Data Acquisition and
Computer Interfaces™



Circle No. 577

omega.com™
ΩOMEGA™

THE OMEGA® DATA ACQUISITION SYSTEMS HANDBOOK 21ST CENTURY™ EDITION



Circle No. 576

omega-on-line™
VISIT OUR WEBSITE!

www.dasieeee.com
e-mail: das@omega.com

© COPYRIGHT 1999 OMEGA ENGINEERING, INC. ALL RIGHTS RESERVED.



Introducing a New Generation of Fast Numerics

with dependability and integration that only Mathematica can provide

WOLFRAM
RESEARCH

Check out Mathematica 4 and see the beginning of gigaNumerics™
www.wolfram.com/mathematica4/ntb or 1-800-WOLFRAM

Researchers and engineers worldwide use Mathematica for modeling, analysis, numeric and symbolic computation, visualization, and as a technical document system.

Wolfram Research, Inc.: www.wolfram.com; info@wolfram.com; +1-217-398-0700
Wolfram Research Europe Ltd.: www.wolfram.co.uk; info@wolfram.co.uk; +44-(0)1993-883400
Wolfram Research Asia Ltd.: www.wolfram.com.jp; info@wolfram.com.jp; +81-(0)3-5276-0506

© 1999 Wolfram Research, Inc. Mathematica is a registered trademark and gigaNumerics is a trademark of Wolfram Research, Inc. Mathematica is not associated with Mathematica Policy Research, Inc. or MathTech, Inc.

Sales inquiries outside the U.S. and Canada:
www.wolfram.com/services/intldealers

All Mathematica products are available for Microsoft Windows, Macintosh, and most Unix platforms.

For More Information Circle No. 505

Redefining Distribution!

Call, write, fax or visit us on the
Internet for your **FREE CATALOG** today!

Digi-Key®

Quality Electronic Components Superior Service

1-800-344-4539

Fax: 218-681-3380 • www.digikey.com

701 Brooks Ave. South

Thief River Falls, MN 56701

**SAME-DAY
SHIPMENT**

On Orders
Entered By:

7:00

PM Central

**NEXT-DAY
DELIVERY**

For More Information Circle No. 540



FEATURES

- 18 Tech East '99 Highlights
- 22 InReview
- 24 Application Briefs
- 26 Technology Forecast: Data Acquisition

BRIEFS



28 Special Coverage: Data Acquisition

- 28 Post-Processing Satellite Image Data in Secondary Schools
- 30 Using Narrow-Band Data Links in Locating Lightning Strikes
- 30 Centralized Electronic Reporting of Material-Science Tasks
- 31 Algorithm for Rapid Acquisition of a PPM Optical Signal



34 Electronic Components and Systems

- 34 Tunable HTS/Ferroelectric Microstrip Band-Pass Filters
- 37 Return-Link Processor PCI Card



38 Software

- 38 The Automated Fatigue Calculation Program (FATPLUS)



40 Materials

- 40 Composite-Material Heat Sink for Printed-Circuit Boards
- 41 Reducing Methanol Crossover in CH₃OH-Fuel-Cell Membranes



42 Mechanics

- 42 Inflatable Wing Leading Edges for High Lift and Deicing
- 44 Bushing-Mounted Drag Chain



46 Bio-Medical

- 46 Improved Urine Preservative
- 47 Noninvasive Determination of Pressure in Cerebrospinal Fluid
- 48 Primers for Amplifying CMV DNA in Body Fluids and Tissue




49 Physical Sciences

- 49 GFSSP — Program for Analyzing Flows in a Complex Network
- 50 Temperature Correction for Pressure-Sensitive Paint



33



60




61

DEPARTMENTS

- 10 Commercial Technology Team
- 12 Reader Forum
- 14 UpFront
- 16 NEW! This Month in RPD Online
- 23 Commercialization Opportunities
- 33 Special Coverage Products: Data Acquisition
- 60 Special Coverage Products: Sensors
- 61 New on the Market
- 62 New on Disk
- 64 Advertisers Index

SPECIAL SUPPLEMENTS



1a - 28a Photonics Tech Briefs

Follows page 16 in selected editions only.

Introducing

www.FEAINCAD.com


**All you need to do FEA within CAD
\$975**

Algor, Inc.
150 Beta Drive, Pittsburgh, PA 15238-2932 USA
Phone: +1 (412) 967-2700
Fax: +1 (412) 967-2781



*When the Engineering
Has to be Right*

California: +1 (714) 564-0844
Europe (UK): +44 (1784) 442 246
E-mail: info@algor.com
www.algor.com



All trademarks may be trademarks or registered trademarks of their respective owners.

For More Information Circle No. 521 or Visit www.nasatech.com/521

52 Information Sciences

- 52 Further Developments in Web Interactive Training
- 54 Developmental Software for Exploiting Hyperspectral Imagery
- 55 Expert System To Develop Job Standards

56 Books and Reports

- 56 Update on Electrolytes for Low-Temperature-Lithium Cells
- 56 Techniques for Controlling Buoyancy of Balloons on Titan
- 56 Studies of Interaction Impedance in a TWT Helix

57 Special Coverage: Sensors

- 57 Nonintrusive Flow-Measurement System
- 57 High-Temperature Pressure Sensors Made From Silicon Carbide
- 58 Piezoelectric Igniter/Pressure-Sensor Devices
- 59 Lightweight, Low-Power, Inexpensive Ozone Dosimeters

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

PRODUCT OF THE MONTH

Labtec's new 3D motion controller/input device is ergonomically designed for right- or left-hand use.

14



ON THE COVER



This month, *NASA Tech Briefs* introduces a new web publication called Rapid Product Development (RPD) Online. Available at www.rapidproducts.net, RPD Online is designed to help engineers develop products faster by giving them access to feature stories, interviews, show coverage, and other information on CAD, FEA, modeling, reverse engineering, and rapid prototyping. RPD Online also will feature new products, including the latest version of Mastercam CAD/CAM software — from CNC Software, Tolland, CT (www.mastercam.com) — which was used to create the models on our cover. For more information on RPD Online, see page 16.

(Image courtesy of CNC Software)

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00

Nobody Puts it Together Like Ocean Optics

One-stop Shopping for Fully Integrated Optical-sensing Solutions

A decade ago, Ocean Optics was little more than two guys in a boat with an idea for an oceanographic sensor. Ten thousand spectrometers, 3,000 applications and nearly 500 products later, Ocean Optics has expanded its OEM and R&D business to include high-precision optical components, filters and coatings. It's all part of our mission to become your one-stop shopping source for innovative optical-sensing systems.



- Dichroic Filter Arrays® and wheels
- microlithographic thin films
- high-reflection and AR coatings



- $\lambda/20$ high-precision optics
- spherical, aspherical and flat lenses and mirrors
- collimation testers and profilometers

www.OceanOptics.com

**See us at Photonics West 2000
Booth #322/324**




**Phone: (727) 733-2447
Fax: (727) 733-3962
Info@OceanOptics.com
www.OceanOptics.com**

MORE TEST CAPABILITY AND SPEED IN ONE LITTLE BOX THAN ANYONE THOUGHT POSSIBLE...

CS29010 Fully Integrated Wideband Distortion Test Set

- Arbitrary Waveform Generator
- Data Recorder
- Up/Down Converter

Cellular, PCS, satellite, LMDS and all communications or data link systems operating in complex multi-channel and multi-signal environments



3IM

ACPR

NPR

EXCEPT CELERITY.

Because that's what we do - design and build test solutions for the industry's toughest challenges. Introducing the new CS29010 Wide Band Distortion Test Set, a complete signal generation, data acquisition and record/playback end-to-end solution. The CS29010 delivers a level of capability you'd never expect in an off-the-shelf product: huge bandwidth (45 MHz @ 12 Bits), deep memory (4 GB RAM) and blazing fast speed (600 MHz Pentium III based, 100 times faster than the competition).

By utilizing an open architecture design, user-friendly software and standard module cards, the CS29010 is a single platform tool that can simplify and enhance your test, measurement and analysis capability. The CS29010 is ideally suited for testing these key performance parameters:

THIRD ORDER INTERMOD (3IM) Active microwave and electronic component testing. 3IM test and measurement for non-linear components and sub-assemblies such as filters and amplifiers whether stand-alone or integrated.

ADJACENT CHANNEL POWER RATIO (ACPR) PCS, Cellular or SATCOM (dual band, multi-channel). ACPR test for broadband communications amplifiers with any test signal such as CDMA and noise. Multi-channel capability for crosstalk measurements and evaluation of components and subsystems, bench level or installed.

NOISE POWER RATIO (NPR) Solid-state TWT's, amplifiers, telecom switches, cable (modems). RF and data NPR test capability that surpasses anything available. Additional functions include Power in/Power out, device gain and phase delay as a function of power.

All this capability is packaged in a single, easy-to-use box (bench, rack mount or portable configuration) with Windows NT/Pentium controls for efficient integration into your test system and plan. Check out the details at www.csdaq.com or call us directly to discuss your testing requirements.

MORE DATA. MORE SPEED. MORE FLEXIBILITY.



communications

Celerity Systems

10411 Bubb Road Cupertino, CA 95014 • Phone (888) 274-5604 • www.csdaq.com

COMBINE MULTIPLE
**COMPUTER
& VIDEO
SOURCES**
ON A SINGLE SCREEN



SUPERVIEW™
DISPLAY PROCESSOR
LET'S YOU COUNT UP TO
10
IN REAL-TIME AND
FULL COLOR

Display up to **10**
simultaneous video inputs
including NTSC/PAL or S-Video

Display up to **10**
simultaneous computer inputs
up to 1280 x 1024 pixels

Display a combination of **10**
simultaneous video and
computer inputs

Position and scale each
window independently

Zoom within each window

Overlay computer graphics
on video

RS-232 or front panel control

Visit our web site
<http://www.rgb.com>

RGB SPECTRUM®
a visual communications company™
950 Marina Village Parkway
Alameda, California 94501
Tel: (510) 814-7000
Fax: (510) 814-7026
E-mail: sales@rgb.com



TECH BRIEFS
www.nasatech.com



Published by Associated Business Publications
Publisher..... Joseph T. Pramberger
Chief Editor..... Linda L. Bell
Associate Publisher, *Photonics Tech Briefs* Linda Silver
Editor, Market Focus Editions..... Robert Clark
Internet Editor Suzanne Bilyeu
Production Manager Margery Koen
Assistant Production Manager..... John Iwanciw
Art Director Lois Erlacher
Production Artist Christopher Coleman
Circulation Manager..... Hugh J. Dowling

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor Ted Selinsky
Sr. Technical Analyst..... Dr. Larry Grunberger
Art Manager Eric Starstrom
Staff Writers/Editors..... Dr. Theron Cole, George Watson
Graphics Robert Simons
Editorial & Production..... Joan Schmiemann, Becky D. Bentley

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:

Administrator Daniel S. Goldin
Director, Commercial Technology..... Dr. Robert Norwood
Publications Director Carl Ray

ASSOCIATED BUSINESS PUBLICATIONS INTERNATIONAL

317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer..... Bill Schnirring (bill@abpi.net)
President/Chief Operating Officer..... Domenic A. Muchetti
MIS Manager Ted Morawski
Webmaster Albert Sunseri
Credit/Collection Felecia Lahey
Accounting Manager..... Larry Duze
Trade Show Manager..... Melissa Hinnen
Human Resources Manager..... Lourdes Del Valle
Office Services Manager Sylvia Ruiz

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES


Headquarters..... (212) 490-3999
MA, NH, ME, VT, RI, Eastern Canada Ed Marecki
at (401) 351-0274
NY, CT Mike Venezia
at (860) 871-7491
NJ, PA, DE, VA, DC, MD Ryan Kraven
at (212) 490-3999
NC, SC, GA, FL, AL, TN, MS, LA, AR, OK, TX Bill Manning
at (770) 971-0677
MN, ND, SD, WI, IL Bob Casey
at (847) 223-5225
IL, MO, IA, KS, NE Jeff Casey
at (847) 223-5225
IN, KY, MI, OH, Western PA & NY, Central Canada Chris Casey
at (847) 223-5225
N. Calif., CO Bill Hague
at (408) 492-9292
WA, OR, ID, MT, WY, UT, Western Canada Bill Madden
at (253) 858-1192
S. Calif., NV, AZ, NM Jana Peck
at (760) 634-3983
S. Calif., Photonics Tech Briefs..... Linda Silver
at (310) 247-0317
International Sales..... Rachel Di Santo
at (0144) 01932-564999
Internet Advertising..... Luke Schnirring
at (212) 490-3999
TechDeck Postcard Advertising Erving Dockery
at (212) 490-3999
Trade Show Sales Carolyn Lighty
at (727) 796-5550, ext. 135

**For a complete list of staff e-mail addresses,
visit www.nasatech.com**

The Pinnacle of Telemetry Recording

EVEREST™

**Telemetry
Recorder-
Workstation**



- Large color display for real-time data viewing
- Intuitive touch-screen interface simplifies setup and operation
- Look-back while recording in real time
- Up to 32 analog or digital input channels
- Virtual Chart™ efficiently stores data while saving paper
- Ethernet interface for command and control
- High-resolution chart printing for clear, crisp traces

Call, E-mail, Fax, or write to us today for all the details.

 **Astro-Med, Inc.**
TEST & MEASUREMENT SYSTEMS

Astro-Med is System Certified to ISO-9001

Astro-Med Industrial Park, West Warwick, Rhode Island 02893

Phone: (401) 828-4000 • Toll Free: 1-877-867-9783 • Fax: (401) 822-2430

In Canada Telephone 1-800-565-2216

E-mail: MTGroup@astro-med.com • Web Site: www.astro-med.com

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (609) 667-7737 for the FLC coordinator in your area.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths:
Fluid Dynamics;
Life Sciences;
Earth and Atmospheric Sciences;
Information, Communications, and Intelligent Systems;
Human Factors.
Carolina Blake
(650) 604-1754
cblake@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths:
Aerodynamics;
Aeronautics
Flight Testing;
Aeropropulsion;
Flight Systems;
Thermal Testing;
Integrated Systems Test and Validation.
Lee Duke
(805) 258-3802
lee.duke@dfrc.nasa.gov

Goddard Space Flight Center

Selected technological strengths:
Earth and Planetary Science
Missions; LIDAR;
Cryogenic Systems;
Tracking; Telemetry;
Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths:
Near/Deep-Space Mission Engineering;
Microspacecraft; Space Communications;
Information Systems;
Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@ccmail.jpl.nasa.gov

Johnson Space Center

Selected technological strengths:
Artificial Intelligence and Human Computer Interface;
Life Sciences;
Human Space Flight Operations;
Avionics; Sensors; Communications.
Hank Davis
(281) 483-0474
hdavis@gp101.jsc.nasa.gov

Kennedy Space Center

Selected technological strengths:
Command, Control, and Monitoring Systems; Range Systems, Fluids and Fluid Systems; Materials Evaluation and Process Engineering.
Gale Allen
(407) 867-6226
gale.allen-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths:
Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Dr. Joseph S. Heyman
(757) 864-6006
j.s.heyman@larc.nasa.gov

John H. Glenn Research Center at Lewis Field

Selected technological strengths:
Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Larry Viterna
(216) 433-3484
cto@grc.nasa.gov

Marshall Space Flight Center

Selected technological strengths:
Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Sally Little
(256) 544-4266
sally.little@msfc.nasa.gov

Stennis Space Center

Selected technological strengths:
Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(228) 688-1929
technology@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Carl Ray
Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)
(202) 358-4652
cray@mail.hq.nasa.gov

Gerald Johnson
Office of Aeronautics (Code R)
(202) 358-4711
g.johnson@aeromail.hq.nasa.gov

Bill Smith
Office of Space Sciences (Code S)
(202) 358-2473
wsmith@sm.ms.oss.hq.nasa.gov

Dr. Robert Norwood
Office of Aeronautics and Space Transportation Technology (Code R)
(202) 358-2320
rnorwood@mail.hq.nasa.gov

Roger Crouch
Office of Microgravity Science Applications (Code U)
(202) 358-0689
rcrouch@hq.nasa.gov

John Mulcahy
Office of Space Flight (Code MP)
(202) 358-1401
jmulcahy@mail.hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Wayne P. Zeman
Lewis Incubator for Technology
Cleveland, OH
(216) 586-3888

Joe Boedeker
Ames Technology Commercialization Center
San Jose, CA
(408) 557-6700

B. Greg Hinkebein
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

Marty Kaszubowski
Hampton Roads Technology Incubator (Langley Research Center)
Hampton, VA
(757) 865-2140

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

Joseph Allen
National Technology Transfer Center
(800) 678-6882

Dr. William Gasko
Center for Technology Commercialization
Massachusetts
Technology Park
(508) 870-0042

Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(409) 845-8762

Chris Coburn
Great Lakes Industrial Technology Transfer Center
Battelle Memorial Institute
(440) 734-0094


Ken Dozier
Far-West Technology Transfer Center
University of Southern California
(213) 743-2353

J. Ronald Thornton
Southern Technology Applications Center
University of Florida
(352) 294-7822

Lani S. Hummel
Mid-Atlantic Technology Applications Center
University of Pittsburgh
(412) 383-2500

NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.



SIMPLY BRILLIANT. INTRODUCING THE KINGSTON *infoStation*.™

WHEN IT COMES TO INTELLIGENT STORAGE ENCLOSURES, the spotlight shines on Kingston's new InfoStation™. Perfect for RAID applications, the InfoStation is a scalable backplane expansion chassis featuring:

- Support for up to (9) 3.5" Ultra2 (LVD) drives
- A user display and control interface for drive bay configuration and system set-up
- Upgradable support for up to 4 host channels (60 devices)
- (2) redundant, hot swappable, load sharing 400W power supplies
- (4) high-pressure, variable-speed blowers in (2) hot swappable modules
- A generous 7-year warranty

With many field-upgradable options to come, such as a SCSI RAID controller board, a Fibre to SCSI bridge, and remote monitoring capabilities, the InfoStation is flexible and will grow with your future storage needs.

Call Kingston® Storage today at (888) 435-4963 to request more information about this brilliant new addition to Kingston's family of rugged and reliable Rhino® products. Mention this ad and Kingston will include a small token of appreciation in your literature packet.



Kingston Technology Company, 17600 Newhope Street, Fountain Valley, CA 92708, USA (714) 438-1850, Fax (714) 438-1847. © 2000 Kingston Technology Company. All rights reserved. All trademarks and registered trademarks are the property of their respective owners.

Reader Forum

Reader Forum is devoted to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a specific technical problem, or an answer to a question that appeared in a recent issue, send your letter to the address below.

I am looking for information and manufacturers of bi-directional air sensors, specifically in the range of ± 5 feet/minute (0.06 mph). I have found some types, but I'm looking for other units that may be applied to cleanroom applications. Any assistance would be appreciated. Thanks.

John Victor
jvictor@engsvcs.com

spelled. The research in this article verifies the effectiveness of our acetylene black in significantly improving cycle-life performance. I'd also like to offer our e-mail address, aceblack@chevron.com, for those interested in more information and/or samples.

Cindy French
lwie@chevron.com

The metal also has to be machinable without much difficulty, and must be purchased in rods or blocks. Thank you.

Jeff Sauck
sauckje@worldnet.att.net

In the September 1999 issue of NASA Tech Briefs, you included a brief entitled "Mixed-Carbon Anodes for Improved Li-ion Cells," by Jet Propulsion Laboratory (page 46). In the brief, the trade name of Chevron's petrochemically derived acetylene black, Shawinigan Black, was mis-

I'm looking for metals similar to BeCu or better in thermal conductivity, with hardness greater than 15 Rc. I'd also like to find something more conductive than Ampcoloy materials. Does anyone know of materials like these, and where I can obtain materials that fit these criteria?

NASA Tech Briefs has helped me find sources for machining precision parts, and has provided design/build options for in-house designs of turbine/flowmeter rotors. Thank you for your help.

Laurence de Quay
Project Engineer
NASA Stennis Space Center
Mississippi
larry.dequay@ssc.nasa.gov

Post your letters to Reader Forum on-line at: www.nasatech.com or send to: Editor, NASA Tech Briefs, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and phone number or e-mail address.

BR SERIES GRAPHIC RECORDER



The BR paperless recorder from CHINO offers easy to use configuration and a wide variety of displays/screens.



CHINO

CHINO Works America Inc.
Instrumentation, Control and Systems

Victoria Business Park
18005 S. Savarona Way, Carson, CA 90746
Phone: 323-321-3943 • Toll Free: 888-321-9118
Fax: 310-532-7195
Website: www.chinoamerica.com



RECORD

Introducing

StreamStor™ from Boulder Instruments,

the deepest, fastest PCI-direct-to-disk recorder ever developed.

800 Mbits

per second, with

For the first time ever, you can record data at the astonishing rate of 240 Mbits/second

to 800 Mbits/second, with total capacities from 15 GBs to more than 675 GBs.

By writing data directly to disk without going through system memory,

675 GBs

capacity.

StreamStor avoids the bottleneck traditional storage systems encounter.

The result is blazing speed and awesome depth. Don't compromise your

data-intensive applications. **StreamStor** is as fast and deep as it gets.



Boulder Instruments 303.485.1246 • 888.497.7327

Find out more about **StreamStor**. Visit our Web site at www.boulderinstruments.com

PRODUCT OF THE MONTH

Labtec, Vancouver, WA, has introduced the Spaceball 4000 FLX 3D motion controller/input device that minimizes arm and wrist stress, and features a new, adjustable wrist pad for right- or left-hand use. The device allows users to simultaneously pan, zoom, and rotate 3D models as they build, modify, and inspect their 3D designs within their 3D applications. With six-degrees-of-freedom (6D) motion control, users push, pull, or twist the PowerSensor ball for X, Y, and Z axis translations and rotations. A specially coated surface allows flexibility for finger and thumb placement on the ball surface; a ridge design around the ball guides fingers into the optimum position. The placement of 12 buttons — three on the right and nine on the left — offers access to 22 customized functions, and eliminates the need to reach over the sensing mechanism. The device is driven by the SpaceWare 99 software driver that is available for UNIX and Windows NT/95/98 environments.

For More Information Circle No. 757



What's New Online

Beginning this month, you have a new vehicle to help you develop better products faster. Rapid Product Development Online, a completely web-based publication, provides immediate, 24-hour access to the latest information on CAD, FEA, modeling, reverse engineering, and rapid prototyping tools and techniques. Rapid Product Development (RPD)Online is available at www.rapidproducts.net, and includes feature stories updated monthly, industry and product news updated on a continuous basis, product reviews, interviews, show coverage, demos, and links. Look for a monthly RPD Online preview in *NASA Tech Briefs* to find out what's new at www.rapidproducts.net. A preview of this month's features can be found on page 16.



The Microlith catalyst-coated metal substrate is in the foreground. Behind it is an automotive Microlith light-off converter and main converter in an integrated car. A standalone Microlith automotive preconverter is on the right.

The Air They Breathe

NASA's Marshall Space Flight Center, Huntsville, AL, is field-testing a small, metal monolith as a potential component of the International Space Station's Trace Contaminant Control System. The monolith is a catalyst-coated metal honeycomb of a specific geometry that allows efficient, direct electrical heating and better catalytic activity than with conventional catalyst substrates.

The technology, called Microlith[®], could save NASA up to \$31 million over a 15-year period in air-cleaning of space flight life support. Precision Combustion of New Haven, CT, has employed a small amount of electrical heating of the ultra-lightweight metal catalyst substrate to achieve better than 99% destruction of trace organic contaminants at low air inlet temperatures.

The company is conducting research and development with NASA to produce a high specific surface-area washcoat, a specially formulated chemical coating that allows an increased amount of a reactive catalyst to be more evenly and durably applied to the metal monolith.

Non-heated versions of the technology are being evaluated by auto manufacturers for emission concerns. The Microlith enables air-cleaning system designers to use more advanced catalysts, while maintaining safe, low-cost, low-temperature operation.

NEW
PRODUCTS
FOR MATLAB

Have more time to work on the really hard stuff.

Data Acquisition Toolbox


MATLAB Report Generator

C/C++ Graphics Library

MATLAB Web Server

UPDATE Optimization Toolbox

Now you can have more time to think, more time to explore, more time to solve



real problems. With MATLAB, you can analyze data and develop interactively. MATLAB integrates numeric computation, advanced graphics and visualization, and a high-level programming language in a single environment.

MATLAB includes powerful visualization features for creating images like this isosurface of wind speeds over North America.

Companion products provide application-specific tools that save you even more time.

Start now. Get product details, complete specifications, and application examples.

Learn how MATLAB can help you work smarter. For product

information, or to buy online, visit www.mathworks.com/ntbm.



MATLAB®



Visit www.mathworks.com/ntbm
Or Call 508-647-7000

We have a worldwide network of international representatives.
Visit our Web site at www.mathworks.com/eur for more information.

MATLAB tools include interactive signal analysis and filter design, 2-D and 3-D plotting, and volume visualization.





© 1999 The MathWorks, Inc.

Introducing ...

Rapid Product Development Online

A new web publication for *NASA Tech Briefs* readers.



NASA Tech Briefs is proud to introduce this month a new, totally digital publication called Rapid Product Development Online. Available at www.rapidproducts.net, RPD Online is designed to help engineers develop better products faster by giving them immediate, 24-hour access to the latest information on CAD, FEA, modeling, reverse engineering, and rapid prototyping tools and techniques.

RPD Online will include feature stories, industry and product news, product reviews, interviews, show coverage, demos, links, and a keyword-searchable supplier guide.

Each month in *NASA Tech Briefs*, we'll give you a preview of what's new in RPD Online. This month's premier edition includes:

■ **Behavioral Modeling: The Next Generation of Mechanical Design Automation** — Learn how the challenges of today's design market are forcing organizations to take a smarter, more objective-driven and process-wide approach to product development.

■ **Laser System Rapidly Produces 3D Models** — An industrial design school uses a low-cost laser marking and cutting system to produce 3D parts from students' technical designs.

■ **Medical Device Maker Cuts Design Time With CAD Software** — This application story describes how Medstone International, a leading medical device maker, used SolidWorks mechanical CAD software to cut prototyping and development time.

■ **New Products** — New offerings in reverse engineering, epoxy materials, CAM and cost estimating software, and CNC machining are featured.

Be sure to visit www.rapidproducts.net for the latest information on the rapid product development industry. For advertising and sponsorship information, contact Joe Pramberger at joe@abptuf.org; Tel: 212-490-3999.

www.rapidproducts.net

January 2000

PHOTONICS *Tech Briefs*

PHOTONICS SOLUTIONS FOR THE DESIGN ENGINEER



**Coatings and
Environmental Testing**

**Capturing Nasal-Spray
Dynamics**

**Segmented-Cold-
Cathode Display
Panels**

**New Products—
see page 28a**

www.ptbmagazine.com



The New Princeton Instruments PI-MAXTM

The First Completely Integrated Intensified CCD Camera System

The Princeton Instruments PI-MAX uses a new integrated Programmable Timing GeneratorTM (PTG) that completely controls all ICCD camera timing, including data pulse width, gate delay, and external synchronization, through software.

The PI-MAX ICCD camera features:

- Integrated PTG that provides full software gate control with a tiny 25-ns insertion delay
- Nanosecond temporal resolution
- Unmatched sensitivity (QE better than 40%)
- MCP Bracket PulsingTM for on/off ratios greater than $10^7:1$, even in the UV



ROPER SCIENTIFICTM
PRINCETON INSTRUMENTS

3660 Quakerbridge Road Trenton, NJ 08619 tel: 609.587.9797 fax: 609.587.1970 email: info@roperscientific.com

For More Information Circle No. 485

Inspect Anything.

With Measurement Ready™ tools from National Instruments, you can quickly and accurately create a custom solution that completes any inspection and measurement:

- ✓ Machine vision
- ✓ Image acquisition
- ✓ Data acquisition
- ✓ Signal conditioning
- ✓ Sound and vibration
- ✓ Distributed I/O
- ✓ Servo and stepper motion control
- ✓ Thermocouple and RTD sensors

Automate Everything.

From ready-to-run systems to enterprise-wide solutions, use LabVIEW™ and our other industry-leading measurement and automation software to:

- ✓ Increase measurement performance
- ✓ Automate your measurements
- ✓ Simplify hardware integration
- ✓ Reduce development time
- ✓ Lower costs


Choose National Instruments – get the flexibility to create any automated inspection and measurement solution.



www.ni.com/vision (800) 327-9894

Tel: (512) 794-0100 • Fax: (512) 683-9300 • info@ni.com

For More Information Circle No. 486



Call for your **FREE**
IMAQ™ Vision
Evaluation Software

BUY ONLINE!



© Copyright 1998 National Instruments Corporation. All rights reserved. Product and company names are trademarks of their respective owners.

Precision Molded Plastic Optics

- Complete mold making facilities, including a CNC machining center, EDM machines and Nanoform 200 diamond turning center.
- State-of-the-art molding facilities.
- Comprehensive testing, measurement, and evaluation capabilities, including Zygo Interferometer, Taylor-Hobson Form TalySurf S6 PGI and various client-provided testing capabilities.
- High quality, quick turnaround diamond-turned prototyping in most substrates.
- High quality production of optical elements such as diffractives, hybrids, aspheres, cylinders, prisms, toroids, mirrors and HUDs.
- Collimating lenses for laser diodes.
- Optical design services provided from minimal assistance to full design capabilities.

For design, production or pricing information, please contact us.



AVIMO PRECISION POLYMER OPTICS

A member of Avimo Group Limited

560 West Terrace Drive
San Dimas, California 91773
Telephone 909-599-9341
Fax 909-592-2780
www.polymeroptics.com
Email: infoatappo@aol.com
salesatappo@aol.com

PHOTONICS Tech Briefs

Supplement to *NASA Tech Briefs* January 2000 Issue
Published by Associated Business Publications International

Features

- 6a Coatings that Weather the Testing Storm
- 10a The Way to the Spray
- 16a Photonics West Kicks Off the Millennium

Tech Briefs

- 18a Current-Mode Dark-Level Subtraction in LWIR Imaging
- 20a Segmented-Cold-Cathode Display Panels
- 22a Method of Measuring Encircled Energy in Imaging Optics
- 24a High-Power, Wideband Laser-Diode Transmitter Module
- 26a Software for Processing Data in Particle-Image Velocimetry
- 27a Telescope for Imaging and Laser Communication

Departments

- 4a The Power of Light—from SPIE, the International Society of Optical Engineering
- 28a New Products

Editorial Advisory Board

Bob Breault, President, Breault Research Organization

Dr. Geoffrey Burnham, President, Semiconductor Laser International

Dr. Jack D. Gaskill, Professor of Optics, Optical Sciences Center, University of Arizona

Dr. Arthur Guenther, Professor of Electrical Engineering and Physics & Astronomy, Center for High Technology Materials, University of New Mexico

R. Brian Hooker, Associate Research Professor, Dept. of Electrical and Computer Engineering, University of Colorado at Boulder

Heather Tooker, General Manager, Meadowlark Optics



Cover photo: Lasiris's new APM line of apodized phase masks have a spatially varying first-order diffraction efficiency that generates a special apodization profile to reduce the sidelobes in the Bragg response of the fiber grating. Photo courtesy Lasiris Inc., a Stocker and Yale company.

New

Break the 100 μm Barrier




**Drill Metal, Ceramic and Diamond
with High Speed and Accuracy**

With precision accuracy and high throughput, the Gator™ 2000 drills holes smaller than 100 μm (.004"), breaking the barrier for diode-pumped solid state laser technology. At 10 W, the Gator 2000 delivers a powerful beam for exact micromachining in metal, ceramic and diamond. The Gator 2000 offers the best of DPSS laser features to perform optimal drilling of even the toughest materials.

- Diode Pumped Solid State Nd:YAG laser with easy system integration
- 10 kHz repetition rate
- 10 W at 1064 nm; 6 W at 532 nm; 4 W at 355 nm
- High peak power with 15 ns pulse
- 1064 nm, 532 nm, 355 nm
- Superior beam profile
- Small footprint – 330 x 112 mm²

Amplifier and harmonics (30 W at 1064 nm; 15 W at 532 nm; 10 W at 355 nm) coming soon.

You can test the Gator 2000 in our application lab. Call your local sales office today for more information at 1-800 EXCIMER.



0.6 mm stainless steel,
100 μm diameter, low taper,
low roundness error.



Magnified hole from photo above. Gator is used for material processing in the automotive, semiconductor device manufacturing and medical device manufacturing industries.



Visit us at Photonics West, Booth #922



LAMBDA PHYSIK

Driving the Pulse of UV Technology

U.S.A: (954) 877-480-5768 • (954) 486-1500
FAX: (954) 486-1501

Germany: 49 (0)551 69380
FAX: 49 (0)551 68691

Japan: 81 (0)45 9397848
FAX: 81 (0)45 9397849

e-mail: marketingusa@lambdaphysik.com • www.lambdaphysik.com

Melles Griot makes Green DPSS Lasers



Our new 58 GCS series diode-pumped solid-state (DPSS) lasers deliver low-noise, single-mode output at 532 nm. Available in four power configurations, from 5 to 40 mW, these new lasers operate from a 5-Vdc supply and maintain excellent power stability over the entire operating temperature range.

The stable, diffraction-limited green beam is useful for R&D or OEM scanning, alignment, or fluorescence applications. The compact rugged housing contains all drive electronics, for easy integration into new or existing designs.

- 532-nm TEM₀₀ output
- Noise <0.5% rms
- Completely self contained
- + 5-Vdc input, 20 W maximum
- 0 to 40°C operation

Custom configurations available.

Find out more:

1-800-645-2737

www.mellesgriot.com/mg136.htm

Visit Us at
Photonics West
Booth No. 910

MELLES GRIOT

ELECTRO-OPTICS, INSTRUMENTS

4601 Nautilus Court South, Boulder, CO 80301 • 1-800-326-4363 • (303) 581-0337
FAX (303) 581-0960 • E-mail: sales@boulder.mellesgriot.com

LASER GROUP

2051 Palomar Airport Road, 200, Carlsbad, CA 92009 • 1-800-645-2737 • (760) 438-2131
FAX (760) 438-5208 • E-mail: sales@carlsbad.mellesgriot.com • www.mellesgriot.com

Canada (613) 226-5880 Denmark (08) 630-8950 France (01) 3012-0680
Germany (06251) 84060 Japan (03) 3407-3614 Netherlands (0316) 333041
Singapore 392-5368 Sweden (08) 630-8950 United Kingdom (01353) 654500



SPIE Corporate Services

SPIE—The International Society for Optical Engineering serves both individual and corporate members. The Society offers the following services for the companies that develop, distribute, and market optical, optoelectronic, photonics, and imaging technologies.

- Large industry exhibitions—Photonics West (see page 16a), Photonics East, and the SPIE Annual Meeting with its optical sciences and technology exhibit;
- Focused technical exhibits—Microlithography, Medical Imaging, Micromachining/Microfabrication, Smart Structures, and AeroSense with its focus on defense/sensing controls and simulation;
- Regional exhibitions—New customers in hot growth regions: Seattle, Albuquerque, Charlotte, Rochester, Toronto;
- Corporate membership—SPIE corporate membership helps companies network and build name recognition within a key technical audience, and provides the tools to train and educate employees in a cost-effective manner;
- Advertising—SPIE provides opportunities to contact the world's leading developers of optical and imaging products and processes through SPIE Web, OPTICS.ORG, *OEReports* (monthly membership newspaper), technical programs, journals, exhibit guides, and other vehicles.

SPIE exhibitions bring thousands of qualified professionals in contact with the suppliers of the solutions that meet their scientific and engineering needs. The Society sponsors exhibits in North America, Europe, and Asia. Corporate membership provides companies a voice on what exhibits need to be held when and where, and delivers a substantial discount each time a company exhibits.

SPIE operates on the principle that while individuals are its focus, behind those individuals are companies, universities, laboratories, and institutions which benefit from the information and fund much of the activities. By listening to the needs of the corporate citizens, SPIE can better serve them.

For more information on SPIE corporate services, contact SPIE—The International Society for Optical Engineering, PO Box 10, Bellingham, WA 98227-0010 USA; +1 (360) 676-3290; fax +1 (360) 647-1445; e-mail: spie@spie.org; web: <http://optics.org>.

How do you choose a superior scanner?

- ✓ Highest Speed?
- ✓ Smallest Size?
- ✓ Greatest Precision?
- ✓ Superior Reliability?
- ✓ Largest Aperture?
- ✓ Premium Price Performance?

That's Easy!

You choose Cambridge Technology, Inc., the world's leading manufacturer of closed-loop galvanometer based optical scanning components. Cambridge Technology focuses on your scanning applications with continued developments and innovations that always offer you the highest system performance levels.

You optimize your application for any combination of speed, accuracy, cost or size by selecting from Cambridge Technology's broad range of scanner options! We have solutions that offer frequencies of over 1 KHz, step response times of under 200 microseconds, positioning repeatability to the single micro-radian level and system operation into the billions of cycles.

We provide the highest levels of customer commitment, technology and technical support which makes Cambridge Technology the obvious choice and partner for your beam positioning system requirements. Contact our Sales Engineers and Field Representatives today for the very latest details on how our team can help you gain the competitive edge with superior scanning solutions!



109 Smith Place • Cambridge, MA 02138
Tel: (617) 441-0600 • Fax: (617) 497-8800
Web Site: <http://www.camtech.com>
E-mail: scanners@camtech.com

COATINGS THAT WEATHER THE TESTING STORM

Reactive sputtering produces durable coatings for a demanding environmental test application.

The response and resistance of products to the effects of weathering is of concern in a wide variety of industries. Typical examples include automobiles (exterior finish, paint, upholstery, plastics, trims), fabrics (clothing, carpeting, wall coverings, outdoor furniture), building materials (lumber, roofing), architectural coatings (paint, vinyl siding), toys, bicycles, and camping equipment, to name just a few.

Simply exposing a product under test to the elements, however, is not always the ideal way to perform this type of environmental testing, as the exact exposure conditions cannot be controlled and the process cannot be accelerated. On the other hand, accurately simulating outdoor exposure in the laboratory, especially the effects of natural sunlight, poses its own set of challenges. This article reviews the technology currently in use to perform accelerated weathering, and in particular examines the use of thin-film coatings to better match the output of xenon arc lamps to the natural solar spectrum.

Anatomy of a Weathering Chamber

The three major factors that determine damage to products outdoors are sunlight, moisture (in the form of both humidity and rain), and temperature. Thus, properly simulating outdoor exposure requires the ability to produce a given level of these parameters with accuracy, repeatability, and reproducibility. In this context, repeatability means the consistency of response of a particular testing station when given a specific input, and reproducibility means the unit-to-unit consistency for a specific input. When these three goals are achieved, then a test can be closely correlated with true outdoor exposure. This also enables a manufacturer to make an "apples-to-apples" comparison of the results of testing on various product formulations to determine which one will

work best under a certain set of conditions.

The photo of an actual weathering test chamber, the Atlas Ci4000 Weather-Ometer®, illustrates how such testing is implemented in practice (Figure 1). A high-intensity xenon arc lamp line source sits at the center of a stainless steel chamber. Specimens of the materials under test are placed on a barrel-shaped rack that rotates about the center of the lamp. This shape and motion of the rack are designed to enhance irradiation uniformity. A blower, sitting atop the unit, is used to draw air through the chamber. An array of water nozzles is available to produce "rain." Additionally, atomized water can be introduced into a compressed-air stream to enable any arbitrary chamber humidity within a certain range to be reached.

The lamp output is intended to simulate sunlight; some of it is channeled through a light pipe to an ultraviolet (UV) bandpass filter, and then on to a photodetector. This signal is then used in a closed-loop system to stabilize source output. The lamp is monitored in the UV for two reasons. First, most material degradation occurs because of UV exposure, so maintaining constant UV output is critical to achieving high accuracy, repeatability, and reproducibility. Second, the lamps themselves tend to degrade more quickly in the UV than they do in the visible or infrared (IR) portions of the spectrum.

A unique patented feature of the Weather-Ometer is its ability to independently control both chamber air temperature and the "Black Panel" temperature, which is an industry standard that is meant to represent worst-case surface temperature of the parts under test (due to heating by the light source). Air temperature is continuously monitored and



Figure 1. The Atlas Ci4000 Weather-Ometer.

regulated by opening or closing a damper, which in turn limits the ability of the blower fan to draw air through the chamber. Typically, the Black Panel temperature is measured by a resistance temperature device welded to a metal panel that is painted black and placed in the sample rack.

In operation, air temperature, sample temperature, humidity, and part irradiance can be held constant at various levels to simulate the type of exposure experienced at different locations (northern versus tropical latitudes) or during different seasons at a given location; alternately, exposure parameters can be cycled to simulate diurnal variations or the effects of specific weather patterns.

Accelerated Testing

Besides allowing precise control of exposure parameters, another important benefit of this type of environmental testing is that it enables acceleration of the weathering process. Obviously, when testing a product designed to withstand ten years of exposure, it is not practical to take that long to perform the experiment.

Accelerated testing is accomplished through two means. First, the percentage of time a part is exposed to sunlight during a 24-hour period can be increased up to 100 percent. In the real world, even during daylight hours, the changing angle of the sun alters the level of exposure experienced out in the open. Thus, maintaining a noontime light level over an entire day of testing results in far more than a twofold

When Accuracy Is Important To Your Project.

When it comes to choosing an optical design & analysis software tool, it makes sense to choose the tool that is recognized throughout the industry for accuracy and reliability: CODE V® from Optical Research Associates (ORA®).


CODE V is the most comprehensive, accurate, and powerful optical design & analysis software available. Including:

- Exact Optimization Constraint Handling holds constraints in all cases
- Global Optimization that works
- NEW Diffraction-based Beam Propagation
- Powerful Macro Language including Fast Fourier Transform function

When accuracy counts, you'll be glad to know that our in-house optical engineers have used CODE V on over 4000 successful customer designs.

To help assure your success, you can count on ORA technical support—optical engineering professionals who speak your language and know the importance of accurate results.


The optics may be complex, but the choice is simple. When accuracy is important to your project, the answer is CODE V.



Non-sequential Surface Modeling and an Interferogram Interface are two of the many advanced features of CODE V.

code v®

Near & Far Field Intensity Output from CODE V's **NEW Beam Propagation Feature** along with applications that demand accuracy. CODE V was the leading software package used to design the optics installed during the First Servicing Mission of the Hubble Space Telescope.



**OPTICAL
RESEARCH
ASSOCIATES**

www.opticalres.com

Corporate Headquarters: 3280 East Foothill Boulevard, Suite 300, Pasadena, CA 91107-3103 (626) 795-9101
Fax (626) 795-0184 E-mail: service@opticalres.com Web: www.opticalres.com

Midwest Office: Beachwood, OH **East Coast Office:** Westborough, MA

CODE V and ORA are registered trademarks of Optical Research Associates. Wide angle lens photo courtesy of Coastal Optical Systems, Inc.

For More Information Circle No. 480

• VERSION •
8.4
• WITH BEAM PROPAGATION •

increase in exposure. The second method of producing acceleration is to use light levels that are greater than "one sun." This can also be accompanied by higher air temperature and humidity.

Accurate Solar Simulation

In order for laboratory weathering to simulate accurately the effects of real-world exposure, it is essential that the output spectrum of the light source closely match the solar spectrum. The xenon arc lamp source approximates solar radiation well; however, its output does contain some intense spectral lines in the IR and also extends deeper into the UV than the sun does (Figure 2). The IR spikes become particularly problematic during accelerated testing—greater than one sun exposure levels—because they produce excessive product heating.

Historically, absorptive glass filters have been the solution for eliminating the unwanted UV and IR portions of the xenon arc lamp spectrum. IR absorption filters, however, are notoriously unstable in the critical UV, and significant changes in UV transmission challenge efforts to achieve repeatability and reproducibility. Thin-film coatings are inherently more stable, and can also be designed to block the IR spikes in the xenon lamp output more precisely.

In the case of the Atlas Ci4000 Weather-Ometer, however, the filters are in the form of long concentric cylindrical tubes that surround the lamp. Water is flowed in through the inner tube and back out through the outer tube to cool the lamp. Thus, a thin-film coating for this application must be deposited on a small-radius tube and also be capable of surviving both high flux levels and direct exposure to the continual abrasive flow of cooling water.

Traditional evaporative coating technology cannot meet these demands for a number of reasons. First, it is difficult to uniformly coat the entire surface of highly curved parts using evaporation methods. More importantly, this type of film is relatively porous, and a porous film has poor resistance to heat and mechanical wear, and also tends to absorb water, caus-

ing a shift in its spectral characteristics.

Sputtering is an alternative coating method that provides denser films and also enables uniform deposition on highly curved parts. Sputtering is con-

mechanical and thermal characteristics. Recently, Deposition Sciences Inc. has developed a new approach to reactive sputtering called the MicroDyn® process. In MicroDyn, sputtering is augmented by a microwave plasma that forms a wider range of oxygen species (ozone, etc.) to enhance the reactive process. The net result is faster, more efficient deposition, with greater control and variation of the deposited material's refractive index.

Using MicroDyn sputtering, it has been possible to produce a filter that supplies the necessary spectral characteristics, while delivering sufficient mechanical density to withstand prolonged exposure to water, heat, and high flux levels. Specifically, a multilayer, broad-bandpass filter with a cut-on deep in the UV and a cut-off in the IR is deposited on the outside diameter of the inner tube. The cut-off of the filter is placed to provide the precise attenuation of IR wavelengths required; the UV cut-on is placed at a wavelength much lower than required. The outer tube is then fabricated from sharp cut-on absorptive glass, which only transmits above the necessary UV wavelength, but has relatively low IR absorption for maximum stability. This arrangement enables the

overall transmission to be optimized on both the long- and short-wavelength ends of the spectrum simultaneously.

Laboratory weathering enables manufacturers in a broad range of industries to improve their products' durability and lifetime. Recent developments in coating technology have now enabled weathering systems with both improved solar accuracy and greater reliability.

The authors of this article are Robert Crase, lighting operations manager of Deposition Sciences Inc., and Kurt P. Scott, general manager of laboratories and calibration services for Atlas Electric Devices. For further information, contact Deposition Sciences at 386 Tesconi Court, Santa Rosa, CA 95401; (707) 573-6785; fax (707) 579-0731; e-mail: bob.crase@depisci.com; www.heatbuster.com; or Atlas Electric Devices at 4114 N. Ravenswood Ave., Chicago, IL 60615; (773) 327-4520; fax: (773) 327-5787; e-mail: kscott@atlas-mts.com.




Figure 2. Xenon arc lamp output versus solar radiation spectrum.

ducted in a chamber filled with an inert gas at low pressure. Targets of various conductive materials are placed around the periphery of the chamber. A high voltage is applied to the targets, ionizing the gas around them to form a plasma. These ions are then accelerated into the target, causing atoms to sputter off. The sputtered atoms fill the chamber, and some are deposited on the surfaces of the optics. The low-pressure gas randomizes the movement of the sputtered atoms, leading to uniform deposition on all surfaces regardless of their orientation relative to the material source. Furthermore, the high energy of the sputtered atoms produces coatings that are inherently denser than is achieved through evaporation.

If oxygen is introduced into the machine during sputtering, it will react with the atoms of the material to produce oxides. This process, called reactive sputtering, yields coatings with even better



Modular Photonics Test Systems

Model 8800 and 8200 mainframe controllers house a variety of plug-and-play instrumentation modules which enable users to test and characterize components and systems used in DWDM, datacom, sensor and other applications.

High-Density LD Control

Control up to 16 laser diodes with our Model 8016 High-Density LD Controller. When used with the Model 708 eight-channel butterfly telecom LD Mount, pump lasers or DFB lasers can be controlled in a convenient, rack-mountable configuration.



DWDM Reference Standard

The Model 2010WR Wavelength Reference Standard provides a rock-solid set of densely spaced vapor cell absorption lines in the 1512 to 1563nm range, accessible via a single-mode output port. Applications include OSA calibration or locking of WDM sources.



The new kids on the bench.

Newport is now into fiber optic test and measurement instrumentation in a big way. Our presence in the fiber optic market is greater than ever. And with the introduction of this new line, so is your choice of test equipment.

Our instruments offer all the features and functions you need to perform DWDM-related tests with speed, precision and accuracy. So now you can concentrate on the quality of your testing without wondering about the quality of your equipment.

Newport. Your new, one-stop shop for fiber optic testing. For your free 1999/2000 catalog that features our entire product line, visit www.newport.com/wdm or call us today at 800-222-6440.

Tunable and Locked LD Sources

Our Model 2010 Tunable Laser Diode systems feature 20 laser modules which cover the 630 to 1780nm range. Model 2010S Stabilized Light Sources incorporate a vapor cell-based locking mechanism, creating a reliable light source with an extremely narrow linewidth of <100 kHz at a variety of preselected wavelengths.



The Way to the SPRAY

A high-speed measurement and analysis system aids in improving the efficacy of nasal inhalers.

Image Therm Engineering of Waltham, MA, has developed a state-of-the-art nonintrusive nasal-inhaler spray characterization system. The system design included a Kodak high-speed digital camera and a Lasiris diode laser sheet generator. The analysis and processing software of the system was fully implemented using LabVIEW and IMAQ Vision from National Instruments of Austin, TX. SprayVIEW is currently being used as a research and development tool for current and pending nasal-spray-based medications at Muro Pharmaceutical of Tewkesbury, MA, while Image Therm seeks FDA approval and patents for the system's novel measurement and analysis techniques.

The fluid-dynamic characterization of the aerosol spray emitted by nasal inhalers is crucial in determining the overall performance of the inhaler as a medicinal delivery system to people suffering from various respiratory ailments. Thorough characterization of the spray's geometry has been found to be the best indicator of the overall performance of most nasal inhalers. In particular, measurements of the spray's divergence angle as it exits the inhaler, the spray's cross-sectional ellipticity and uniformity, and the time evolution of the

developing spray have been found to be the most representative performance quantities in the characterization of an inhaler design.

These measurements are typically used to optimally match the spray pump's performance characteristics with the fluid properties of the liquid medicine solution, resulting in a more cost-effective and efficient product design. But accurate, reliable, and easy-to-use protocols and a system for nasal spray characterization do not exist for these inhalers. These needs were the motivation for this work.

TLC-Plate Testing Technique

The nasal spray testing standard in use today at many pharmaceutical companies involves firing the spray pump at a solid, thin-layer chromatography (TLC) plate. This plate is positioned at a fixed height above the end of the pump's tip. Spray pattern analysis is done by first exposing the particle-covered plate to UV radiation, causing its coating to fluoresce and helping to highlight the spray pattern. Marking instruments and




Figure 1. Spray-pattern test setup showing the horizontal laser light sheet, camera, and nasal-spray pump actuator.




Figure 2. Spray geometry test setup showing the vertical laser sheet, camera, and nasal-spray pump actuator.

mechanical calipers are then used to draw and measure an outline of the deposited pattern on the plate. Measurements of the pattern's ellipticity in terms of major and minor diameters are recorded.

Experience has revealed many problems with this technique, including:

- Radical changes to the fluid dynamics of the spray caused by the presence of the TLC plate;
- Flow complications induced by the large amount of spray particles that bounce off the plate;
- Operator error, causing inaccurate measurements of the spray pattern; and
- Lack of support for spray geometry measurements.

OptiCAD[®]

New Version 6.0!
Now with IGES import

Software for Stray Light and Illumination Analysis

OptiCAD models arbitrary 3D optical systems illuminated by multiple arbitrary sources. Objects and light sources are defined, placed and combined in a 3D CAD environment.

Objects are created within OptiCAD, or imported using IGES, STL, or ZEMAX[®] format files. Once objects are imported, surface and volume properties such as glass, gradient index, transmission, reflection, scattering, absorption, and thin film coatings are applied.


Scattering models include BSDF/BRDF data or parametric formulas. Optical coatings may be multilayer dielectric or metallic coatings.

Light sources are defined using points, lines, arcs, luminous volumes, IESNA lamp data or Radiant Source[™] data files. Multiple sources may be placed anywhere within the geometry.


OptiCAD then performs ray tracing to determine irradiance distributions on any surface anywhere in the model. All effects of transmission, reflection, scattering, absorption, TIR, and polarization are accounted for. At surfaces which partially transmit and partially reflect light, both paths are traced to account for all energy.

OptiCAD imports objects designed in mechanical CAD packages using the built-in IGES or STL convertors. OptiCAD models surface and volume scattering, and supports user defined sources and gradient index media.



OptiCAD is priced at \$3,500.00 and runs under Windows 95/98 or NT. Please contact Focus Software or visit our web site for more information.



False color irradiance distributions are viewed anywhere "in place" on detectors of arbitrary shape.



Complex objects may be imported, like this IGES light bulb. Other objects, such as this lenslet array, are generated within OptiCAD.



BSDF/BRDF measured scattering data may be placed on any surface for accurate modeling of scattered light.




Image of a helical light source ray traced in OptiCAD. Light sources include parametric models, user defined, or tabulated ray data.



FOCUS
SOFTWARE, INC.

Focus Software, Incorporated
P. O. Box 18228, Tucson, Arizona 85731 USA
Tel: (520) 733-0130 Fax: (520) 733-0135

www.focus-software.com

OptiCAD is a registered trademark of The OptiCAD Corporation. ZEMAX is a registered trademark of Focus Software, Inc.

Radiant Sources is a trademark of Radiant Imaging, Inc.

Hardware and System Design

A thorough search of existing technology that could be used or adapted for this system was conducted at the outset of the project. The team finally decided on a hybrid design consisting of a combination of off-the-shelf and custom-made components. The system's basic components are:

- SprayVIEW software built using National Instruments' LabVIEW and IMAQ Vision software;
- a Kodak (San Diego, CA) SR-500 MotionCorder Analyzer high-speed digital camera system;
- a Lasiris (St. Laurent, Quebec) Magnum 4000 4-W laser diode sheet generator operating at 810 nm;
- an InnovaSystems (Pennsauken, NJ) pneumatically controlled mechanical actuator with a digital trigger.

National Instruments' software was used to build the SprayVIEW system software because it provided the best mix of image processing functionality and user interface development tools that would be needed to implement the final custom application. In addition, the SCSI Toolkit for LabVIEW from Icon Technologies of Victoria Park, Australia helped to provide seamless integration for downloading the digital images from the Kodak SR-500 into the SprayVIEW system.

The team chose the Kodak digital camera system because it has a programmable framing rate from 30 to 500 fps at resolutions up to 512 x 480 pixels with 256 grayscales (8-bit). In addition, it has fast on-board memory that allows reliable image captures and a SCSI interface bus for direct downloading of these images to the custom-developed SprayVIEW analysis software running on the host computer.

The researchers selected the Lasiris laser sheet generator because it operates in a continuous mode, produces a thin sheet of laser light directly, and favorably matched the spectral response characteristics of the Kodak camera for adequate illumination of the spray particles.

Since the duration of a single pumping of the spray is on the order of one second, it is crucial to have accurate synchronization between the spray pump actuator and the camera. The InnovaSystems nasal spray pump actuator was

chosen because it is standard equipment at many pharmaceutical companies and could be used to trigger the camera accurately when the spray pump is fired.




Figure 3. SprayVIEW spray-pattern measurement tools showing spray ellipticity on the summary image.

Setting up the System

The spray pump is first filled with test fluid and inserted into the mouth of the actuator, which has been precalibrated for compression force and duration per company testing guidelines. The camera is set to capture at 500 fps at a resolution of 512 x 240 pixels. The input trigger is




Figure 4. SprayVIEW spray-geometry measurement tools showing spray divergence angle on the summary image.

armed and set to wait for the actuator to fire. The laser is turned on and its light sheet is focused to a thickness of approximately 1 mm when it illuminates the plane of spray particles.

In this configuration, the laser is positioned so that it illuminates a predetermined axial cross section of the spray directly downstream of the spray pump, as shown in Figure 1. The camera is positioned so that it can view the spray pattern from above at angle slightly off-axis to prevent the spray particles from directly impinging on the camera and

lens. A calibration target is then temporarily placed in the plane of the laser sheet, and the camera lens is adjusted until the target comes into focus. An image of the focused target is captured with the camera and downloaded to the computer. This target image is used as a basis for calibrating the physical coordinate system of the spray-pattern images and to perform the necessary perspective correction to the images to account for the off-axis viewing angle.

The target image is then removed from the scene, and the trigger is fired on the actuator, causing the camera to start capturing the time-evolving images of the spray pattern. This takes about two seconds. When completed, the images are downloaded from the camera into the SprayVIEW system.

In this configuration, the laser is positioned so that it illuminates a plane of particles parallel to the flow direction along the centerline of the spray, as shown in Figure 2. The camera is positioned perpendicular to the plane of the laser light's sheet. As in the spray pattern test, the calibration target is temporarily placed in the plane of the sheet and the camera lens adjusted until the target comes into focus. Since in this case the camera views the scene normally, no perspective correction is necessary, so the target image is used solely for calibrating the physical coordinate system of the images of the spray geometry. Again, the target image is removed from the scene, the actuator trigger is fired, and the acquired images are downloaded from the camera into the SprayVIEW system.

Image Processing and Analysis

The SprayVIEW software was designed specifically to combine powerful image processing and analysis functionality with an intuitive and easy-to-use interface for detailed study of spray images by technicians and scientists alike. The software's VCR-like controls and variety of color palettes allow a user to visualize the details and development of the time-evolution of the spray images.

Our Hot Mirrors clearly have explosive advantages.



The line between success and failure is often as thin as a mirror. If your specifications call for hot mirrors, it's time to call ZC&R. No matter what your need, from off-the-shelf to custom coatings, you'll find all your solutions in one place – ours. And if cold mirrors are more your style, ours stand up to even the toughest test. Our filters always give you superior separation of visible, UV and IR radiation. So don't let your project go up in smoke. For a closer look into our mirrors, call us today. ZC&R. Burning up the competition.



Crystal Clear Hot Mirrors

Guaranteed color neutral even at 5500° K, our crystal clear hot mirrors are perfect for applications such as entertainment lighting, biomedical applications and fiber optics. Guaranteed not to peel, fade or craze.

- Ave. T \geq 90% at 425-675 nm
- Ave. R \geq 95% at 750-1150 nm
- Incident angle = 0°



Cold Mirrors

Our cold mirror filters reflect visible light and transmit IR. They are used in a wide variety of products from projectors to fiber optic illuminators.

- Ave. T \geq 90% at 750-1200 nm
- Ave. R \geq 95% at 420-650 nm
- Incident angle = 45°



UV Pass Hot Mirror

Designed to block IR and allow visible and UV light to pass through, these hot mirrors are especially well adapted for UV curing of inks, dyes and cements.

- Ave. T \geq 85% at 245-680 nm
- Ave. T \geq 86% at 245-400 nm
- Ave. R \geq 75% at 800-1050 nm
- Incident angle = 0°

Extended Hot Mirrors

Similar to our crystal clear hot mirrors, our extended hot mirrors provide a wider range of IR protection. They are ideally suited for applications which also require reflectance from 1200 to 1600 nm. Guaranteed not to peel, fade or craze.

- Ave. T \geq 85% at 425-675 nm
- Ave. R \geq 95% at 750-1150 nm
- Ave. R \geq 85% at 1200-1600 nm
- Incident angle = 0°

ZC&R

COATINGS FOR OPTICS

See us at Photonics West
Booth #1236

1401 Abalone Ave. / Torrance, CA 90501
310-381-3060 / 800-426-2864 / FAX: 310-782-9951
e-mail: info@zcrcoatings.com / www.zcrcoatings.com

For More Information Circle No. 475 or Visit www.nasatech.com/475

The time-average or summation tool allows a user-selectable range of spray images to be combined to simulate the trajectory of the individual particles in the spray. This key feature allows the 200+ valid images from a typical test to be represented in one image that can be used for measurements of the spray's uniformity, ellipticity, and divergence angle, for example. The summary image is also the closest representative of the TLC-plate technique, and this pseudo-backward compatibility forms a key requirement for FDA approval of the system.

Measuring Pattern and Geometry

Spray pattern images are analyzed and processed using the pattern tools. These tools allow a user to specify the major and minor axes of an elliptical pattern template on the summation image. The axis specification is accomplished using interactive cursors that are dynamically linked to line profiles of particle intensity along the axes in absolute and percentage units. The user can adjust the cursors until the most representative elliptical pattern has been specified based on the intensity profiles and computed measurements of the ellipticity ratio, as shown in Figure 3.

Once this elliptical template has been specified, the VCR controls can be used to play back the images in the time-evolution of the spray while simultaneously displaying an overlay of the template. This feature allows a user to visualize the time-evolution of the particle distribution and dynamically compare it to the time-averaged pattern of the particles in a very intuitive manner.

Spray geometry images are analyzed and processed using the geometry tools. These tools allow a user to specify the vertex and included angle of a set of two intersecting orthogonal lines on the summation image. The line specification is accomplished using interactive cursors that are dynamically linked to line profiles of particle intensity along the lines in absolute and percentage units. The user can adjust the cursors until the most representative line-pattern template has been specified based on the intensity profiles and computed measurements of the divergence angle, as shown in Figure 4. Once again, this line-pattern template can be simultaneously overlaid on the time-evolving images and played back using the VCR controls for comparison purposes.

Results and Summary

Muro Pharmaceutical and Image Therm Engineering successfully combined their knowledge and experience with nasal-spray drug development, fluid mechanics, high-speed imaging and image processing software to develop the novel SprayVIEW spray characterization system. It allows spray-based drug developers to characterize the time-evolution, cross-sectional ellipticity, and divergence angle of spray patterns quickly and effectively. The system's nonintrusive optical-based design provides significantly improved measurement performance over the currently accepted TLC-plate-based testing technique. The highly modular hardware and software implementation of the system allows easy customization to meet the needs of a variety of spray-testing applications both in R&D and production environments.

For more information, contact the authors of this article, Dino J. Farina, President, and Socratis Kalogrianitis, Software Designer, at Image Therm Engineering, 159 Summer St., Suite 2R, Waltham, MA 02452; (781) 893-7793; e-mail: farina@imagetherm.com.

Oriel Engineered & Manufactured

- **UV - IR Detection Systems**
- **UV - IR Light Sources 10 to 1,000 W**
- **Solar Simulators**
- **Monochromators**
- **Imaging Spectrographs**
- **Lock-in Amplifiers with DSP**
- **PDA's & CCD's**
- **Cooled Detection Systems**
- **Fiber Optics & Optical Components**
- **Raman PL Systems**
- **FT-IR Spectrometers**

Optical Instruments & Components



Optics



Micropositioning & Control Products



See us at Photonics West 2000
Booth # 1746 & 1748

Oriel is a partner to OEM and researchers who work with light. Oriel is the leader in supplying technically superior instruments and components for the best value anywhere. We continually create and develop new products for OEM and research applications. When you buy from Oriel, you can expect to get the most advanced state-of-the-art instruments and components in the industry, all backed by superior service.

Oriel Instruments

150 Long Beach Boulevard
Stratford, CT 06615 USA
TEL: 203-380-4376
FAX: 203-375-0851
E-MAIL: res_sales@oriel.com





Request our NEW catalog!

203-380-4376

www.oriel.com



LASER & LASER DIODE TO FIBER DELIVERY COMPONENTS



Photonics West

Showcasing the Power of Light for the New Millennium


Kicking off the new millennium, SPIE's Photonics West technical symposium and exhibition will fill the San Jose (CA) Convention Center January 22-28. Better than 12,000 are expected to attend from all over the world: 5000 technical attendees, 4000 for the exhibits only, and 3000 exhibitor representatives. Companies displaying products in the exhibit hall, which is completely sold out, number around 550. Eighty-five conferences are scheduled, making up four symposia: BiOS 2000, the International Biomedical Optics Symposium; Lase 2000, concentrating on High-Power Lasers and Applications; Optoelectronics 2000, featuring Integrated Optoelectronic Devices; and Electronic Imaging 2000, centering on its Science and Technology.

The opening shot is what SPIE is calling "Saturday Night Hot Topics" on January 22. From 7:30 to 9 pm, a group of conference chairs and other presenters at BiOS talk about leading developments in the application of photonics to medicine. Other special events take place throughout the week. On Monday from 2-5 pm a working session will consider the new draft standard on optical glass that will replace MIL-G-1748. From 7-9 pm a technical group meeting on research, engineering, and applications of holography takes place, as does a workshop called "Transitioning Optical Coherence Tomography to Industry and Health Care."

Tuesday through Thursday sees two-hour (8-10 am) workshops on the future of optoelectronic markets, sponsored by the Optoelectronics Industry Development Association: Optical Communications (Jan. 25), Electronic Imaging (Jan. 26) and Defense Applications (Jan. 27). A technical group meeting on Wednesday (4-6 pm) centers on Electronic Imaging, and two on Thursday on High-Speed Photography, Videography, and Photonics (12-1:50 pm) and Laser Communications (7:30-9 pm).

BiOS 2000 focuses on several biomedical programs: Clinical Applications, Clinical Instrumentation, Tissue Science

and Engineering, Optical Diagnostic Technologies, and Functional Imaging and Biomolecular Analysis. Among the subjects treated are diagnostic and therapeutic cardiovascular interventions; innovations in breast cancer diagnosis and minimally invasive therapy, including laser-interstitial thermotherapy; optical methods for tumor treatment and detection, including photodynamic therapy; and biomedical applications of free-electron lasers. Micro- and nanotechnology for biomedical and environmental applications is a highlight of the Clinical Instrumentation confer-



Laser Science's new pulsed μ -TEA carbon dioxide laser is among the products that will be demonstrated at Photonics West's Product Forums late this month.

ence, which also includes a Critical Review called "Matching the Energy Source to the Clinical Need." Critical Reviews convene a group of invited recognized experts, each of whom presents an extended invited paper on his or her specific field. The collection of presentations is intended to be an authoritative overview of the technology. Biomedical spectroscopy, vibrational spectroscopy, and other novel techniques are a key focus of the Optical Diagnostic Technologies conference.

Lase 2000, drawing a bead on high-power lasers and applications, has two programs: Laser Engineering and MicroEngineering/Manufacturing. In the first, a Critical Review on novel materials and crystal-growth techniques for nonlinear optical devices is followed by a conference on nonlinear materials, devices, and applications. Other conferences include solid-state lasers, laser resonators, gas and chemical lasers and

intense beam applications, high-power electrical lasers and beam control, and free-space laser communication. In the second, laser applications in microelectronic and optoelectronic manufacturing are stressed, along with laser plasma generation and diagnostics.

Optoelectronics 2000, encompassing Integrated Optoelectronic Devices, has three programs: Optoelectronics Materials and Devices, Semiconductor Lasers and Photodetectors, and Hybrid and Monolithic Optoelectronic Integrated Circuits (OEICs). These will be introduced by a series of plenary presentations. On Monday at 8:30 am, the subjects are "Atom Interferometry in Materials Research" and "Two-Dimensional Photonic Bandgap Lasers and Waveguides." Following at 9:15 are "Progress and Commercialization of InGaN-based Violet/Blue Laser Diodes" by a representative of the Nichia Corp. of Japan, and "Plastic Optoelectronics." On Tuesday at 8:00 am the subject is "Soliton Telecommunications." Following at 8:40 is "Polymers in Integrated Photonics—Applications Where They Have the Advantage," and at 9:20 am "Innovative Photonic Components Technology for Communications Systems."

In the first of Optoelectronics 2000's programs there are presentations on micro- and nano-photonic materials and devices, the research, manufacturing, and applications of light-emitting diodes, organic photonics materials and devices, rare-earth-doped materials and devices, and sol gel optics, among others. The second program includes papers on laser diodes in industrial measurement, imaging, and sensors applications, vertical-cavity surface-emitting lasers, and photodetector materials and devices, among others. In the third, there are presentations on WDM and photonic switching devices for network applications, diffractive/holographic technologies and spatial light modulators, and photonics packaging and integration, among others.

Concurrent with these programs, running from Sunday, Jan. 23, through

Friday, Jan. 28, there are 87 courses and 6 workshops in the Continuing Education Program, for which CEUs—Continuing Education Units, a nationally recognized unit of measure—are awarded to registrants who complete the courses.

A special pavilion will be devoted to the Electronic Imaging 2000 symposium, sponsored by SPIE and the Society for Imaging Science and Technology. The symposium's 26 conferences are organized into eight programs: 2D Displays; 3D Capture and Display; Electronic Imaging Systems and Image Processing Methods; Document Imaging, Sensor, and Camera Systems; Image Sequence and Data Analysis; Multimedia Processing and Applications; Optical Security and Anti-counterfeiting; and Image and Video Communications and Processing. The sessions Tuesday through Thursday will be launched each day by a plenary presentation: "Evolution of Digital Photography" (Tues.), "The Co-evolution of Humans and Computers" (Wed.), and "Multispectral Imaging: Fundamentals and Applications" (Thurs.). Individual conferences deal with such topics as projection displays; liquid crystal materials, devices, and flat panel displays; holographic materials; stereoscopic displays and applications;

applications of artificial neural networks in image processing; sensors, cameras, and systems for scientific/industrial applications; Internet imaging; security and watermarking of multimedia contents; and optical security and counterfeit deterrence techniques.

In recent years SPIE has introduced a talked-about series of Product Forums, which take place in the areas called "Town Squares" set aside in the exhibit hall. In a Product Forum, an exhibiting company demonstrates new and successful products in half-hour question-and-answer sessions. This year, in the Laser Town Square, Laser Science introduces its μ -TEA carbon dioxide laser (10:30 am Tuesday); QED Technologies demonstrates the innovative polishing technique for high-precision plano, spherical, and aspherical optics using magnetorheological finishing (11:30 am Wednesday); the market research firm ElectroniCast presents an analysis and 10-year forecast of the global consumption of optical fiber, planar waveguide, and free-space signal and interconnect components (12:30 pm Tuesday); and New Focus shows real-time manufacturing testing using a swept wavelength laser (2:30 pm Tuesday), among other events.

In the Photonics Town Square, Arris International presents a Product Forum

on new materials for the new millennium (12:30 pm Tuesday); Breault Research Organization shows off ASAP 6.6, the latest version of its well-known optical modeling and analysis software (10:30 am Wednesday); and OFC's Diamond Turning Division demonstrates the efficiencies obtained using diamond-turning optical systems having comachined datums for ease of alignment (12:30 pm Wednesday), among other sessions.

In the Electronic Imaging Town Square, GF Measurement demonstrates how the digital projection of light by digital micromirror devices invented by Texas Instruments (Dallas) opens up new possibilities in optical data projection (10:30 am Tuesday); Kodak Microelectronics Division shows its BluePlus line of high-performance CCD image sensors (11:30 Tuesday); and Foresight Imaging stages a demonstration of its automatic configuration software Auto-SYNC, among other sessions.

Symposium registration fees include admission to all conference sessions, either one or two proceedings volumes, one abstract book, plenaries, panels, poster sessions, receptions, coffee breaks, and exhibits admission. For more information, or to register, contact SPIE at (360) 676-3290; fax: (360) 647-1445; e-mail: pw@spie.org; web: www.spie.org/info/pw/.

AeroSense

SPIE's 14th Annual International Symposium on

Aerospace/Defense Sensing, Simulation and Controls

24–28 April 2000 • Marriott's Orlando World Center Resort and Convention Center • Orlando, Florida USA

Thermosense

Guidance & Navigation

Modeling, Simulation, & Visualization

Image Exploitation & Target Recognition

Tactical Sensors including Infrared & Radar

Displays

Laser Sensing

Signal & Image Processing

Wavelets & Neural Networks

Battlefield Technologies

New! **Data Mining**


New! **Oxide Nanoengineering**

Continuing Education • Technical Exhibit

Participate in the foremost international meeting for aerospace/defense sensing, simulation, and controls!

Contact SPIE today!

Phone 360/676-3290 • E-mail spie@spie.org • Web www.spie.org/info/or/

 **SPIE** The International Society for Optical Engineering

Current-Mode Dark-Level Subtraction in LWIR Imaging

This circuit offers high dynamic range and low noise.


NASA's Jet Propulsion Laboratory, Pasadena, California

A complementary metal oxide/semiconductor (CMOS) focal-plane readout circuit for an imaging array of long-wavelength infrared (LWIR) photodetectors effects in-pixel current-mode

subtraction of the dark-level component of each photodetector output. The dark-level signal is subtracted before the signal reaches the integration node. Consequently, for each pixel

in the array, the readout noise is minimized and the net gain and dynamic range are maximized.

This readout circuit was designed to overcome two major obstacles to the



Each Unit Cell of the Readout Circuit effects in-pixel current-mode subtraction of the dark-level component of each photodetector output prior to integration.



Plastic Optics



At G-S, we manufacture precision plastic optics for a variety of opto-electronics applications including imaging, sensing, scanning and detecting.

If you are in fiber optics, low-power laser systems, security, machine vision, or presence sensing — plastic optics can be your solution to cost reduction and weight reduction by combining parts and utilizing alignment features.

We provide custom plastic optics made to your exact specifications. We have extensive experience utilizing plastic in integrating optics into your part — Fresnel lenses, mirrors, diffractive optics and band pass filters from design through production.

Our continuous investment in state-of-the-art production and metrology equipment demonstrates our total commitment to meeting your demanding requirements.



G-S PLASTIC OPTICS
A Germanow-Simon Company
Since 1916

408 St. Paul Street, Rochester, NY 14605 USA
Phone: 888-203-9798
Fax: 716-232-2314
E-mail: gs optics@gs optics.com

VISIT OUR WEBSITE AT www.gs optics.com

achievement of high performance in LWIR arrays used in imaging or spectroscopy under common operating conditions:

- Leakage in the photodetectors and/or high scene background gives rise to a large background signal, making it necessary for the focal-plane circuitry to handle of the order of several billion electron charges per pixel per readout cycle. Ordinarily, prohibitively large capacitors would be needed to handle such large amounts of charge, and the handling of large amounts of charge would introduce additional noise.
- Often, there is poor signal-to-background contrast in the sense that the signal of interest is of the order of only 10^{-4} or 10^{-3} times the background signal.

The present circuit operates in a readout cycle in which a blanking or calibration phase alternates with an imaging phase. During the blanking phase, a current-memory circuit memorizes the background current for use in predicting the background current for the subsequent imaging phase. During the imaging phase, the current-memory circuit acts as a high-impedance current source that generates the predicted background current,

which is subtracted from the photodetector output current to obtain the signal current of interest. This signal current is coupled to external circuitry through low-noise circuitry, and an innovative biasing scheme improves low-noise performance.

A prototype of the circuit comprises a bilinear array of 2×132 multiplexers. Each unit cell (see figure) contains a LWIR photodetector [more specifically, a quantum-well infrared photodetector (QWIP)], a buffered-direct-injection (BDI) input circuit, a current-mode pedestal-subtracting circuit, and a voltage-mode double-sampled differential readout (DSDR) circuit. The BDI input circuit provides the stable bias needed for operation of the QWIP, plus a high input impedance that enables high quantum efficiency. The current-mode pedestal-subtracting circuit comprises a cascode current-memory circuit, and an isolation field-effect transistor (FET) denoted " M_{read} ."

During the blanking phase, the current I_{bak} flowing through the QWIP consists of the detector dark current (usually the dominant component, of the order of a few hundred nanoamperes) plus a smaller current due to scene and instrument background. I_{bak} is the pedestal signal that one seeks to subtract. Ideally, once the current-memory circuit has memorized I_{bak} , it should be able to generate $I_{mem} = I_{bak}$. However, because of imperfections in the circuit, I_{mem} and I_{bak} differ by a small amount: $I_{mem} = I_{bak} - I_{res}$, where I_{res} is denoted the error current. The pedestal signal due to I_{res} cannot be eliminated in the current-mode subtraction; therefore, it is estimated in the voltage mode by integrating the error current onto capacitor C_R in the DSDR circuit. This completes the memorization of the background signal.

During the imaging phase, the current through the QWIP rises above I_{bak} by an amount I_{sig} , which represents the infrared signal to be measured. Thus, the current sent to the integration node during the imaging phase equals $I_{sig} + I_{res}$. Once the imaging phase has been completed, the voltage V_{int} obtained by integrating $I_{sig} + I_{res}$ onto integration capacitor C_{int} is sampled on capacitor C_S in the DSDR circuit. As a result, the difference between the potentials on C_S and C_R is almost exactly proportional to I_{sig} , with background suppressed by factor of more than 10^4 .

The gate of M_{read} is dc-biased with a voltage, such that during the blanking

phase, the current-memory potential shuts M_{read} off, while during the imaging phase, the source of M_{read} charges up to a potential that enables the injection of current into the integration node. This biasing scheme makes it possible for the circuit to operate without need to apply a pulse signal ϕ_{read} to M_{read} . In so doing, the biasing scheme helps to keep noise low by preventing the injection of switching noise into a sensitive node.

The circuit provides for noise-limited measurement of signals 85 dB below the dark level. It is designed to operate with low power dissipation and high

linearity, and is capable of handling pedestal currents up to 300 nA. Accurate subtraction of background charge makes possible a charge-handling capacity of $>5 \times 10^9$ electron charges per pixel.

This work was done by Bedabrata Pain, Guang Yang, Chao Sun, Timothy Shaw, and Chris Wrigley of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

NPO-20486

CCD ARRAY COOLED SCIENTIFIC CAMERAS

Spectral Instruments camera systems are designed for use in the most demanding imaging applications, such as large molecule x-ray crystallography, luminescence from multiwell plates, and astronomical imaging and spectroscopy. The systems can be configured with a variety of CCD sizes and types, including large area devices of up to 4K x 4K resolution.

Options include:


- Single or multiport readout at 50 kHz rates to 5 MHz, 12 to 16 bit digitization.
- PCI computer interface with LabVIEW-based software for Windows® 95/NT, Linux drivers.
- Thermoelectric, LN₂, or cryogenic refrigerator cooling.
- UV enhancement coatings, collimated fiber optic input.

See us at Photonics West
Booth 1408



Spectral Instruments, Inc. 1802 West Grant Rd., Suite 120 • Tucson, Arizona 85745
Tel: 520-884-8821 • Fax: 520-884-8803 • Email: spectral@specinst.com
Visit our Web site: www.specinst.com

Hybrid Laser Rangefinder Receivers



- High sensitivity down to 3nW
- Optimized for pulses down to 6ns
- Choice of InGaAs PIN/APD or silicon APD detectors
- Adjustable time-programmed gain
- Miniature hybrid construction
- TE cooled versions available
- Designed to meet MIL-STD-883D requirements

The 750 Series Hybrid Laser Rangefinder Receivers are designed for military laser ranging applications in which high sensitivity and fast recovery are required. Either an InGaAs PIN or APD, or silicon APD is available to detect wavelengths from 400nm to 1.7 μ m. The 750 Series family offers receivers that operate with pulsewidths ranging from < 1ns to > 30ns.

*Call today for additional
information!*



Analog Modules, Inc.

Specialists in Analog and Laser Electronics

126 Baywood Avenue
Longwood, FL 32750-3426

Tel: (407) 339-4355

Fax: (407) 834-3806

e-mail: ami@analogmodules.com

www.analogmodules.com


Segmented-Cold-Cathode Display Panels

In comparison with CRTs, these panels could be much wider and thinner.

Goddard Space Flight Center, Greenbelt, Maryland

Display panels based largely on the principles of proximity-focused image-intensifier tubes have been proposed as alternatives to cathode-ray tubes (CRTs) and other conventional devices for wide displays. A panel of the pro-

posed type would afford the high brightness and wide viewing angle (almost 180°) of a CRT, but it could readily be made much wider than the maximum dimension [50 in. (127 cm) diagonal] of currently available CRTs. The thickness of the



This Display Panel would include a proximity-focused channel-plate image intensifier with a segmented control grid and a segmented photocathode illuminated by an electroluminescent panel.




Figure 2. Pixels Would Be Defined by intersections of photocathode and control-grid segments. The photocathode segments would be activated sequentially to turn on rows of pixels sequentially. The brightness of each pixel in a row during its "on" period would be controlled via the voltage applied to the corresponding control-grid segment.

panel [<4 in. (<10.2 cm)] would be much less than the depth of a typical CRT. Moreover, unlike a CRT, the panel would not introduce any geometric distortion into the displayed image because the image geometry would be established by a pixel structure within the panel.

Partly ignoring the two-dimensional aspect of the display for the moment, some basic physical aspects of the panel can be explained by reference to Figure 1. An electroluminescent panel on the back side would supply photons for excitation of a segmented photocathode. The photons would travel through an input window and through a transparent gate metal layer into the photocathode segment. The gate of the photocathode segment would be biased at about -20 V, relative to a channel plate, to encourage photoemission of electrons and force the emitted electrons toward the channel plate. A control grid based on the same principle as that of a control grid in a triode vacuum tube would be variably biased (probably to a potential between -10 and -30 V) to control the local brightness of the display by allowing more or fewer electrons to pass to the channel plate.

The channel plate would be about 2 cm thick, and the pores in the channel plate would be about 0.5 mm wide. The output side of the channel plate would be biased to a maximum potential of about 1 kV relative to the input side, so that the number of electrons striking the input pores of the channel plate would be multiplied to a large magnitude. The resulting cloud of electrons emerging from each pore in the channel plate would encounter an electric field that would accelerate the electrons toward a phosphor. The electric field would be provided by biasing a phosphor electrode at about 22 kV relative to the output side of the channel plate.

The phosphor electrode would be about $1,000 \text{ \AA}$ thick — thick enough to be opaque to light coming from behind but thin enough to pass electrons with kinetic energy >2 keV. Thus, the electrons would lose about 2 keV of kinetic energy traversing the phosphor electrode and would deposit the remainder of their kinetic energy in the phosphor, causing the phosphor to glow. The local intensity of the glow would depend on the bias applied to the local control grid. A multicolor display could be implemented by placing groups of red, green, and blue phosphors in registration with groups of three control grids in red/green/blue sequence. Thus, a multicolor display would contain three times the number of control grids of a monochrome display.

The two-dimensional aspect of the display can be explained by reference to

Figure 2. A pixel would be defined by an intersection between one of the vertical control-grid segments and one of the horizontal photocathode segments. The minimum pixel size would be of the order of 1 mm; although this size is too large for the desired resolution in a small display that would ordinarily be implemented in a liquid-crystal display unit, it is an appropriate size for a wide-screen television or similar display. One of the advantages of larger pixels is greater ease of fabrication.

During operation, one photocathode segment (defining a row of pixels) would be biased to promote photoemission while the other photocathode segments would

be biased to inhibit photoemission. During a frame period, rows of pixels would thus be turned on sequentially, the sequence repeating for each subsequent frame period. During the "on" period for each row, each control-grid segment would be biased to the potential needed to obtain the desired brightness in the pixel lying at the intersection of the control-grid segment and the activated photocathode segment. An alternate version of this display panel replaces the channel plate with a uniform grid mesh. This mesh is biased to the same level as the channel-plate input side. Although this version of the display will not be as bright



HITACHI

A Million Eyes For Detail

KP-F100 KP-F110

Megapixel

2/3" CCD Black & White Cameras

For an economical solution to high scan rate requirements, look to Hitachi's two new megapixel cameras. Both provide a 2/3" progressive scan CCD, analog and 10 bit digital outputs, single and two trigger inputs for frame-on-demand, and up to 1/10,000 second shuttering speed. The KP-F100 offers 1300(h) x 1030(v) effective pixels, with 12 frames per second output. The KP-F110 offers 1024(h) x 1024(v) pixels, with dual channel, 30 frames per second output.

Request Your Free Demonstration

HITACHI

Hitachi Denshi America, Ltd.

www.hdal.com

- Atlanta 770-242-3636
- Chicago 630-250-8050
- Dallas 817-488-4528
- Los Angeles 310-328-6116
- New York 516-921-7200
- Canada 416-299-5900

IntelliWave™ INTERFEROMETRY SOFTWARE

MatLab™ and IDL™ interfaces

Data acquisition

Microsoft Excel™ interface

Phase shifted analysis

Integrated quality control

Static fringe analysis

Automate repetitive tasks

Zernike & Seidel Analysis

Write your own Plug-Ins

Diffraction Analysis

Customized applications

Image processing

Use any camera or shifting device

Use your interferometer

New Product! IntelliWave Library
Now you can add interferogram
analysis to your own applications.

Download from the web.
www.engsynthesis.com
sales@engsynthesis.com

See us and a product demo at
Photonics West. Booth #1420

Free IntelliWave LE-1 Analysis for the first person or company to determine the zernike term and
number of waves used to create the frame around this advertisement. All applicable laws apply.

Copyright 1998-1999
IDL is a trademark of Research Systems, Inc.
MatLab is a trademark of Math Works, Inc.
Excel is a trademark of Microsoft, Inc.



**Engineering
Synthesis
Design, Inc.**

Tucson, AZ

Tel: 520.296.3068

Fax: 520.296.2897

For More Information Circle No. 466

Think Fast!



Introducing **Vitesse**, our most advanced camera ever. With high frame rates and high resolution it satisfies your need for speed *and* precision. And it's affordable. Think fast...and think SpectraSource. Call or visit our web site today.

See us at Photonics West
Booth #1830

- RS422/LVDS and HotLink I/Fs
- 30 fps @ 1k x 1k, 12 bit
- 12 or 16 bit A/Ds
- 32 bit DLLs
- Off shelf, custom and OEM

CCD Imaging Solutions

• Scientific • Biomedical • Commercial



31324 Via Colinas, Suite 114

Westlake Village, CA 91362

818-707-2655 / Fax: 818-707-9035

e-mail: info@spectrasource.com / www.spectrasource.com

as the channel-plate version, existing photocathode materials support current densities that will allow output light levels near that of conventional CRT's without using a channel-plate electron multiplier. Also, this alternate version is substantially easier to fabricate.

This work was done by Leslie James Payne of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-13708.

Method of Measuring Encircled Energy for Imaging Optics

Micromachined apertures are precisely, concentrically interchanged in focal planes.

*Goddard Space Flight Center,
Greenbelt, Maryland*

The radial distribution of energy within an image, called encircled energy, is a classical measure of the quality of the optical system producing that image. An improved method for measuring encircled or enclosed energy for imaging optical systems makes use of precisely micromachined apertures which are positioned with great accuracy at the center of an image.

The technique is an improved solution to the problem of measuring radiant fluxes passing through a sequence of round or square holes of progressively increasing size, all centered on the same point of interest in a focal plane of the optical system. The sequence of measurements determines the radial distribution of irradiance about the point of interest. This distribution is useful for specifying and characterizing the performance of the optical system; in particular, if the point of interest is the nominal center of the image of a bright point object, then the desired distribution is related in a known way to the point-spread function of the system.

The concept of using progressively wider apertures of identical shape to

measure the radial distribution of irradiance is so straightforward as to seem almost trivial; however, in practice, it has historically proven difficult to implement this concept with the precision needed to characterize the performances of advanced vacuum-ultraviolet and x-ray imaging instruments. The difficulty lies in being able to interchange each aperture exactly concentrically and in focus, especially with a collection of discrete apertures. Alternative methods which involve knife-edge or slit scanning are always indirect approaches to measuring encircled energy and produce somewhat ambiguous results.

The new method affords all of the necessary precision. An opaque mask containing a linear array of identically-shaped but differently-sized apertures has been fabricated by chemical micro-machining in a thin, flat silicon substrate. Also fabricated during the micro-machining process are a set of binary-coded fiducial marks — one mark for each aperture, located at a known distance well to the side of the aperture. The precision of dimensions and locations of apertures and fiducial marks are of the order of 0.1 to 0.2 μm — commensurate with the state of the art of microlithography. Aperture sizes progress slowly from 1 μm all the way up to 2 mm in both circular and square aperture shapes.

The aperture mask is mounted in front of a photodetector on a translation stage with three mutually orthogonal axes with 0.1- μm position resolution — one for motion perpendicular to the focal plane (focus) and two for motion within the focal plane.

The linear array of apertures is carefully mounted so as to be parallel to the direction of travel of one of the latter motions. The exact position of the selected aperture of interest in the focal plane is sensed by using an optoelectronic apparatus to measure the position of the associated fiducial mark: A lens focuses a magnified image of the backlit fiducial mark onto a small charge-coupled-device (CCD) image detector. The CCD output is digitized and processed to decode the binary pattern (and thereby the selected aperture) and to determine the position of the aperture to within about 0.01 μm .

In preparation for the measurement process, a photodetector wider than the focal spot of interest is positioned just behind the focal plane to intercept the focused light. The largest aperture in the aperture mask is centered approximately on the image, then moved from side to side along both image-plane axes while observing the photodetector output to find the points, corresponding to pas-

sage of the aperture edge, beyond which the light is totally blocked. The center of the image is tentatively deemed to lie halfway between the extinction points on the two axes. To locate the center of the image with progressively increasing precision, this procedure is repeated with the next smaller aperture, and so forth down to the smallest aperture. Then a final precise centering operation is performed by searching for the maximum photodetector output or other suitable indication while using the smallest aperture.

Once the center has been located, the encircled-energy measurement begins with the recording of the pho-

todetector response with the smallest aperture in place. Then the responses are recorded with successively wider apertures, using the translation stage and fiducial marks to ensure the concentricity of each successively selected aperture. The photodetector responses thus recorded constitute the desired raw encircled-energy data.


This work was done by Douglas B. Leviton and Sridhar M. Manthripragada of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category. GSC-13872

Less is more.

Laser marking systems



that go anywhere!



Less

Less maintenance
Lower costs
Small footprint
No external peripherals

More

Productivity
Peak power
Portability
User friendly

IDEAL FOR:

Material processing
Industrial marking
Awards & gift items
Photographic engraving
Medical applications



106 Laser Drive
Lafayette, CO 80026
Phone: (303) 664-9000
Fax: (303) 664-9090
www.lasermarking.net

High-Power, Wideband Laser-Diode Transmitter Module

Diffraction-limited operation affords long range.

Goddard Space Flight Center, Greenbelt, Maryland

A prototype compact, rugged optomechanical module contains a high-power, wideband laser-diode transmitter. The laser diode is of a commercial single-quantum-well AlGaAs type. Each laser diode of this type is manufactured for a specific nominal wavelength in the range from 810 to 860 nm; the one in the prototype module lases at a nominal wavelength of 824 nm. The laser diode can be operated to emit continuous-wave power of 150 mW or with amplitude modulation at average and peak powers of 150 and 300 mW, respectively. The power consumption of the entire module in dc operation is 400 mW. The laser diode is mounted on a copper plate, which conducts heat from the laser to a cold plate on which the module is mounted. The cold plate is maintained at a temperature of 15 °C.

A circuit board mounted on the copper plate next to the laser diode incorporates both dc and ac modulation electronics. Also included on the circuit board are a thermistor and a resistive heater for sensing and regulating the temperature of the laser diode. The modulation electronics include a reactive network matching circuit that enables

the use of modulation frequencies up to a 3-dB-falloff frequency of 2.5 GHz. The laser diode, circuit board, and copper plate are all epoxied to a block of low-thermal-expansion glass, providing a stable platform from which to collimate and point the laser beam.

The laser diode emits a widely diverging, diffraction-limited, single-spatial-mode beam. A glass etalon in front of the laser provides wavelength-selective feedback and thus enables single-wavelength operation even in the presence of a large modulation signal. A molded glass aspherical lens with a focal length of 2 mm and an aperture diameter of f/1 roughly collimates the diverging laser beam to a divergence of about 0.5 by 1.5 milliradians. The roughly collimated laser beam also passes through a matched pair of lenses comprising a long-focal-length positive and a long-focal-length negative lens; the distance between these two lenses is adjusted to achieve fine adjustment of the collimation of the beam. The divergence achievable with fine adjustment of the collimation is low enough to make the laser beam useful at distances of the order of kilometers.

A pair of wedge prisms is used for fine

adjustment of the pointing of the beam. A cubic beam splitter picks off a small fraction of the beam and directs it to another aspherical lens, which focuses this sample of the beam into a single-mode optical fiber for use in monitoring the modulation waveform or as a local-oscillator source for an optical receiver. To reduce the effects of optical feedback from the passive optical components into the laser, a quarter-wave plate is placed immediately after the first aspherical collimating lens, and adjusted such that the polarization of any reflected light passing through is rotated to be orthogonal with the original polarization of the laser. Because the laser has almost no gain for this orthogonal polarization, the reflected light exerts no measurable effect on the laser.

This work was done by Donald M. Cornwell, Jr., and Pamela S. Millar of Goddard Space Flight Center, Daniel X. Hopf of SSAI, and Anthony W. Yu of HSTX. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category. GSC-13824

Glendale Laser Eye Protection Protection + Visibility + Color Definition + Comfort

- Maximum Protection
- High Light Transmission for Optimum Visibility
- Excellent Color Definition
- Four Lightweight Styles Protect from All Sides
- Two Styles Fit Comfortably over Prescription Spectacles



Glendale has been a pioneer in the development of protective laser filters since 1968. Ongoing R&D keeps pace with new laser technology providing effective filters to protect against radiation from virtually all lasers.


VISIT BOOTH 1444
at Photonics West

For assistance with your laser safety program,
call 1-800-500-4739, ext. 128.

CUSTOM FILTERS
designed for
specific applications




DALLOZ SAFETY 5300 Region Court, Lakeland, FL 33815
Toll-free: 800-500-4739 / International: 941-687-7266
Fax: 941-687-0431 / e-mail: marketing@glendale-laser.com



YOUR SEARCH IS OVER!


Available for the *First* Time...
Extended Contact Bearing Linear Stages



When nothing but the best will do, these stages are the ones you need. Our patented precision extended contact ball bearing ways provide the highest possible load capacity and resist damage due to impact or wear. The linear bearing ways are machined directly into the steel plates and honed to provide the highest possible precision. The ball bearings are contacted by an extended curved surface providing greater load capacity and precision. This family of products is offered in steel stages, stainless steel stages and as a slide for OEM positioning applications.



Stainless Steel Stages



Steel Stages



OEM Slides

- Patented extended contact bearings • Thin design using only two plates • High load capacity
- Straightness of travel <2 microns • Low thermal expansion for unparalleled stability
- Industry standard 1/4-20 (M6) holes on inch (25mm) centers
- Vacuum compatible option • Micrometer driven • Lockable



For a copy of our new 1999/2000 catalog please call (949) 851-5881. *Today! not Tomorrow!*

G L O B A L M A N U F A C T U R I N G

OptoSigma Santa Ana

Sigma Koki Headquarters
Hiroaka, Japan

Sigma Koki Matto, Japan

Sigma Koki Noto, Japan

Sigma Koki Shanghai, China

 **OptoSigma**[®]
Optics • Opto-Mechanics • Motorized Products
a Sigma Koki Company

2001 DEERE AVENUE • SANTA ANA • CALIFORNIA • 92705

TEL: (949) 851-5881 • FAX: (949) 851-5058

E-MAIL: optosigm@ix.netcom.com • WEB CATALOG: <http://www.optosigma.com>

LaserMax INC.

Celebrating 10 years of
Manufacturing Excellence

DIODE LASERS



We have solutions for:

- Alignment
- Optical Data Storage
- Scanning
- Aiming
- Biomedical

We want to meet you to
discuss how we can
introduce laser solutions for
your applications at
Photonics West #1640

800-LASER-03

3495 Winton Place
Building B

Rochester, NY, USA 14623

www.lasermx-inc.com

☎ (716) 272-5420

Fax: (716) 272-5427

Software for Processing Data in Particle-Image Velocimetry

**This flexible, user-friendly program computes flow
velocities from seed-particle images.**

John H. Glenn Research Center, Cleveland, Ohio

PIVPROC is a computer program for processing data in particle-image velocimetry (PIV), which is a method of determining a flow velocity field from images of small seed particles that are entrained in the flow and that are illuminated by laser pulses at known intervals of time. PIVPROC creates an interactive computing environment for displaying and processing PIV image data. This environment includes a graphical user interface that provides user-friendly access to the image-data-processing capabilities of the program.

In PIV, a charge-coupled-device (CCD) camera records images that show the positions of the illuminated particles at two or more instants of time; then the image data are processed to extract velocities from the apparent displacements of the particles during the intervals between exposures. The processing involves one or more of three types of data-reduction techniques: autocorrelation, cross-correlation, and particle tracking. Autocorrelation is used to process double-exposure images, whereas cross-correlation and particle-tracking techniques are applied to pairs of single-exposure images.

In correlation processing, an image frame is divided into small subregions, each containing particle images. An auto- or cross-correlation operation is performed in each subregion, wherein the average displacement of the particles results in a displacement peak on a correlation plane. From the location of the displacement peak on the correlation plane and the time between laser pulses, the velocity in the subregion during that time can be computed. By thus processing the image over a regular grid of small subregions, one generates a velocity-vector map.

In particle tracking, displacements of individual particles are identified and used to compute velocities. In a combined correlation/particle-tracking operation, a correlation velocity-vector map is computed, then used as a guide for particle tracking.

The graphical work environment created by PIVPROC helps the user to perform autocorrelation, cross-correlation, and particle tracking operations on PIV image data. The raw PIV

image data can be loaded and displayed on the computer screen. The image gain and threshold level can be adjusted by use of dialog boxes. The correlation processing settings are also displayed in dialog boxes. Subregions wherein correlation processing is in progress are displayed in real time, along with the output correlation plane.

PIVPROC employs fuzzy logic for validating detections of correlation peaks and for determining correct particle pairings in particle-tracking operations; fuzzy logic enables the implementation of data-reduction algorithms that mimic or surpass the ability of a human operator to identify the correct particle pairings in the image data. PIVPROC supports the combined use of cross-correlation and particle tracking to obtain high-quality velocity data over a wide range of particle-seeding densities.

The velocity-vector maps generated by processing image data can be displayed, edited manually by use of the computer mouse, printed, and written to files. The data can also be interpolated; the program includes interpolation algorithms that enable the user to transform the spatially randomly sampled data from a particle-tracking operation onto a uniform grid of velocity vectors; the use of a uniform grid facilitates comparison of a velocity field determined by PIV with the corresponding velocity field determined by computational fluid dynamics.

PIVPROC runs in the Windows 95, Windows 98, and Windows NT operating systems. All of the data-processing and image-manipulation routines in PIVPROC are written in FORTRAN. The Microsoft Windows Application Programming Interface (API) functions are used to generate and service the interactive user environment.

This work was done by Mark P. Wernet of Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category.

LEW-16857

Telescope for Imaging and Laser Communication

Light is transmitted and received through the same objective lens.

NASA's Jet Propulsion Laboratory, Pasadena, California

Miniature, single-aperture optoelectronic instruments called "multi-function telescopes" are being developed for use in both scientific observations and laser communications aboard microspacecraft that are expected to be launched in the next few years. These instruments could also be adapted to imaging and communication applications on Earth.

As now envisioned, a multi-function telescope would serve as (1) a conventional telescope for scientific imaging, (2) a telescope for celestial navigation, (3) an infrared spectrometer, and (4) a laser communication system. A prototype multi-function telescope called "a combined laser-communication and imager for microspacecraft" (ACLAIM) has been built and tested to demonstrate two of these functions: laser communication and scientific imaging. The prototype instrument was assembled from mostly commercially available parts.

The figure schematically depicts the prototype instrument. All incoming and outgoing light passes through a telephoto mirror camera lens. Within the instrument, there are three partly overlapping optical channels: a receiving channel, a transmitting channel, and a boresight channel. The three channels intersect at a dichroic beam splitter, which makes it possible to use the same path through the telephoto lens for both receiving and transmitting.

The receiving channel extends from the telephoto lens to the beam splitter to an Active-Pixel Sensor (APS). Light to be transmitted is generated by modulating the power supplied to a laser diode equipped with a pigtail optical fiber, and the transmitting channel is considered to extend from the output end of the optical fiber to the beam splitter, then from the beam splitter out through the telephoto lens. The beam splitter exhibits high reflectance at wavelengths from 500 to 900 nm, except in a 40-nm-wide band at the laser wavelength of 670 nm, where it exhibits 70-percent transmittance.

The boresight channel includes a retroreflector, which sends a small portion of the laser beam to the APS. A laser beacon at a distant receiver is also imaged onto the APS. The positions of the spots of light from the beacon and the laser beam are measured and used to compute the angle between the transmitted beam and the line of sight to the beacon.

In the original intended use aboard a spacecraft, the spacecraft would be turned to aim the telescope at an astronomical target of scientific interest and image data would be acquired by use of the APS. The image data would be stored in memory for subsequent transmission to the distant receiver via modulation on the outgoing laser beam.

In preparation for transmitting the image data, the spacecraft and telescope would be turned to bring the beacon at the receiver within the field of view of the telescope. Then a control system would adjust the orientation of the spacecraft and of a fast-response fine-pointing mirror in the instrument, in response to the angle measured as described in the preceding paragraph. The techniques for measuring the angle and aiming the telescope were described in more detail in four previous articles in *NASA Tech Briefs*,

"Beam-Steering Subsystem for Laser Communication" (NPO-19069), Vol. 19, No. 6 (June 1995), page 32; "Digital Controller for Laser-Beam-Steering Subsystem" (NPO-19193), Vol. 19, No. 11 (November 1995), page 93; "More About Beam-Steering Subsystem for Laser Communication" (NPO-19381), Vol. 19, No. 11 (November 1995), page 93; and "Image Processing in Laser-Beam-Steering Subsystem" (NPO-19396), Vol. 20, No. 5 (May 1996), page 24.

This work was done by Hamid Hemmati and James Lesh of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Technology Reporting Office

JPL


Mail Stop 122-116

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240


Refer to NPO-20388, volume and number of this NASA Tech Briefs issue, and the page number.



This Instrument Can Be Used for both imaging and laser communication. The imaging function is also used to aim the instrument for laser communication.

NEW PRODUCTS

PRODUCT OF THE MONTH



Two Surface Topography Instruments in One

Burleigh Instruments, Fishers, NY, calls its new Gemini surface topography system the first to combine an atomic force microscope (AFM) and an optical profiler in one package. The Gemini includes Burleigh's Vista large-sample AFM and Horizon noncontact optical profiler, providing direct 3D measurements from the millimeter to the angstrom level. The Vista offers contact, AC, phase, and lateral force imaging modes with optional scanning tunneling mode. The Horizon offers the capability to measure areas as large as 2 mm square with a Z range of 100 microns, while also providing vertical resolution on the angstrom level. Thus the Gemini measures topographic features, surface roughness, friction, and compliance.

For More Information Circle No. 745



Flexible Light Pipe System

The Optoelectronics Division of Bivar Inc., Irvine, CA, introduces a flexible

light pipe (FLP) series. The new light pipes' flexible tubing, the company says, is clad in flame-retardant 94V-0 UL-rated material, and can extend to reach virtually any LED location on a PCB. The FLP series can carry the full intensity of a surface mount device or through-hole LED up to 100 feet away. Standard lengths range from 3 in. to 48 in. with custom lengths up to 100 ft. The diffusing lens of the series, offered in a variety of color selections, comes frosted clear as standard, with custom colors available.

For More Information Circle No. 747



Fiber Optic Illuminator

Stocker & Yale, Salem, NH, makes available the Mille Luce™ Model 1000 fiber optic illuminator, which it

says offers a 400-percent increase in lamp life over conventional halogen fiber optic illuminators. It provides a minimum of 1000 hours of shadow-free, glare-free, cool illumination without significant loss in light output, the company says. The Mille Luce has a quick-change positive-locking nosepiece.

For More Information Circle No. 751

ADVERTISEMENT



NEW! ULTRA-SPHEROTRONIC AUTOMATIC SPHEROMETER

Mildex Inc. introduces an ultra-spherotronic automatic spherometer for ultra-accurate radius measurement. Fast, reliable, and PC-controlled, the new Trioptics Ultra-Spherotronic automatic spherometer integrates a special linear encoder featuring the highest measurement accuracy (0.01 μm) available worldwide. Under constant temperature conditions, the absolute measurement error is less than 0.05 μm . Radius measurement accuracy of approximately 0.005 percent and repeatability of 0.001 percent are achievable. Mildex Inc., 1388 Crittenden Rd., Rochester, NY 14623-2308; (716) 473-6540; fax: (716) 475-1971; e-mail: mildex@eznet.net; home page: www.mildex.com.

Mildex Inc.

For More Information Circle No. 490



Laser Interferometer for Optics Industry

Veeco Metrology Group, Tucson, AZ, offers the Wyko™ RTI 4100 laser interferometer, which the

company says provides ultraprecise noncontact surface characterization and transmitted wavefront measurements of optical components and assemblies. Veeco calls the instrument one that provides fast, repeatable measurements with absolute accuracy better than $\lambda/200$ P-V and RMS repeatability better than $\lambda/10,000$. Measurement can be done on steep surfaces, with greater than 7 waves/mm slope at high magnification. A choice of laser sources and apertures allows the system to be tailored to specific applications.

For More Information Circle No. 748



System for "Error-Mapping" a CMM

Automated Precision Inc., Gaithersburg, MD, has designed a new laser measuring system

specifically to enable manufacturers and users to "error-map" their coordinate measuring machines (CMMs) quickly and more accurately than ever before. The API 6D HP system simultaneously maps six possible positioning errors of a CMM, recording linear measurements with a precision of 0.2 part per million. The six factors include linear displacement in the direction of motion, straightness of travel in the two axes perpendicular to the direction of motion, angular pitch motion, angular yaw motion, and the angular roll around the direction of travel.

For More Information Circle No. 752



Super-Bright Light Source

Gradient Lens, Rochester, NY, says that its new LUXCOR-24™ light source is bright enough for high-intensity applications such as video or still photography

and illuminating large and dark cavities like turbine-engine combustion chambers. The device uses a 24-W metal halide arc lamp that generates little heat, making it possible to carry the housing in a pocket. Weighing about 2 lb. 1 oz., the light source is 1.6 times brighter than a typical 150-W tungsten halogen source weighing 6 to 9 lb. Expected lamp life is as much as 500 hours. Gradient Lens says the unit is compatible with most borescopes, including its own Hawkeye® line.

For More Information Circle No. 754



Digital Laser Doppler Vibrometer

Polytec PI Inc., Auburn, MA, launches its new VDD-650-DA and VDD-660-DA

digital laser Doppler vibrometers. According to the company, these devices utilize digital signal acquisition and processing technologies to achieve exceptional displacement accuracy and resolution down to 1 picometer, high linearity, and low harmonic distortion over a very wide vibration frequency range of DC to 2 MHz. The vibrometers can be used in conjunction with almost any of Polytec's optical sensor heads. They include a signal acquisition board for PC-based processing of the Doppler signal and Vibsoft software running under Windows NT for display and processing of frequency-domain and time-domain vibration data.

For More Information Circle No. 746



Laser Displacement Sensors

The AR600™ series of line-scan-camera laser displacement sensors from Acuity

Research, Menlo Park, CA, come in 11 models with full-scale spans from 0.125 in. with an accuracy of 0.00015 in. up to a span of 50 in. with accuracy of 0.05 in. Acuity calls the devices suitable for use in measurement systems from 0.5 to 80 in. distance; they will operate at up to 1250 samples per second. Many CCD-camera-based sensors require an external control and signal conditioning box or PC card, but the AR600 does not; its sensors are self-contained and NEMA-4/IP-67 sealed for wet and dirty environments. The sensors are designed to be used in electronics, wood, metal, paper, rubber, and food production.

For More Information Circle No. 750



Deep-UV Spectrophotometer

Acton Research Corp., Acton, MA, has added the CAMS-507 deep-UV spectrophotometer to its line of

optical measurement systems. The unit is designed to provide precise reflectance, absorption, and transmission measurements in the 120-nm to >350-nm wavelength range. According to Acton, the system measures samples with unsurpassed repeatability, including CaF_2 , "dry" fused silica, deep-UV optics, thin film coatings, photoresists, and silicon wafers under vacuum or purged conditions. Available with an option for measuring samples at 157 nm or 193 nm under polarized conditions, the CAMS-507 was designed with semiconductor industry S2-93A standards in mind.

For More Information Circle No. 753



FTIR Spectroscopy Interferometer

The new interferometer from PLX Inc., Deer Park, NY, contains two mirrors and a beam-

splitter fused with top and bottom glass plates of the same material. The company says this provides a monolithic structure of uniform coefficient of thermal expansion that allows greater stability under high-temperature and vibration conditions. The assembly's single PLX hollow retroreflector separates and recombines the beams for a double-pass configuration PLX says can accommodate any wavelength. The interferometer is available in quartz or BK7 for visible and near-IR applications, or with a KBr beam-splitter for the far-IR.

For More Information Circle No. 755

Fast Fax Information Form

Fax: (413) 637-4343

Fax this form for quickest processing of your inquiry, or use the on-line LeadNet Service at www.nasatech.com.

Name: _____

Company: _____

Address: _____

City/St/Zip: _____

Phone: _____ Fax: _____

e-mail: _____

Circle the numbers below to receive more information about products and services featured in this issue.

| | | | | | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 401 | 402 | 403 | 404 | 405 | 406 | 407 | 408 | 409 | 410 | 411 | 412 | 413 | 414 | 415 | 416 | 417 | 418 | 419 | 420 |
| 421 | 422 | 423 | 424 | 425 | 426 | 427 | 428 | 429 | 430 | 431 | 432 | 433 | 434 | 435 | 436 | 437 | 438 | 439 | 440 |
| 441 | 442 | 443 | 444 | 445 | 446 | 447 | 448 | 449 | 450 | 451 | 452 | 453 | 454 | 455 | 456 | 457 | 458 | 459 | 460 |
| 461 | 462 | 463 | 464 | 465 | 466 | 467 | 468 | 469 | 470 | 471 | 472 | 473 | 474 | 475 | 476 | 477 | 478 | 479 | 480 |
| 481 | 482 | 483 | 484 | 485 | 486 | 487 | 488 | 489 | 490 | 491 | 492 | 493 | 494 | 495 | 496 | 497 | 498 | 499 | 500 |
| 501 | 502 | 503 | 504 | 505 | 506 | 507 | 508 | 509 | 510 | 511 | 512 | 513 | 514 | 515 | 516 | 517 | 518 | 519 | 520 |
| 521 | 522 | 523 | 524 | 525 | 526 | 527 | 528 | 529 | 530 | 531 | 532 | 533 | 534 | 535 | 536 | 537 | 538 | 539 | 540 |
| 541 | 542 | 543 | 544 | 545 | 546 | 547 | 548 | 549 | 550 | 551 | 552 | 553 | 554 | 555 | 556 | 557 | 558 | 559 | 560 |
| 561 | 562 | 563 | 564 | 565 | 566 | 567 | 568 | 569 | 570 | 571 | 572 | 573 | 574 | 575 | 576 | 577 | 578 | 579 | 580 |
| 581 | 582 | 583 | 584 | 585 | 586 | 587 | 588 | 589 | 590 | 591 | 592 | 593 | 594 | 595 | 596 | 597 | 598 | 599 | 600 |
| 601 | 602 | 603 | 604 | 605 | 606 | 607 | 608 | 609 | 610 | 611 | 612 | 613 | 614 | 615 | 616 | 617 | 618 | 619 | 620 |
| 621 | 622 | 623 | 624 | 625 | 626 | 627 | 628 | 629 | 630 | 631 | 632 | 633 | 634 | 635 | 636 | 637 | 638 | 639 | 640 |
| 641 | 642 | 643 | 644 | 645 | 646 | 647 | 648 | 649 | 650 | 651 | 652 | 653 | 654 | 655 | 656 | 657 | 658 | 659 | 660 |
| 661 | 662 | 663 | 664 | 665 | 666 | 667 | 668 | 669 | 670 | 671 | 672 | 673 | 674 | 675 | 676 | 677 | 678 | 679 | 680 |
| 681 | 682 | 683 | 684 | 685 | 686 | 687 | 688 | 689 | 690 | 691 | 692 | 693 | 694 | 695 | 696 | 697 | 698 | 699 | 700 |
| 701 | 702 | 703 | 704 | 705 | 706 | 707 | 708 | 709 | 710 | 711 | 712 | 713 | 714 | 715 | 716 | 717 | 718 | 719 | 720 |
| 721 | 722 | 723 | 724 | 725 | 726 | 727 | 728 | 729 | 730 | 731 | 732 | 733 | 734 | 735 | 736 | 737 | 738 | 739 | 740 |
| 741 | 742 | 743 | 744 | 745 | 746 | 747 | 748 | 749 | 750 | 751 | 752 | 753 | 754 | 755 | 756 | 757 | 758 | 759 | 760 |
| 761 | 762 | 763 | 764 | 765 | 766 | 767 | 768 | 769 | 770 | 771 | 772 | 773 | 774 | 775 | 776 | 777 | 778 | 779 | 780 |
| 781 | 782 | 783 | 784 | 785 | 786 | 787 | 788 | 789 | 790 | 791 | 792 | 793 | 794 | 795 | 796 | 797 | 798 | 799 | 800 |
| 801 | 802 | 803 | 804 | 805 | 806 | 807 | 808 | 809 | 810 | 811 | 812 | 813 | 814 | 815 | 816 | 817 | 818 | 819 | 820 |
| 821 | 822 | 823 | 824 | 825 | 826 | 827 | 828 | 829 | 830 | 831 | 832 | 833 | 834 | 835 | 836 | 837 | 838 | 839 | 840 |

WIN A FREE SUBSCRIPTION...

to a new e-mail newsletter from *NASA Tech Briefs*, featuring exclusive technology and business news as well as previews of upcoming issues. To qualify, simply complete the survey below and fax this page to (413) 637-4343. Your response will be kept completely confidential and will be used for statistical purposes only. This survey is optional and not required to order product information above.

1a. Are you involved in advising, recommending, specifying, or approving the purchase of computer-aided design (CAD) software for your company? ☐ Yes ☐ No

1b. If yes, do you plan to increase your purchase of CAD software in the next 12 months? ☐ Yes ☐ No

2. Which of the following types of CAD software do you now use? (check one) ☐ 2D ☐ 3D ☐ Both

3. Please list the names of CAD packages you (or your department) currently use.

4. Please list any additional CAD packages you are considering purchasing in the next 12 months.

☐ Check here to receive your free subscription to the new *NASA Tech Briefs* e-mail newsletter. (Please be sure to fill in your e-mail address at the top of this page.)



Highlights from the annual national technology transfer conference and exposition

Tech East '99 brought together three events — Technology 2009, the Engineering Innovation Show; Southeast Design & Manufacturing Expo; and the Small Business Tech Expo — at Miami's Fontainebleau Hilton in November. Sponsored by NASA, NASA Tech Briefs, the Federal Laboratory Consortium, and Hewlett-Packard, the shows drew design and manufacturing engineers and entrepreneurs looking for the latest technologies and products.

A featured event at Tech East was the first NASA Business Forum, which focused on emerging commercial opportunities in aerospace and aviation. Sessions covered how to do business with NASA, spaceports and spaceliners, medical benefits from the space program, and new initiatives in general aviation.

General Spence M. Armstrong, NASA Associate Administrator for Aero-Space Technology, opened the forum with "How to Do Business With NASA," an introduction to key NASA enterprises, including contacts, programs, and resources available to commercial industry. General Armstrong spoke about those partnership opportunities, and presented his views on the technology transfer process.

"The Aero-Space Technology Enterprise is unlike the other NASA enterprises. We're never finished. We're always looking for someone to finish the job. I sometimes say that our goals are like the tape at the end of a long relay race. It's not run against the competition, but against time. We never run the anchor leg. That's technology handoff. We want somebody who will take our technology and run with it, and cross the finish line," the General said.

General Armstrong explained that NASA has a mandate that "uses the taxpayers' money, so we should give them the maximum benefit for their money. We're not in the business to provide technology to the public. We're in the business to carry out our mandate of the Space Act — to make the technologies useful to the public," he said.

The session also included presentations from Dr. Robert Norwood, Director of Commercial Technology for NASA, who discussed the Commercial Technology Network. Vernotto McMillan, Deputy Director of the Technology Transfer Department at NASA's Marshall Space Flight Center explained the tech transfer process at his center. Finally, Lamont Hames, Small and Disadvantaged Business Specialist at NASA Headquarters, discussed opportunities for minority- and women-owned small businesses.



General Spence Armstrong (left) and Lamont Hames of NASA were panelists in a forum session for companies looking to do business with NASA.

Just What the Doctor Ordered

The potential of space technology to improve the quality of life on Earth is most dramatically demonstrated in the area of healthcare and innovative medical treatment. Helen Stinson, program manager of NASA Marshall's Small Business Innovation Research (SBIR)/Small Business Technology Transfer (STTR) program, was the moderator for a NASA Business Forum session devoted to medical advances. Topics included innovations in obstetrics, cancer surgery, and wound healing; a "bionic" eye; telemedicine in extreme environments; microgravity's impact on nutraceuticals; and biotechnology and drug discovery.

Daniel L. Wakefield, senior engineer at the Research Triangle Institute in North Carolina, led off with an overview of success stories and partnership opportunities in medical innovations. "The US commands a healthy market share in the medical device industry," he said. "But new products are critical to success. If we don't have new products coming out every year, we will start losing market share."



SBIR Technology of the Year Award nominee Genex Technologies displays their 3D imaging techniques to Tech East '99 attendees.

We don't think you should have to choose between getting it fast

At Spectrum Astro, we know that shortened schedules are the key to lower costs. That's why every spacecraft we build is designed for extreme producibility and fast production. From the smallest piece part to the most complex subsystems, our technical designs facilitate fast installation, removal, replacement and upgrade at any point in the factory production flow.



Or getting it right

In fact, we've implemented dozens of streamlined manufacturing processes in virtually every area of operation throughout the company. At the same time, we continue to emphasize quality without compromise. Because we've never lost sight of the single most important practice that enables Spectrum Astro to consistently deliver products faster and at lower cost than our competitors: Getting it right the first time.



Arizona

California

Colorado

Virginia

Contact Howard Parks, Director, Program Development
1440 N. Fiesta Blvd. • Gilbert, AZ 85233 • Phone 480.892.8200 • FAX 480.892.2949

www.spectrumastro.com

AFFORDABILITY THROUGH INNOVATION

For More Information Circle No. 555

SPECTRUMASTRO



Wakefield cited several recent examples of NASA technologies that have been transferred to the medical device industry. These have led to the development of a non-invasive, intracranial pressure monitor for closed head injuries; vision-enhancement device; digital mammography; and an ultrasonic periodontal probe.

Obstetrical forceps are undergoing a 21st-century makeover, thanks to fiber-optic sensors developed for the X-33 reusable launch vehicle. "Since the 1930s, the forceps have not been innovated," according to Dr. Jason Collins of the Pregnancy Institute in New Orleans. "In terms of delivering babies, what we don't know is the force being used to deliver that baby — that's a critical issue."

Using conventional forceps during delivery increases the risk of brain damage and other serious injuries to the infant. Dr. Collins is participating in the development of "smart forceps" in which embedded fiber-optic sensors will enable the doctor to monitor the amount of force being applied throughout the delivery. Developing the new forceps involves finding a composite material equal in strength to steel, formulating an embeddable sensor, transforming force to a recordable pattern, accumulating case histories, and devising a 3D simulator/trainer.

Dr. Harry Whelan, a pediatric neurologist at the Medical College of Wisconsin, presented an LED probe that has been used in surgery to treat otherwise inoperable brain cancer. Quantum Devices originally developed the LED technology for plant-growth research on the Space Shuttle. The probe consists of 144 pinpoint LEDs that are used to activate a light-sensitive, tumor-destroying drug in a technique known as photodynamic therapy.

The potential exists to use photodynamic therapy to treat other forms of cancer, such as melanoma and other skin cancers. "Anywhere you can easily place the light probe is a possibility," said Dr. Whelan.



1999 SBIR Technology of the Year Award winners: (front row l-r) Kang Lee, Aspen Systems; Zafar Munshi, Lithium Power Technologies; Stephanie Vierkotter, Quantum Magnetics; Ian Ferguson, Emcore; and Dan Berger, Irvine Sensors. (Back row): Chief Editor Linda Bell and Publisher Joe Pramberger (far right) of *NASA Tech Briefs* with members of the Quantum Magnetics team.

Small Business Wins Big

Tech East '99 hosted the presentation of the annual SBIR Technology of the Year Awards, which recognize companies that have developed important new commercial products and services through the federal government's Small Business Innovation Research (SBIR) program. The program is the country's largest source of early-stage, high-risk technology financing, with some 5,000 grants totaling \$1.2 billion awarded annually by ten federal agencies.

Winners were chosen in four categories, and a Grand Winner was selected as the best new technology. Emcore Corp. of Somerset, NJ, won the Computers and Electronics category with their indium-gallium-nitride-based material for bright, blue, light-emitting diodes (LEDs). The company received funding from the Ballistic Missile Defense Organization (BMDO) to commercialize the technology, which is in great demand for automobile tail lights and traffic lights.

The Manufacturing and Materials category winner was Aspen Systems of Marlborough, MA. The company developed an improved drying method for aerogels, the silica materials with densities as low as three times that of air. Widespread use of aerogel-based insulation would significantly reduce energy consumption and emissions.

The winner in the Sensors and Instrumentation category was Irvine Sensors of Costa Mesa, CA, for a 3D chip-stacking process in a neural network. The network emulates the human eye-brain interconnection, and has potential applications in medical diagnostics and security screening.

BMDO also funded the winner in the Health, Energy & Environment category. Lithium Power Technologies of Manvel, TX, created film hybrid dielectric capacitor materials based on polymer blends capable of high energy densities and able to be manufactured at a cost of about half that of existing film capacitors.

The Grand Winner was Quantum Magnetics of San Diego, CA, for their sensor that detects the explosive charge inside a buried land mine. The life-saving device employs quadrupole resonance (QR), a spectroscopic technique that involves illuminating a mine with radio frequency (RF) waves and measuring the RF response. The waves' frequency is chosen from a set of resonance frequencies unique to each explosive used in land mines.



New "Horizons"

A capacity audience attended "Tapping Into the Federal Laboratory Network to Improve Your Bottom Line," a session that featured information on partnership and commercialization opportunities with the Department of Defense and other major federal agencies. One of those agencies, the Air Force Research Laboratory (AFRL), announced during the session their partnership with ABPI, publisher of *NASA Tech Briefs*, to produce a new magazine for the US Air Force called *Air Force Technology Horizons*. The magazine, scheduled to debut in March, will report on new technologies available for commercialization from the AFRL. For more information on AFRL, visit the web site at www.afrl.af.mil; for more information on *Air Force Technology Horizons*, see next month's issue of *NASA Tech Briefs*.

PRECISION MACHINING

COMPLEX MULTI-FACETED PARTS
THE WAY YOU WANT THEM

... EXACT TO PRINT.



RIGID ADHERENCE TO SPECIFICATIONS
TOLERANCES TO ± 0.000040 "

PROTOTYPE TO PRODUCTION ...
VERY SMALL TO LARGE PARTS
EXTENSIVE EXPERIENCE WITH
HIGH STRENGTH ALLOYS & TITANIUM

STATE-OF-THE-ART EQUIPMENT
8-AXIS SWISS, 5-AXIS MACHINING CENTERS,
LARGE TURNING WITH C&Y AXIS, FULL C-AXIS CNC GRINDING

MIL-I-45208A, GMP, ISO 9002 & ISO-10012-1
GOVERN MANUFACTURING SYSTEMS, PROCEDURES &
QUALITY CONTROL TO THE LEVEL OF ZERO DEFECT

OVER 90 YEARS OF EXPERIENCE AND EXCELLENCE
MANUFACTURING IN A MODERN 50,000 SQ FT FACILITY

FAST QUOTE ON YOUR PRINTS & SPECS ...

E-MAIL lpi@lavezzi.com OR FAX 630-582-1238

RELY ON ACCURATE ESTIMATES & ASSISTANCE WITH
INNOVATIVE ENGINEERING SERVICES &
PRECISION MANUFACTURING

QUALITY SYSTEM
REGISTERED TO
ISO 9002:1994



LAVEZZI

QUALITY ... ABOVE ALL ELSE.

LaVezzi Precision, Inc. ■ 999 Regency Drive ■ Glendale Heights, IL 60139-2281
630-582-1230 ■ Fax: 630-582-1238 ■ E-mail: lpi@lavezzi.com ■ 800-323-1772

For More Information Circle No. 513

Beyond the Basics: Mathcad 2000

Steven S. Ross

The basics of Mathcad are fairly well known among techno-citizens: Copy an equation out of a textbook onto a Mathcad screen, and the math goes live. You can solve for any variable without bothering to transpose the equation. The unknown is on one side and all other vari-

ables and constants are on the other — the same as what you would do with a programming language such as C or BASIC. Mathcad can handle, among other things, basic linear equations with as many as 50 variables. This capability has been around since the early 1980s, when TKSolver was first developed.


Mathcad 2000 comes in three versions: Premium (\$999.95), Professional (\$499.95), and the blowout-priced Standard (\$99.95). The Standard version has everything that most people need at school or at home. Professional adds some advanced functions and a "lite" edition of Axum for graphs. Premium adds the full version of Axum, an "expert solver" (adapted from the solving and optimization add-on in Version 8) that allows mixed-integer programming, and the "treasury," a powerful reference tool.

All three versions include more statistical curve-fitting functions for exponentials, logs, power, periodical (mainly sinusoidal), and logistical data than in Version 8. While it is true that you could build these functions as you need them using Mathcad's own on-screen tools, having them built in allows faster execution and less chance for error.

More revolutionary is that all of the new versions now do equations with Boolean operations (AND, OR, NOT, XOR). The Professional and Premium versions include a new, powerful differential equation solver. The odesolve function is especially slick. It solves any single ordinary differential equation subject to either an initial value or boundary value. The equation must be linear in its highest-order derivative term. Also noteworthy in Version 2000 are great 3D graphics and (in Pro or Premium, with the Axum add-on) 2D plotting improvements. There's a link with SmartSketch (full version in Premium, LE in the other versions), the program from Intergraph that formerly was called Imagineer. It allows you to make computations based on values in your sketched drawings, and to import files from AutoCAD and other CAD packages so you can use the drawing dimensions as data. Finally, there is a new

error-tracing tool and better equation and document formatting.

Using the basic functions of Mathcad does not require much orientation. You start on an almost blank screen and specify a region. As you start to type an equation, Mathcad always seems able to decide whether you are typing math or text. As you need special symbols and functions, you can pick them up from various toolbars scattered around the interface — one for calculus, one for matrices, one for standard math, one for Booleans, and so forth.




Simple contour plot.

ables and constants are on the other — the same as what you would do with a programming language such as C or BASIC. Mathcad can handle, among other things, basic linear equations with as many as 50 variables. This capability has been around since the early 1980s, when TKSolver was first developed.

Mathcad (from MathSoft, Cambridge, MA; www.mathsoft.com) did TKSolver one better by adding a simple text processor, so you can handle engineering reports — words, equations, and graphs — with one package. Mathcad now also has automatic support for unit conversion. Combine calories and BTUs, and you get a combined answer that makes sense. I find this particularly magical because I wrote the original units-conversion add-on package for TKSolver back in 1983.

But Mathcad these days goes far beyond the basics. I had not looked at it in depth for about four years. I should have. And so should you.

There's much more interactivity with other software. Mathcad 2000 is both an OLE2 (COM) server and client, so its functional equations can be plugged into a Word document, and data from another program can be plugged into Mathcad. The new version is particularly



Start of a formatted analytical report. In this case, on the odds and payouts for the New Jersey Pick 6 Lottery.

If you do need help, you'll probably find it. The help system is quite good. It does require that you install Internet Explorer 4.0 or higher. Mathcad requires a Windows 95/98/NT Pentium computer with 32 to 64 MB of RAM. Complete installation of the Professional version takes about 130 MB of disk space.

Steven S. Ross is an associate professor at Columbia University in New York City. He has authored three commercial software packages, including a units conversion program and an engineering calculations program.



Commercialization Opportunities

Composite-Material Heat Sink for Printed-Circuit Boards

A lightweight heat sink and mechanical support has been developed for printed-circuit boards. The heat sink weighs 43 percent less than an aluminum heat sink does. (See page 40.)

Reducing Methanol Crossover in CH_3OH -Fuel-Cell Membranes

Improved membranes can be made by impregnating the baseline membrane material with cross-linked polystyrene. The principal benefit is a reduction in permeability by methanol, which otherwise wastes fuel and degrades fuel-cell performance. (See page 41.)

Inflatable Wing Leading Edges for High Lift and Deicing

Preliminary results demonstrate the feasibility of using inflatable boots on the leading edges of airplane wings to increase lift and to act as deicing actuators. (See page 42.)

Improved Urine Preservative

A new solution eliminates the need to refrigerate urine samples and does not alter the pH values of the samples. (See page 46.)

Noninvasive Determination of Pressure in Cerebrospinal Fluid

The proposed technique could make it unnecessary to perform spinal taps. This noninvasive technique involves tomographic scanning and digital processing of the image of the inside of the eye to determine the cerebrospinal fluid pressure. (See page 47.)

Primers for Amplifying CMV DNA in Body Fluids and Tissue

A set of primers has been developed for faster, more sensitive detection of cytomegalovirus (CMV). CMV annually infects about 40,000 infants in the U.S. alone and is the leading infectious cause of mental retardation and nonhereditary sensorineural deafness. (See page 48.)

High-Temperature Pressure Sensors Made From Silicon Carbide


These are prototype sensors for use at high temperatures in engines, power plants, material-processing systems, and numerous other applications. Their working temperatures range up to 500 °C. (See page 57.)

Nonintrusive Flow-Measurement System

Flow is measured ultrasonically from outside the pipe. This design eliminates a number of potential mechanical failures that can happen in conventional flowmeters and eliminates the risks of leakage, clogging, and corrosion. (See page 57.)

Piezoelectric Igniter/Pressure-Sensor Devices

These devices would supplant conventional spark plugs in internal-combustion engines. Unlike conventional spark plugs, these devices would work without need for wire connections to high-voltage sources and without external timing circuitry. (See page 58.)



In Any Condition

Are harsh **environmental realities** causing a high degree of anxiety for your design team? NuSil Technology produces Thermally and Electrically Conductive Silicone Materials that meet and exceed the industry's strictest specifications. So no matter how challenging the environment, structural integrity and flexibility are always intact.

As a recognized leader in the engineering materials industry, NuSil develops and manufactures advanced silicone products for a wide variety of applications. If you have a need for polymers that always conduct themselves properly, get attached to NuSil. For more information, contact us today.

NuSil Technology
1050 Cindy Lane
Carpinteria, CA 93013, U.S.A.
(805) 684-8780
Fax (805) 566-9905
www.nusil.com

NuSil Technology — Europe
Atlantic Parc - Les Pyramides No.5
P.A. de Maignon 64600 Anglet
FRANCE
+33 (0)5 59 31 41 04
Fax +33 (0)5 59 31 41 05




SILICONE
TECHNOLOGY
ISO 9001 Certified

Application Briefs

NASA Uses Radiance Infrared Camera for Component Evaluation

Radiance infrared camera
Raytheon Infrared
Raytheon Systems Co.
Dallas, TX
800-990-3275
www.raytheon.com/ir

NASA's Marshall Space Flight Center (MSFC), Huntsville, AL, is testing Raytheon's Radiance infrared camera to devise nondestructive evaluation (NDE) methods for assessing Space Shuttle and other aerospace components. MSFC researchers are combining thermography, ultrasound, and radiography technologies in various ways to develop these NDE techniques, which will be used to identify structural anomalies in components. Researchers are using the Radiance for the thermography component because the camera's 256-x-256-pixel InSb staring focal-plane array generates high-resolution images and is highly sensitive to slight temperature changes.



The infrared camera is used to image the Space Shuttle nose cap.

With the Radiance, MSFC has conducted nondestructive evaluations of various Space Shuttle components, including a prototype nose cap for the shuttle's Reusable Solid Rocket Boosters. Six feet high and four feet wide at its base, the nose

cap consists of a foam core sandwiched by inner and outer graphite-epoxy skins.

Sam Russell, Ph.D., an NDE specialist at NASA Marshall, said thermography is useful for identifying anomalies, such as delaminations, in composite material. Proper functioning of the nose cap requires that the core and inner and outer skins be perfectly bonded throughout the cap structure. Delaminations and other anomalies can occur during composite manufacturing or be caused by something such as an object striking the outer skin.

According to Russell, the Radiance camera's 0.025C° sensitivity enables the camera to detect slight subsurface anomalies. "This high sensitivity is critical to us. Even the most subtle anomalies, such as minute delaminations, can cause problems, and we must be able to detect them,"

Russell said. He emphasized that MSFC's testing of various NDE methods is ongoing. Most likely, any final NDE procedures will combine, in some manner, thermography, ultrasound, and radiography.

For More Information Circle No. 742

Anchor Pins Selected for Space Station Crew Return Vehicle Testing

Force test hardware
Strainsert
West Conshohocken, PA
610-825-3310
www.strainsert.com

NASA's X-38 technology demonstrator is an emergency Crew Return Vehicle (CRV), or lifeboat, for the International Space Station. The design uses a lifting body concept, that upon jettison of a de-orbit engine module, the X-38 will glide from orbit, unpowered, like the Space Shuttle. It will use a steerable, parafoil parachute, and will touch down on landing gear consisting of three skids, rather than wheels.

Strainsert designed and developed three instrumented clevis pins to measure the unknown forces exerted on the vehicle's landing skid joints. The force data will be used to evaluate and verify the skid design loads and distribution. The pins were custom-designed for integration into the port, starboard, and forward pin joints of the landing skids. Requirements for each pin included a high measurement load combined with impact loading, a wide temperature range over which data must be acquired, and little or no modification to existing hardware.

To meet the requirements, the pins consist of cylindrical pins, instrumented with strain gages to sense shear strain in direct response to the applied load. The strain gages were internally installed and bonded in small holes along the neutral axis at the sensing sections of the pin, with the orientation aligned in accordance with the direction of the applied load to be measured. The pins are made of steel alloy with nickel plating, and are capable of withstanding over 40,000 pounds of applied double shear load for a 1" pin diameter.

The pins were used successfully during landing tests. Future tests using the pins are scheduled for this spring. Later this year, the unpiloted test vehicle is planned to be deployed from a Space Shuttle and descended to a landing.

For More Information Circle No. 743



The X-38 shown during a test landing at NASA's Dryden Flight Research Center. (Photo by Bill Isbell)

We Did It!

That's right: we've taken portable data acquisition to a whole new level. The DEWE-3010 and DEWE-2010 completely redefine what a data acquisition system should be. Not just portable and rugged, but also open-architecture, so you can upgrade the hardware and software long into the future. With modular signal conditioners you can mix and match to create your own system with dozens of fast channels and up to 2048 slow/temperature channels!




Plug-in DEWE-MODULES



DEWE-RACK-16 and any PC



DEWE-3010 Ultra-portable complete system



- MIL-STD-810 Shock/Vib*
- Includes DEWEScope+ Software
- Plug-in DEWE-MODULES
- Front-ends for any A/D card
- Complete stand-alone systems

Our DEWEScope+® software makes setup and recording easier than ever. Want to use DASyLab® or LabVIEW®? No problem - our open-architecture platform runs them all (and more) without a hitch. Trigger and capture effortlessly to disk at rates up to 1.25 MHz. With plug-in modules for direct connection of every sensor - DC and AC strain gages, charge and ICP® accelerometers, microvolts to kilovolts, RTDs and thermocouples (9 types), LVDTs, string pots, RPM and TACH signals from engines and turbines, and more.

With 1000V isolation, exceptionally low noise, and multiple range/filter selections in each plug-in module Dewetron builds rack-mounted and portable systems for a wide variety of applications in the automotive, aerospace, industrial, process control, research, chemical, medical research, and other industries. Find out what so many others have already discovered—for a no-obligation demo, please contact us today at 1-401-782-3866, visit our website, or send an email to: justdewit@dewamerica.com



Dewetron, Inc.
18 South Glen Court
Wakefield, RI 02879-7690
Tel: 1-401-782-3866
www.dewamerica.com

AMERICA • AUSTRIA • BELGIUM • GERMANY • NETHERLANDS • SLOVENIA • THE CZECH REPUBLIC • THE U.K.

All trademarks acknowledged as the properties of their owners. * Certain CDROM drives do not meet MIL-STD specifications

For More Information Circle No. 533

Technology Forecast


This month's technology forecast for the data acquisition industry is contributed by Tom DeSantis, President of IOtech, Cleveland, OH. Tom discusses why the time is right for synchronous measurement on low-cost PC plug-in boards.

Advancements in personal computer technology continue to push the world of data acquisition to new capabilities. Many of the analog measurements that were once made with digital multimeters, dataloggers, and chart recorders are now made with PC plug-in data acquisition boards. In addition to measuring analog signals, these boards also have the ability to acquire digital, counter, and frequency input signals, and to output analog and digital signals.

Historically, plug-in boards have done an excellent job of providing time-synchronized analog measurements, where the time relationship between each measurement — even on multiple channels — was precise and predictable. This is particularly important when waveform measurements are made, since the time relationship between multiple channels is almost always necessary to accurately correlate the acquired data.

Take an example where an analog-to-digital (A/D) board uses a 100K-kHz A/D converter, and two channels are to be measured at exactly 10 kHz per channel. Nearly all of today's boards are capable of measuring first one and then the other of the two channels at precisely 50 kHz per channel, with a mere 10-sec (1/100-kHz) time skew between them. Since the time relationship between the sampling of each channel is precise and deterministic, the acquired waveforms can be analyzed relative to one another with precision.

The problem with most of today's A/D boards is that most or all of their other I/O capabilities cannot be time-correlated to the analog measurements, or to each other, making it nearly impossible to correlate analog measurements to digital, counter, or frequency measurements. Consider a test example in which a board would be used to test a rotating motor in a piece of machinery. It may be desirable to measure various supply voltages and currents to the motor, the motor's RPM, the status of control switches, temperature, and perhaps other parameters. Thus, not only is it necessary to acquire analog data, but digital input data and counter/



Tom DeSantis, President, IOtech

frequency data as well. In addition, it may be desirable to output an analog waveform from the board's D/A converters to create a dynamic load to the motor, or to output a control signal from the board to apply an impulse load to the motor.

Nearly every A/D board available today would have difficulty performing this test, because the analog output, digital I/O, and counter/frequency input are updated or measured asynchronously to the analog input scanning, making it nearly impossible to time-correlate the various I/O functions. The reason is that, while most boards operate their A/D converters and multiplexers from precise, clock-driven electronics, the other I/O usually is controlled via software in the PC. In addition, since all PCs operate at different speeds, the rate at which they can access the hardware is highly dependent on what other tasks are being performed at the time. The timing of the other I/O is almost entirely non-deterministic.

Notable exceptions are some higher-end boards with on-board intelligence, which have their own processors that are dedicated exclusively to managing the I/O functions. These boards typically are two to ten times more expensive than the typical multifunction A/D boards, and often require the use of a unique programming environment in order to accomplish the time-correlated multifunction I/O.

New Technologies Drive the Future

Now that PCs are faster than ever before, and with the advent of the PCI bus as the backbone for all new PCs, the future is bright for using low-cost plug-in boards to accomplish time-critical, multifunction I/O. Besides the cost advantage over processor-based plug-in boards, using low-cost, non-processor boards for multifunction I/O means that they can be programmed with popular and low-cost standard languages such as C++ and Visual Basic.

Two technology advancements are making the use of low-cost plug-in boards for time-critical multifunction I/O possible. First, the PCI bus, now ubiquitous on today's PCs, has the bandwidth necessary to acquire data from multiple sources on a single, low-cost plug-in board, as well as to generate multiple channels of output to the same plug-in board. The 15-year-old ISA bus, which has only recently been replaced by PCI, simply couldn't deliver this bandwidth.

The second advancement is the way in which multifunction A/D boards are designed. In the past, standard digital I/O devices, such as the 8255 chip, were used for digital I/O on nearly all boards. And the 9513 device was used to provide the counter/timer capability on most boards.

For less than \$500, these new boards are capable of synchronously measuring analog inputs, generating analog outputs, acquiring digital inputs, controlling digital outputs, measuring counter inputs, and generating digital patterns — all in synchronicity with one another. Although most multifunction boards have yet to offer this capability, it's only a matter of time before these capabilities are considered standard features for low-cost plug-in boards.

For more information, contact IOtech at 25971 Cannon Rd., Cleveland, OH 44146; Tel: 888-805-3020; Fax: 440-439-4093; www.iotech.com.



Yes, there's a difference between a PC plug-in and our data acquisition system. But it's not the price.

20 channels for \$1,685*

Agilent 34970A

- 22 bit resolution (6 1/2 digits)
- 11 built-in measurement functions
- 50,000 readings of non-volatile memory
- Scanning up to 250 channels per second



Modular flexibility

Fundamentally, yes, they both collect data. The similarities end there. Meet the Agilent 34970A data acquisition system. Full performance you can afford for about the price of a PC plug-in system. How does dcV accuracy as good as .0035% sound? Plus built-in circuitry to measure 11 different functions without paying more for external signal conditioning. And BenchLink Data Logger software free with every unit.

The 34970A truly gives you everything you need for low-speed data logging and characterization. A front panel that's easy to use. Standard GPIB and RS-232 interfaces. Still not convinced? Try the 34970A for yourself with our easy demo program. Or download the free BenchLink software from our web site. And of course, you can always call and talk to another engineer, too. With Agilent's online purchasing and a price this affordable, it's a simple decision. And that's a difference everyone will like.

www.agilent.com/find/bi

1-800-452-4844; Ext. 6873



Agilent Technologies

Innovating the HP Way

*U.S. list price.

**In Canada, call 1-877-894-4414, Ext. 6873. ©2000 Agilent Technologies ADGPP002/NTB



Special Coverage: Data Acquisition

Post-Processing Satellite Image Data in Secondary Schools

Direct experience helps prepare children for participation in an increasingly technological world.

Goddard Space Flight Center, Greenbelt, Maryland

Never before have secondary schools been able to post-process raw satellite data, and now they can do it in real time. This is credited to advances in technology that have recently made the necessary equipment simple, inexpensive, powerful, and available enough for any school to fit into their technology-education curricula. This equipment couples ideally with the emerging utilization of the Internet in secondary schools.

Such precursors to the Internet as the direct satellite broadcasts called Advanced Picture Transmissions (APT) and Weather Facsimile (WeFax), were placed in schools over the past 15 years but never integrated into the curriculum. They provided Graphic Image Files (GIFs), i.e., snapshots of scenes taken by satellites of the Earth below, by polar orbiting (NOAA) and geosynchronous (GOES) satellites, respectively. The operators of the satellites would produce these products on the ground and then uplink them to the same satellites for rebroadcast to the public. Users had no control over what images would be received nor could they enhance them to any notable extent. Recently, the Internet has supplanted this pathfinding service, by enabling the user to request such "canned" images on demand. Yet, due to the enormous amount of data in a single raw image (up to 385 MB), any attempt to access the raw data over the Internet must be severely constrained. Even high-speed connectivity is bogged down by the number of users all too quickly to use the Internet, for accessing anything larger than snapshots. This inherently limits the utility of the Internet services alone.

Now, innovations sponsored by GSFC have enabled us to bring raw, highest resolution, real-time data from the NOAA and GOES satellites to the secondary schools nationwide without compromise, at a price and complexity that they all can afford.

This has required advancements in antenna design, a PC-based ingest and image processing system, and a curriculum that meets core learning goals and will be used by the teachers.

Standing Acoustical Wave (SAW) technology was applied to the low noise amplifier inside the antenna feed to better isolate the satellite downlink frequency and remove more of the background noise. This signal is then down-converted inside that feed to a lower frequency, before more noise can be picked up. The lower frequency preserves the signal-to-noise ratio along 300-ft (91-m) of inexpensive coaxial cable. A standard 10-ft (3-m) antenna, used by homeowners for satellite TV, was adapted with this new feed, keeping the antenna costs to a minimum. Next, the expensive (\$30k) radio receiver normally employed for access to multiple satellites was replaced by a tailored version on a PC board that can sell for under one thousand dollars. Likewise, the related external components were all designed onto PC boards, so that now the antenna feed plugs right into your PC, with no external components.

The software was rewritten to work on personal computers, which guarantees that the system will get faster, better, and cheaper every few months. At this writing, the entire system costs between \$5.5k and \$8.5k depending on the sophistication of the server computer and economy of scale for software licensing. Compare this to almost \$200k for the first systems that NASA used to handle these functions.

The use of these new tools in secondary schools was introduced in 1996 when they still cost \$25k. At that time, GSFC augmented the costs for two schools in Maryland and Pennsylvania, and they agreed to use the systems in technology-education programs.


Curricula were developed jointly over the next two years as the tech-

nologies and the application software improved and the price came down. Currently, schools in six states, including the Pine Ridge Indian Reservation in South Dakota, are using these systems for academic credit. Students can use their Internet service to get ground truth images of wildfires, ocean currents, rain, snowfall, and the like. They can then locate the same time and place in their large data base of the raw satellite data, and custom enhance their images to match the ground truth. Having developed a suitable algorithm for rainfall where there is Doppler data and bucket measurements, they can now apply that algorithm to anywhere in the Western Hemisphere. Furthermore, using the continuous data from the geostationary satellites (GOES) they can apply their algorithms to the same scene every half hour or so and put it in motion. Now they can watch the rain/snow in motion or the wildfires move as they burn. Using emerging information technologies, they can e-mail their customized film loops to other schools nationwide or beyond. The learning potential is enormous. They learn marketable technology skills in the areas of electronic access of information, post-processing of raw satellite image data, multimedia production, and both electronic and verbal communication skills, while doing really cool science projects. This critical part of the overall program has been a product of cooperation between the educators and NASA, as is essential if it is to be used for academic credits on a nationwide scale.


This work was done by Michael Comberiate of Goddard Space Flight Center, George Isleib of GTI Electronics, and Shawn Terry of Aquila Systems. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category, or access the website: <http://coolSPACE.gsfc.nasa.gov/GSC-14038>

1 Engineer
1 Idea
1165 Parts
20 Days...

Geometry generated using Parasolid® and instantly, natively usable by either Parasolid or ACIS®-based applications.



Geometry generated using ACIS and instantly, natively usable by either Parasolid or ACIS-based applications.



*Model courtesy
of Simon Floyd
Design Group*

... And Now, the Power of Dual Kernels

Users have been amazed at the power and speed of IronCAD®. Now their ideas can leap organizational and CAD system barriers in a single bound. IronCAD is the world's first and only system to seamlessly and simultaneously utilize both the leading solid modeling kernels. It's like having two experts combining strengths—providing extra power for tough modeling problems and greater freedom in collaborating with others. It's the best of both worlds.

IC038 ©1999 Visionary Design Systems, Inc. All Rights Reserved

www.ironcad.com

800.339.7304



For More Information Circle No. 504

Using Narrow-Band Data Links in Locating Lightning Strikes

Electric-field waveforms are preprocessed to extract selected characteristics.

John F. Kennedy Space Center, Florida

A method of preprocessing lightning-measurement waveforms has been devised to reduce the bandwidth needed to transmit data for computing the locations of lightning strikes. The method is used in a system in which electric fields and electric-field derivatives induced by lightning are measured at remote stations and the measurement data are transmitted to a central station. At the central station, the location of each lightning strike is computed from the known positions of the stations, the speed of light, and the differences among times of arrival of common waveform features at the remote stations. Prior to the development of the present method, in order to achieve a required spatial resolution of tens of meters, it was necessary to transmit full measurement data from each remote station to the central station in real time at a bandwidth of 10 MHz.

The preprocessing method exploits the following two concepts:

- A lightning strike typically comprises multiple strokes 20 to 50 ms apart, each stroke lasting of the order of 0.1 ms. Even during an intense thunderstorm,

lightning strikes usually occur no more frequently than once every few seconds. Given this essential intermittency, the data-transmission bandwidth necessary to accommodate the time-averaged data rate is much less than the real-time, full-resolution bandwidth of 10 MHz. Thus, by abandoning real-time transmission, one can make possible a reduction in the data-transmission rate.

- If one extracts data on waveform characteristics that can be used to establish times of arrival, then the remaining waveform data can be discarded to effect a further reduction in bandwidth.

In this method, each remote station is equipped with a digitizer and an embedded controller. When a signal exceeds a predefined threshold, digital samples of the signal are taken at a rate of 20 megasamples per second for an observation interval of 100 μ s. The record of samples is time-stamped with the starting time of the observation interval as determined by a differential Global Positioning System (GPS) receiver.

Still at each remote station, waveforms are characterized in terms of time

elapsed between largest peaks (both positive and negative), rise times, durations at half maximum amplitudes, and other parameters. Each such characteristic is encoded in two bytes: one that identifies the characteristic and one that gives its value. The resulting code data and the time stamp are then transmitted to the central station for processing.

In the central station, the data from the remote stations are lined up in a search for matches among the characteristics. Differences among times of arrival are then determined on the basis of the best match.

The accuracy of the estimated differences among times of arrival increases with the number of characteristics. About 10 unique characteristics are enough to obtain good alignment. The bandwidth needed to transmit 10 coded characteristics and the accompanying timing data is 5 kHz — only 1/2,000th of the bandwidth needed for real-time transmission of full waveform data.

This work was done by Jose M. Perotti of Kennedy Space Center and Pedro J. Medelius, formerly of I-NET, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Programs and Commercialization Office, Kennedy Space Center, (407) 867-6373. Refer to KSC-11955.

Celebrating Ten Years of Innovation

1990 - 2000

| <u>Instruments division</u> | <u>Components division</u> | <u>Mil/Aero division</u> |
|--------------------------------|----------------------------|-------------------------------|
| • Field test equipment | • Cable assemblies | • Cable harnesses |
| • Laboratory test equipment | • Fiber end preparation | • Design and prototyping |
| • Manufacturing test equipment | • Tools and accessories | • Manufacture & qualification |

Measure

Manufacture

Qualification

RIFOCS Corporation
INT+1-805-389-9800 • Fax. INT+1-805-389-9808 • sales@rifocs.com • www.rifocs.com
Shop online NOW @rifocs.com



Centralized Electronic Reporting of Material-Science Tasks

Expensive and time-consuming distribution of, and searches among, paper documents are no longer necessary.

John F. Kennedy Space Center, Florida

The Materials Science Division (MSD) at Kennedy Space Center is developing a computer system to maintain a material-science data base coupled with a user-friendly interface on the World Wide Web. The system is designed to eliminate the need for time-

consuming and expensive distribution of, and searches among, paper documents.

The system comprises two main parts: the MS Report Log and the MSD Report Server. The MS Report Log facilitates tracking the statuses of tasks and maintaining documentation pertinent to those tasks in various subdivisions of material science, including failure analysis, chemical analysis, metallurgical evaluation, and physical testing. The MS Report Log serves as a unified medium for reporting, replacing a disjointed combination of paper and computer logging and reporting by mail and telephone. The MS Report Log is accessible via any computer workstation running commercially available web-browser software.

The MS Report Log automatically sends, by electronic mail, notices of changes in a task to all investigators, their supervisors, and others who are involved in or have expressed interest in the task. A person using the MS Report Log can view all data related to a task, can (if authorized) request a new task, and can download reports of tasks electronically. Investigators and their supervisors can update selected task fields in the data base, generate reports, and add related documents.

The MSD Report Server, still undergoing development, is intended to serve as an electronic archive of all MSD reports, which have been accumulating since the early 1960's. The MSD Report Server would provide quick and easy access to documents, many of which are, variously, inaccessible or accessible only through consultation with experts: These documents

— about 45,000 in all — are in paper form, stored in boxes and filing cabinets in various laboratories, each of which uses its own report-numbering system. In addition, laboratories have been divided, merged, and renamed over the years, and experts who retain the institutional memory of the report files have retired, so that it is becoming increasingly difficult to locate old reports on specific parts or materials that could be relevant to current investigations.

The paper documents would be scanned and digitized to generate the data for the MSD Report Server. Reports would be indexed and would be accessible via keyword searches entered via the MSD Report Search web page. Each report would be made available electronically, in both full text and portable document format (PDF). The PDF versions of reports would include images. PDF-viewer software can be downloaded via the MSD Report Search web page. Optionally, each report could be reprinted in its original format. At present, only Kennedy Space Center personnel have access to the MSD Report Server; eventually, wider access will be allowed.

This work was done by Scott Murray, Tim Bolo, Debra Folmar, Bill Dearing, and Angela Balles of Kennedy Space Center and William I. Spiker II and Nancy Tuttle, formerly of I-NET, Inc.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Programs and Commercialization Office, Kennedy Space Center, (407) 867-6373. Refer to KSC-11948/60.

Algorithm for Rapid Acquisition of a PPM Optical Signal

Data frames can be synchronized with part of the synchronization sequence.

NASA's Jet Propulsion Laboratory, Pasadena, California

An algorithm for rapid acquisition of a pulse-position-modulation (PPM) optical data signal implements a pattern-matching technique for synchronization of receiver timing with the temporal boundaries of data frames. Synchronization is necessary because in PPM, information is conveyed by the time slot during which a pulse is detected. Fast acquisition of a signal depends on detection of pulses in noise, and on correct estimation of

the times of detected pulses. To facilitate synchronization at the receiver, a transmitter periodically inserts a prescribed sequence of pulses — the synchronization sequence or word — into the transmitted data stream. Older PPM-signal-acquisition algorithms are based on correlations and depend on reception of the full synchronization word (128 bytes long in some applications). The present algorithm is more computationally effi-

What do you need for your data acquisition application?

✓ Real-time data processing?

You can have that.

✓ A custom-built PCI system?

You can have that.

✓ Many channels, easy expansion?

You can have that.


✓ A way to eliminate aliasing?

You can have that.


✓ Continuous high-speed sampling?

You can have that.

with the DAP 5200a



or other DAP models



*** Now with ***
*** onboard processors ***
*** up to 300 MHz ***

Call 888 678-2752 today
to find out how you
can have what you want.

**MICROSTAR
LABORATORIES™**
the onboard intelligence company

www.mstarlabs.com • info@mstarlabs.com
888 MSTARLABS (678-2752)

What can IRIS Explorer help you see?



This is what a leading
athletic shoe maker saw!


In our Advanced Technology Exploration department, we look at all computer tools that can help us design product faster. We use IRIS Explorer for rapid application prototyping when we want to test a new analysis algorithm and



when we want to do "what if" experiments. It gives us a fast and flexible way to pull together prototype code.



IE's low programming overhead is a big advantage. Understanding our analysis results and the morphology of the foot requires fast and accurate visualization, and this is where IE delivers the second big benefit. Whether our data is from a laser scanner or a touch probe, IE consistently handles any dataset.



Mark Johnston, Nike Inc.

IRIS Explorer can bring a new view to your science and engineering applications whether it is medical imaging, chemistry, fluid dynamics, finance, earth sciences, or manufacturing. Now offered for UNIX workstations and Windows NT. Y2K compliant!

Numerical Algorithms Group

1400 Opus Pl., Suite 200
Downers Grove, IL 60515
Ph: (630) 971-2337

NAG[®]

www.nag.com • info-ntb@nag.com

Received Pattern: 1 0 1 (Two Bytes Received)

WS: 1 0 0 0 0 1 0 1 1 0 1 0 1 0 0 0 1 1 1 0 1 1 1 1 0 0 1 0 0 1 1 ← Synchronization Word
PPL: 0 0 0 0 0 1 0 1 1 0 1 0 1 0 0 0 0 0 1 0 1 0 0 0 0 0 0 0 0 0 0 0 ← Four Possible Locations of Received Pattern

Received Pattern: 1 0 1 1 (Three Bytes Received)

WS: 1 0 0 0 0 1 0 1 1 0 1 0 1 0 0 0 1 1 1 0 1 1 1 1 0 0 1 0 0 1 1 ← Synchronization Word
PPL: 0 0 0 0 0 1 0 1 1 0 0 0 0 0 0 0 0 0 1 0 1 1 0 0 0 0 0 0 0 0 0 0 ← Two Possible Locations of Received Pattern

Received Pattern: 1 0 1 1 0 1 (Four Bytes Received)

WS: 1 0 0 0 0 1 0 1 1 0 1 0 1 0 0 0 1 1 1 0 1 1 1 1 0 0 1 0 0 1 1 ← Synchronization Word
PPL: 0 0 0 0 0 1 0 1 1 0 1 0 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 ← One Possible Location of Received Pattern:
Synchronization Complete

Received Byte Patterns are compared with sub-sequences of a 32-bit synchronization sequence. Matches with sub-sequences of increasing length are sought until the received pattern matches a unique sub-sequence.

cient and is capable of achieving synchronization with part of the synchronization word — typically with as few as 2 to 6 bytes.

The algorithm involves, among other things, selective elimination of unlikely starting points for a sequence of received pulses detected in the presence of noise. It is assumed that the pulse-detection threshold of the receiver is set at a level that corresponds to a specified bit-error probability. The receiver is switched on at a random time, and a search for the synchronization sequence is started. The objective of the algorithm is to uniquely identify the temporal location of a received sub-sequence of the synchronization sequence.

Initially, the algorithm seeks all possible candidate sub-sequences that match a received 2-byte sequence. The process continues with the reception of additional bytes; the algorithm seeks matches with 3-byte sub-sequences, 4-byte sub-sequences, and so forth, until it eliminates all candidate sub-sequences that do not match and arrives at a single unique sub-sequence and thereby establishes the receiver timing relative to the entire synchronization sequence. The figure presents an example of this process in the case of a 32-byte synchronization sequence.

When real data are interleaved between periodic transmissions of the synchronization sequence, data-bit patterns can sometimes be identical to sub-sequences of the synchronization sequence. Random bit flips caused by noise can also cause bit patterns other than the desired ones to

alias as synchronization sub-sequences. To reduce the incidence of such errors, one can require confirmation in the form of additional received bytes beyond those needed to establish a unique synchronization sub-sequence; the additional bytes are said to constitute a confirmation sequence. The probability of false synchronization is inversely proportional to the length of the confirmation sequence.

The procedure for confirmation immediately follows the identification of a unique sub-sequence and determination of its starting time. The unique sub-sequence enables the algorithm to predict the arrival of the next pulse in the known synchronization sequence. If the next detected pulse arrives at the expected time, confirmation continues with the next pulse, and so on, for as many pulses as required for the confirmation sequence. If all predictions and observations have been found to match when the confirmation procedure has been completed, then synchronization is deemed to have been achieved and the temporal boundaries of data frames are calculated. If a mismatched pulse is detected during the confirmation procedure, then the algorithm resets.

This work was done by Payman Arabshahi, Tsun-Yee Yan, and Kourosh Rahnamai of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category. NPO-20528

Out-of-the-Box™

Data Acquisition


For Portable, Distributed, & Lab Applications

Whether you're in a vehicle, on the plant floor, or in the test lab, IOtech has the optimal data acquisition solution for your application. Our *Out-of-the-Box™* software allows you to acquire data as soon as you've attached your signals. Drivers for all popular languages & applications under Windows® 95/98/2000/NT, including Visual Basic®, C++, Delphi™, LabVIEW®, & DASyLab® are also provided.

USB




High Speed



Up to 80 channels of volts, thermocouples, digital I/O, & frequency – *all in one compact, USB-powered module.* **Personal Daq™**, from \$695

WEB QUICK FIND #400*


Out-of-the-Box™ Software



1 MHz, 16-bit sampling for portable & desktop applications. Expandable up to 72 channels – ICP® accelerometers & strain gage signal conditioning options. **WaveBook™**, from \$2,995.

WEB QUICK FIND #401*

Stand-Alone



Measure & control over 400 I/O channels at rates up to 100 kHz – *without a PC at the test site.* Programs & acquired data are stored in removable PC-Card memory. **LogBook™**, from \$3,495.

WEB QUICK FIND #402*

**SHOP
ON
LINE**

Isolated voltage & thermocouple inputs, all from one ethernet or serial port. OPC/DDE-server for SCADA/HMI applications. **NetScan™** & **ChartScan™**, from \$1,995.

WEB QUICK FIND #403*

**Ethernet
& Serial**



included FREE!

www.daqproducts.com

For a complete listing of IOtech worldwide sales offices, see www.iotech.com/sales.html

Australia 61 3 9569 1366; Austria 43 316 30700; Belgium 31 162 472 461; Brazil 55 11 853 2733; Canada (905) 890 2010; China 86 10 6232 9880; Denmark 45 43 71 64 44; Central Europe 431 54 51588; Finland 358 9 4761600; France 331 3489 7878; Germany Synotech 49 2462-99-19-0; Spectra 49 7119-02-97-0; Hong Kong 852-2833-9987; India 91-80-655-4993; Indonesia 65-482-5600; Israel 972-3-649-8538; Italy 39 02 392 66561; Japan 81 3-3279 0771; Korea 82 2 538-4001; Malaysia 603-791-2220; Netherlands 31 162 472 461; New Zealand 64 9309 2464; Norway 47-22-76-40-00; Portugal 349-1-570-2737; Singapore 65-482-5600; South Africa 27-11-254-8420; Spain 349-1-570-2737; Sweden 46-13-357030; Switzerland 411-878-9090; Taiwan 886 2 2797 3357; Thailand 65 482-5600; United Kingdom 44 1296 397676



1.888.816.1701


CIRCLE 401

IOtech Inc.
25971 Cannon Rd
Cleveland OH 44146
Fax 1.440.439.4093
sales@iotech.com

* For up to date information on products, and to order online, visit the IOtech Web site and enter the QUICK FIND number.

All trademarks or registered trademarks are property of their respective holders.


Temperature



Strain



Vibration



Pressure



You've Got Sensors, We've Got Solutions

Attach your sensors directly to IOtech's Out-of-the-Box™ data acquisition solutions for portable, lab, & stand-alone applications. Get signal conditioning, A/D, & software – all from one supplier. Browse a wide selection of solutions online, or call for your free Y2000 catalog & demo CD.

www.iotech.com

WEB QUICK FIND #407*




1.888.890.3011

* For up to date information on products, and to order online, visit the IOtech Web site and enter the QUICK FIND number.

CIRCLE 402

PCI Data Acquisition

16-Bit Performance 12-Bit Price!



DaqView™ software for Out-of-the-Box™ setup & instant operation



Drivers for Windows® 95/98/2000/NT, LabVIEW®, TestPoint®, & DASyLab®

\$495

These astonishing features and value are the outcome of over 15 years of developing data acquisition products, including signal conditioning and software.

Visit our Web site at www.daqboard.com to learn more about the DaqBoard/2000™, and to place your order directly. Contact us today for your FREE Y2000 Catalog.

www.daqboard.com

WEB QUICK FIND #404*



1.888.890.0688

* For up to date information on products, and to order online, visit the IOtech Web site and enter the QUICK FIND number.




IOtech Inc.
25971 Cannon Road
Cleveland OH 44146
Fax 1.440.439.4093
sales@iotech.com

All trademarks or registered trademarks are property of their respective holders.

CIRCLE 403



Special Coverage: Data Acquisition



Iotech, Cleveland, OH, offers the DaqBoard/2000™ PCI data acquisition board, which is designed for high-speed, plug-and-play PC-based acquisition. The board includes 16-bit, 200-kHz A/D; bus mastering; dual 16-bit, 100-kHz D/As; 40 digital I/O lines; four counters; and two timers. Also offered are signal conditioning and expansion options for thermocouples, RTDs, accelerometers, isolation, high-voltage, strain gauges, and current.

Up to four boards can be installed into one PC. One 100-pin connector provides access to all input and output signals. Users can expand the board up to 256 analog inputs. An on-board scan sequencer allows selection of any combination of up to 512 channel/range combinations. Software support includes drivers for programming tools such as Windows® 95/98/2000/NT, Visual Basic®, C++, and LabVIEW®.


For More Information Circle No. 733



Keithley Instruments, Cleveland, OH, has introduced the Integra Series Model 2700 multimeter/data acquisition system that combines a high-channel-count datalogger with a 22-bit DMM. The half-rack-size system can perform up to 80 channels of measurement and control. The system can function as an integrated, PC-based, mini-ATE system. Built-in mainframe signal conditioning can handle inputs up to 1000V.

Two card slots accept a variety of input modules, with the ability to vary channel count from 20 to 80, apply a stimulus to DUTs, route signals, control system components, and make measurements with 13 different test functions. D-Sub or oversize screw terminal connectors are available. With DMM-like pushbutton controls and front/rear inputs, users easily can collect data and/or perform troubleshooting. Communication with a PC is via a GPIB or RS-232 interface.

For More Information Circle No. 730



Microstar Laboratories, Bellevue, WA, offers the iDSC 1816 data acquisition board, an eight-channel, 16-bit resolution board for the PCI bus. The board, designed for those PC-based systems requiring anti-aliasing filters, has onboard filters that combine analog and digital algorithms. The board acquires data at up to 153.6 Ksamples per second per channel, and filters signals for all types of spectral analysis.

The user can control the board from any Windows system that contains the board, or remotely from any other Windows system on the same network. The board also features 8 differential inputs with simultaneous sampling and independent filters, and expansion to 112 simultaneous channels in one PC. Software included with the board configures it for data acquisition, and also acquires, graphs, and logs data. The software includes drivers for HP VEE, LabVIEW, DASyLab, and DIAdem.

For More Information Circle No. 729



The DEWE-3010 data acquisition system from Dewetron, Wakefield, RI, combines a portable industrial computer with slots for 8 modules that adapt the system to virtually any sensor. The CPU is a 400-MHz AMD K6™II,

with a 100-MHz bus, and features 128 MB RAM and a 4 or 9 GB hard disk drive. It also features a USB interface, built-in CD-ROM drive, 12.1" display, and internal UPS. The system can expand to 2,048 channels.

The connectable modules power virtually any sensor, provide up to 1500 Vrms of isolation, and include anti-aliasing filters. They provide up to 8 input channels each, and 8 modules can be plugged into the system. DEWScope+ software provides set-up for the system. The modules are software controllable; the software is included. Any Windows application can be run on the system.


For More Information Circle No. 731



Vision is a portable data acquisition system from Nicolet Technologies, Madison, WI, that combines elements of DAT recorders, oscillographs, and oscilloscopes. It provides real-time scrolling, triggered, or XY displays, and has removable storage. The system's universal amplifiers provide 500V isolation, with 16-bit digitizers on each channel. Eight channels at 100 kS/s each can be recorded in 80 minutes; 16 channels at 1 kS/s can be recorded over three days.

Other features include 20 kHz analog bandwidth, universal isolated signal conditioning, a lightweight enclosure, continuous recording at full acquisition speed to an 8-GB hard disk or 2-GB Jaz drive, and 100 base-T Ethernet and IrDA connection to external devices. A sound channel records user comments, and 8 digital inputs record status bits, frequency, or RPM.

For More Information Circle No. 728



The ADuC824 MicroConverter™ data acquisition system on a chip from Analog Devices, Norwood, MA, is a data conversion, program and data flash memory, and 8-bit microcontroller. It provides a programmable sigma delta converter, and incorporates a mixed-signal integrated circuit architecture. It is suited for calibrating and conditioning analog and digital sensor signals in portable applications, medical instrumentation, or sensor interfacing.

The chip's mixed-signal integration incorporates two high-resolution analog-to-digital converters, temperature sensor, programmable-gain amplifier, 12-bit digital-to-analog converter, 8-bit microcontroller unit, flash memory, random-access memory, and serial ports. It operates from a 32-kHz crystal with an on-board phase-lock loop, from a single 3V or 5V power supply.

For More Information Circle No. 732



Tunable HTS/Ferroelectric Microstrip Band-Pass Filters

These filters are designed for operation at temperatures less than about 77 K.

John H. Glenn Research Center, Cleveland, Ohio

Electrically tunable microstrip two-pole band-pass filters for a center frequency near 19 GHz and a 4-percent bandwidth have been designed, fabricated, and demonstrated to be functional. These filters are suitable for use in the front ends of K-band communication receivers that operate at low temperatures.

Figure 1 depicts the multilayer configuration and microstrip layout of one of these filters. The top layer is a thin film of the high-temperature superconductor (HTS) $\text{YBa}_2\text{Cu}_3\text{O}_{7-\delta}$ patterned into microstrip lines. The top layer rests on a layer of the ferroelectric material SrTiO_3 , which rests on a dielectric layer of LaAlO_3 . The bottom of the LaAlO_3 is coated with a thin film of a normal conductor (Au), which serves as a ground plane.

Tunability is achieved through the nonlinearity (specifically, the variation of permittivity with electric field) of the SrTiO_3 layer. Using a commercial electromagnetic-analysis computer-aided-engineering software package, the design of the filter was optimized so that normal operation at the center frequency would occur when the relative permittivity ϵ_r of the SrTiO_3 was 1,650. This resulted in a requirement to maintain a suitable bias in order to maintain ϵ_r at 1,650.

Prototypes of these filters were packaged for swept-frequency measurements of their scattering parameters (S_{ij}) in a helium-gas closed-cycle cryogenic system. In experiments on tunability, a dual-polarity biasing technique was used: Referring again to Figure 1, nodes A and C were biased with a positive voltage, while nodes B and D were biased with a negative voltage of equal magnitude. The dc bias connections at A and D were made via input and output bias tees; the bias connections at B and C were achieved via gold-wire bonds on radial biasing stubs. The dc bias was increased from 0 to ± 500 V in steps of ± 50 V.

Figure 2 depicts results of some of the measurements; namely, the frequency and voltage dependence of S_{11}

and S_{12} of one of the filters at a temperature of 77 K and an input power of 10 dBm. With increasing bias voltage, the center frequency of the filter

shifted from 17.4 GHz at no bias to 19.1 GHz at a bias of 500 V, giving a tunability factor of 9 percent. The lowest measured pass-band insertion loss




Figure 1. $\text{YBa}_2\text{Cu}_3\text{O}_{7-\delta}$ Microstrip Lines are shaped and dimensioned, in conjunction with the underlying layers, to obtain the desired two-pole pass-band frequency response. The pass band is adjusted by varying the dc bias and thus the electric field in the SrTiO_3 layer.



We packed
2
 instruments
 IN
 so you can
CRANK
 more product
OUT.



Keithley 2400 Series SourceMeters® have tightly integrated source and measure functions for big throughput advantages compared with multiple instrument systems. Designed for component production testing, these instruments combine a precision power supply and a highly repeatable 5½-digit

DMM. In operation, the 2400 line can act as a V-Source, an I-Source, a V-Meter, an I-Meter, and an ohmmeter.

The high voltage Model 2410 and high current Model 2420 extend dynamic range capabilities while the optional contact check function quickly verifies good connection to the component under test. Accessories and switching systems let you easily build complete multipoint solutions.

For a detailed brochure with complete specs, or to talk to an Application Engineer, contact Keithley today at 1-888-534-8453.



KEITHLEY

A WORLD OF MEASUREMENT SOLUTIONS

DYNAMIC RANGE

2400/2400-C 2410/2410-C 2420/2420-C

| | | | |
|---------|-------------|-------------|---------|
| Voltage | ±200V | ±1100V | ±60V |
| Current | ±1A/20V | ±1A/20V | ±3A/20V |
| | ±100mA/200V | ±20mA/1100V | ±1A/60V |
| Power | 22W | 22W | 66W |

MAX SYSTEM SPEEDS:

| | |
|---------------|---------|
| Pass/fail | = 500µs |
| To memory | = 500µs |
| To IEEE-488 | = 1ms |
| Range change | = 13ms |
| Contact check | = 350µs |

EXTERNAL INTERFACE:

| |
|-------------------|
| IEEE-488 (SCPI) |
| RS-232 |
| Digital I/O |
| Component handler |

1 YEAR BASIC ACCURACY: (5½-DIGIT RESOLUTION)

| | |
|-------|-------|
| Volts | 0.01% |
| Amps | 0.02% |
| Ohms | 0.04% |




Figure 2. S_{11} and S_{12} of a Filter were measured at 77 K. These plots show the desired voltage dependence of the pass band, plus a desirable increase in S_{12} and a desirable decrease in S_{11} with bias voltage.

of this filter was 1.5 dB at 24 K. Another filter exhibited a tunability factor of 12 percent at a temperature of 30 K. In general, the return losses S_{11} and S_{22} of the filters were near or greater than 10 dB in the pass band. The resonance quality factor (Q) of the filters in the absence of loading was estimated to be ≈ 200 . Efforts to optimize the HTS and ferroelectric films to obtain lower insertion losses and better tunability near 77 K and at lower bias voltages were underway at the time of reporting the information for this article.

This work was done by F. A. Miranda of Glenn Research Center, F. Van Keuls of the National Research Council and G. Subramanyam of the University of Northern Iowa. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16751.

CO₂ Laser Marking Solutions

Low cost, easy-to-integrate laser technology for OEMs and Systems Integrators




FH Series Marking Head

Synrad has made it easier than ever to incorporate CO₂ lasers into industrial marking systems with a full range of laser marking components that are flexible, easy to integrate, and affordable.

CO₂ lasers can be used to mark a wide range of materials - and, lasers offer a number of benefits over other marking technologies, including less maintenance and higher throughput.

In fact, Synrad offers all the components you'll need to assemble a complete laser marking system (you supply only a PC)-including the software!

To find out more about Synrad CO₂ laser marking, call 1-800-SYNRAD1 today!



WinMarkpro™ Laser Marking Software



An Excel Technology Company

Return-Link Processor PCI Card

Relative to prior return-link circuitry, this card is smaller, less power-hungry, higher performance, more versatile, and much cheaper.

Goddard Space Flight Center, Greenbelt, Maryland

The return-link processor card (RLP) performs all of the fundamental data-processing functions involved in the return of satellite telemetry, in real time at rates up to 400 Mb/s, using industry-standard interface circuitry and connectors with standard sizes and shapes. Previously, four cards, each containing a central processing unit (CPU), were needed to do what the RLP now does. CPU-based cards are complex; are expensive to build, operate, and maintain; are susceptible to malfunction; and require a great deal of power and cooling.

Functions of the RLP include frame synchronization, cyclic-redundancy-code and bit-transition-density decoding, detection and correction of errors by use of Reed-Solomon codes, processing according to the Consultative Committee for Space Data Systems (CCSDS) standard for Advanced Orbiting Systems (AOS) service, and CCSDS conventional processing of packets and frames of telemetric data. The RLP can also synchronize frames of data in a weather-satellite-data format and in other formats. Data received via the Internet and other low-rate sources accessible by a computer can be injected directly by the host computer in which the RLP is installed.

The RLP is a single industry-standard peripheral component interface (PCI) expansion card. In addition to the industry-standard PCI connector, it contains industry-standard subminiature B connectors for emitter-coupled-logic (ECL) input, an industry-standard DB-9 connector for RS-422 input, connectors for programming nonvolatile logic devices and a connector for an optional sorting module (OSM — a mezzanine board on which additional buffering, processing, and output functions can be implemented.)

The RLP contains the following circuits:

- An ECL input interface circuit,
- An RS-422 input interface circuit,
- A special-purpose parallel integrated frame-synchronizing application-specific integrated circuit (ASIC),
- A special-purpose Reed-Solomon error-detecting-and-correcting ASIC,
- A custom ASIC for CCSDS AOS

Service and conventional CCSDS processing of packets and frames,


- A PCI-bus-interface ASIC,
- A custom direct-memory-access interface reprogrammable, non-volatile logic circuit,
- A custom reprogrammable non-volatile logic circuit for monitoring and controlling the other circuits,
- A custom reprogrammable non-volatile logic circuit that serves to collect status from the other circuits and supply it as a telemetry data stream, and
- Miscellaneous active and passive devices.

During typical operation, a standard serial data stream enters via either the ECL or the RS-422 input path, is processed in data-flow fashion through the ASICs, and is deposited in a number of first-in/first-out (FIFO) memory buffers onboard the RLP. Setup, control, retrieval of data, and monitoring are performed through an entirely memory-mapped PCI interface by software running on the host computer. The presence of data can be detected either by use of interrupts or by polling. Monitoring information is semiautomatically collected into easy-to-retrieve data blocks.

In comparison with the previous assembly of four cards, the RLP is smaller, less expensive, faster, and more energy-efficient. The CPU-less, memory-mapped mode of operation of the RLP is simpler and more robust than was the CPU-based operation of the previous assembly. The RLP is more flexible in that it can operate in any industry-standard PCI host computer and all logic is implemented in reprogrammable nonvolatile logic devices. The RLP is also both more flexible and expandable by virtue of the OSM interface connector.

This work was done by Kenneth B. Winiecki, Jason Dowling, Stephen T. Koubek, and Fred H. Peng of Lockheed Martin and Andrew F. Wolf of RMS for Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category. GSC-14032

Powerful Signal Processing Made Easy



- IIR and FIR digital filter design
- 31-band third-octave analysis
- Interactive wavelet and filter bank design
- Joint-time frequency analysis using the Gabor spectrogram
- Super-resolution spectral analysis

Run the Signal Processing Toolset by itself, or seamlessly integrate it with your existing LabVIEW™ software programs.

Call or visit
www.ni.com/labview
today for a **FREE**
Add-on Software
demonstration CD




NATIONAL INSTRUMENTS

www.ni.com/info/cw

(800)-452-9213

Tel: (512) 794-0100 • info@ni.com

© Copyright 1999 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.



The Automated Fatigue Calculation Program (FATPLUS)

Since it was developed in the late 1980s, the Automated Fatigue Calculation Program (FATPLUS) has consistently demonstrated its ability to predict

fatigue life, independently validate proprietary fatigue methodologies, identify fatigue-sensitive parts, and train engineers in predicting fatigue lives. FATPLUS enables its users to create, save, and modify specific stress spectra and properties of materials.

A conservative methodology yields

valid estimates of fatigue lives as long as reasonable engineering practices are maintained. However, FATPLUS can do more than this. The program is also a powerful, menu-driven, interactive design software tool for studying and analyzing effects of a spectrum of stresses, effects of changes in design, effects of changes in materials, and changes in concentrations of stresses.

To make FATPLUS into a program that predicts fatigue lives and a very powerful tool for analyzing systems, the developers of FATPLUS accounted for (1) the spectrum of stresses, (2) the number of loadings per stress event, (3) fatigue properties of materials, and (4) safety factors. Of these considerations, safety factors were found to be the largest variables in estimating fatigue lives because safety is affected by (1) constant life reduction, which multiplies total damage or reduces the number of cycles by a constant factor, and (2) statistical reduction, according to which allowable stress is reduced by a percentage based on the known degrees of variability of properties of materials.


When performing a system analysis or study, FATPLUS uses an online or preprogrammed spectrum, which is applied to a materials curve (a complex curve based on the more conservative of constant life reduction or statistical life reduction). Total damage and allowable life are determined from a combination of input from the user and cycles in the input spectrum. Because all users will not have access to corporate or private fatigue data, the developers of FATPLUS provided MIL-HNDBK-5 data on materials.

FATPLUS is therefore a superior program. Since release, this multifaceted program has proved itself strong and adaptable. FATPLUS can be expected to become used widely across private industry and government as users become more aware of all the program has to offer.

FATPLUS is written in FORTRAN for execution on PC-compatible computers.

This work was done by Thomas Minyard and James A. Babb, formerly of Lockheed Electronics and Space Corporation for Johnson Space Center. The software with complete documentation is available from James Babb, Johnson Engineering, telephone (281) 228-7710. MSC-22537

Space Proven



LOW POWER, FAST WARM UP OCXO's DELIVER ULTRA STABLE PERFORMANCE ON TIME AND ON BUDGET

These space proven units will meet your most demanding space exploration and satellite time/frequency requirements.

FEATURES INCLUDE:

- Stability: 1×10^{-11} / day
- Warm up to stabilized frequency in as little as 2 min. using as low as 1 watt-hr.
- Low power steady state: 0.6 to 3 watts
- Small size & mass: 200 grams; < 7 cu. in.
- Full MIL or 'S' level
- Radiation hardened
- Remote Frequency Comm.

Depend on FEI... send for specifications today.



FEI Communications, Inc.

A Subsidiary of Frequency Electronics, Inc.
55 Charles Lindbergh Blvd., Mitchel Field, NY 11553
TEL: 516-794-4500 • FAX: 516-794-4340
Visit us at: www.frequelec.com



Tuesdays at Ten 10:00 a.m. Eastern Time

Algor Live Webcasts

Expand the Scope of Customer Service



Join the FEA software industry leaders every Tuesday at 10:00 a.m. Eastern Time in a Live Webcast to learn more about using Algor, the leading technology software for mechanical engineers. Each hour-long Webcast contains general news, frequently asked questions, a main topic presentation that shows Algor software in action and a general panel discussion focused around a topic, such as Mechanical Event Simulation, the use of Algor's proprietary kinematic elements or Algor's interoperability with CAD solid modelers. Algor President and CEO Michael Bussler and other key technical experts frequently join Algor application engineers for the Webcasts. During the Webcast, engineers can phone or email questions to be answered live by the panel. After the broadcast, Webcasts are made available as Webcast replays for a personal, free screening any time.

Webcasts help engineers learn these topics faster:

Automatic vs. User-Specified Meshing in CAD • Performing a Linear Static Stress Analysis Using Algor • Performing Heat Transfer Analyses Using Algor • Mechanical Event Simulation vs. Motion Load Transfer • The Use of Kinematic Elements • Fluid Flow Power Using Algor • FEA vs. Mechanical Event Simulation • Algor's PipePak Analysis Capabilities • And more

See our web site for a list of dates and topics of upcoming Webcasts and Webcast replays.



An Algor application engineer answers a customer's question live during an Algor Webcast.

Watch the live Webcasts to interact during the broadcast and have your questions answered live.

- Email your questions before or during the Webcast to webcast@algor.com
- Call in during the Webcast at +1 (412) 967-2700 x3014
- If there is a point of interest or subject matter that you would like added to the schedule, please send an email to webcast@algor.com

About the Streaming Video Format:

The streaming video format used for all Webcasts is designed for Microsoft Windows Media Player. Since most of Algor's customers operate on the Windows 95, 98, or NT platforms, using Microsoft tools such as Windows Media Player and Internet Explorer 4.0 or higher offers maximum compatibility, reliability and through-put. The latest version of Windows Media Player can be downloaded at no charge from our web site or at www.microsoft.com.




For a complete listing of upcoming Algor Live Webcasts and Webcast replays go to:

www.algor.com/webcast

Working with InCAD^{Plus} and Mechanical Event Simulation for Better Product Design

Design new products within your CAD system with Algor's InCAD^{Plus} and Physics-Based Mechanical Event Simulation software (MES). Algor's InCAD^{Plus} couples its innovative MES software and proprietary Kinematic Element technology with the design power of the popular CAD solid modelers listed below so engineers worldwide can design new products that are more reliable, have lower production costs, higher performance and a shorter time-to-market. Algor's InCAD^{Plus} works with the CAD solid modeler capturing the exact assembly or part geometry in coordination with the CAD API, eliminating data translation problems. When Algor and the CAD solid modeler reside on separate computers, Algor's Direct Memory Image Transfer (DMIT) technology can achieve the same level of interoperability without file translation.



All trademarks may be trademarks or registered trademarks of their respective owners.

ALGOR
When the Engineering
Has to be Right

Algor, Inc.
150 Beta Drive, Pittsburgh, PA 15238-2932 USA
Phone: +1 (412) 967-2700
Fax: +1 (412) 967-2781
California: +1 (714) 564-0844
Europe (UK): +44 (1784) 442 246
Email: info@algor.com
www.algor.com



Composite-Material Heat Sink for Printed-Circuit Boards

This is a lightweight alternative to an aluminum heat sink.


Goddard Space Flight Center, Greenbelt, Maryland

A laminated composite-material plate has been developed for use as a lightweight heat sink and mechanical support for rigid printed-circuit boards (PCBs) that hold surface-mounted electronic components. This composite-material plate is intended to replace a conventional aluminum heat-sink plate. The aluminum plate weighs 0.63 lb (0.29 kg), whereas the composite-material plate weighs only 0.36 lb (0.16 kg).

An advanced laminated composite is attractive as an alternative to aluminum in several respects:

- The orientations of fibers in the laminae can be selected to tailor the properties of the laminate.
- The bending stiffness of a typical advanced laminated composite material is eight times as great as that of aluminum; this is an important advantage because PCBs that hold surface-mounted components are relatively intolerant to flexing. (The intolerance to flexing arises because flexing can break the beads of solder used for attachment in surface mounting.)
- The density of a typical advanced composite material is two-thirds that of aluminum.
- The coefficient of thermal expansion (CTE) of a quasi-isotropic composite laminate is typically less than one-eighth that of aluminum. The lower CTE of the composite material, in concert with the CTE of the PCB material, promises an increase in fatigue lives of solder joints, and thus increased reliability.
- The effective thermal conductivity of an advanced composite material can be made to exceed that of aluminum; as a result, better heat-sink performance is attainable. As a consequence of better heat-sink performance, heat-generating components can be packed more densely; thus, a greater degree of miniaturization is possible.

The composite-material heat-sink plate (see figure) comprises (1) a quasi-isotropic laminated core of graphite fibers in a cyanate ester matrix and (2) a 0.002-in. (0.05-mm)-thick aluminum skin backed with a film adhesive. The laminated core consists of six laminae; the



The Composite Heat Sink was designed to satisfy strength, stiffness, and heat-transfer requirements at least as stringent as those imposed on the design of an aluminum heat sink, but to weigh 43 percent less than the aluminum heat sink does.

quasi-isotropy is achieved by stacking each lamina with its fibers at an angle of 60° with respect to those of the adjacent lamina. This fiber orientation was chosen because it optimizes the strength and stiffness characteristics of the laminate. Because the thermal conductivity is greatest along the fibers and it is desired to maximize widthwise thermal conduction in the heat sink, the fibers in the 0° plies are oriented along the width of the heat

sink. The aluminum skin is wrapped around the laminated core to provide a continuous ground plane for the PCBs.

This work was done by Jill M. Holz, Lee Niemeyer, and David Puckett of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category. GSC-14142

Reducing Methanol Crossover in CH₃OH-Fuel-Cell Membranes

Perfluorosulfonic acid-based membranes are impregnated with poly(styrene/divinylbenzene).

John H. Glenn Research Center, Cleveland, Ohio

Improved polymer electrolyte membranes for direct methanol fuel cells can be made by impregnating the baseline membrane material with cross-linked polystyrene (a copolymer of styrene and divinylbenzene). The baseline membrane material is a perfluorosulfonic acid-based hydrophilic, proton-conducting ion-exchange polymer sold under the trade name "Nafion". The principal benefit afforded by the impregnation is a reduction in permeability by methanol; this translates to less crossover of methanol in molecular form (denoted "methanol crossover" for short). Methanol crossover is undesired because it wastes fuel and thereby degrades fuel-cell performance.

8. The sulfonated membranes were placed in distilled water at room temperature, the beaker was covered, and the water was brought to a rapid boil. Samples of the water were cooled to room temperature and tested for Cl⁻ ions by use of one or two drops of AgNO₃ solution. In each case, if a positive result was found, the membranes were removed and placed into another, previously heated beaker of distilled water. This was repeated until the test for Cl⁻ ions yielded a negative result.

Both baseline membranes and membranes prepared as described above were tested to characterize them with respect to ion-exchange capacity, water content, cell resistance, permeability by methanol, and

| Membrane Material | Cell Potential (mV) at Current Density of: | | Crossover, Percent | Electrical Resistance (mΩ) at a Temperature of 60 °C |
|---|--|------------------------|--------------------|--|
| | 100 mA/cm ² | 200 mA/cm ² | | |
| Baseline | 530 | 450 | 19.5 | 7.2 |
| Baseline Containing 8 Weight Percent Cross-Linked Polystyrene | 450 | 290 | 15.6 | 10.5 |

These Fuel-Cell Performance Figures were obtained using MEAs containing two different membranes.

To demonstrate this concept, membranes were prepared as follows:

1. Baseline membranes were cut slightly larger than the final size needed for fuel-cell membrane/electrode assemblies (MEAs). The membranes were dried, weighed, and marked for identification.
2. Solutions of 1, 3, 5, and 8 weight percent styrene/divinylbenzene in methyl chloride with 1 weight percent benzoyl peroxide as an activator were prepared for use in impregnation and polymerization.
3. The membranes were placed in the solutions in test tubes, which were then capped to prevent exposure to air.
4. Each capped test tube was heated to a temperature between 60 and 65 °C for 16 or more hours, until polymerization was complete.
5. After cooling to room temperature, the test tubes were cracked to remove the styrenated membranes.
6. Excess polystyrene (the portion not cross-linked with the baseline membranes) was removed by immersing the samples in methyl chloride at room temperature for various times ranging from 1 to 24 hours.
7. The styrenated membranes were sulfonated by immersing them in a solution of ClSO₃H/CH₃Cl for 16 hours.

proton conductivity. The best one of the prepared membranes was fabricated into a complete MEA, using Pt/Ru anode and Pt black cathode catalysts. An MEA was also made from a baseline membrane. Both MEAs were then tested in a fuel cell. The results of the test (see table) show decreased methanol crossover in the case of the styrenated membrane. The results also show decreased fuel-cell performance in this case. The decrease in performance has been tentatively attributed to incompatibility of the styrenated membranes with the electrode structures and bonding conditions, which were optimized for the unstyrenated membranes. The implication is that it should be possible to recover lost fuel-cell performance by optimizing the electrode structures and bonding conditions for styrenated membranes.

This work was done by J. Kosek, M. Hamdan, and A. B. LaConti of Giner, Inc., for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16669.

SPECIAL
OFFER—
CALL
NOW!

Zero to C/C++ in no time.

Use industry-standard MATLAB to design, develop, and refine your applications. Then use the C/C++ Compiler Suite to convert them into standalone C or C++ code.

MATLAB C/C++ Compiler Suite includes:

- MATLAB Compiler – automatically generates C/C++ code from programs written in MATLAB
- C/C++ Math Library – contains 350 MATLAB math functions accessible from C/C++
- C/C++ Graphics Library – embeds MATLAB graphics and GUIs in your C/C++ code.

Compile

complete

MATLAB

applications,


like this

signal

processing


example, into

C and C++ code.



Information and demos on the Web.

For product information, or to buy online now, visit www.mathworks.com/ntbc.



MATLAB®

508-647-7000 • www.mathworks.com/ntbc



✚ Inflatable Wing Leading Edges for High Lift and Deicing

The incidence of stall accidents could be reduced.

John H. Glenn Research Center, Cleveland, Ohio

Computational simulations and wind-tunnel tests have demonstrated the feasibility of using inflatable boots on the leading edges of airplane wings, both as devices to increase lift and as pneumatic deicing actuators. Assuming success in further research and development, the first applications would likely occur as retrofits to single- and twin-engine airplanes in general aviation (GA). Later, corporate and commuter turboprop airplanes would be included. The eventual incorporation of these boots into new GA airplane designs would be even more desirable because the boots could be integrated with overall wing structures to provide laminar flow in cruise.

The model used in the wind-tunnel tests and as the basis for the computational simulations was a standard airfoil (type 63-212 of the National Advisory Committee for Aeronautics) with a faired circular-arc boot installed on the leading edge (see Figure 1). A boot of this type comprises front and rear cells. The front cell is shaped so that when it is inflated, its exposed leading-edge surface is nominally a portion of a circular cylinder. The rear cell serves as a fairing; it is vented to the atmosphere instead of inflated, and it is formed by attachment between a tangent line on the front cell and a line on the bottom surface of the airfoil.

Faired circular-arc boots for the wind-tunnel model were made of a standard deicing-boot material, and two different designs called "inlaid" and "overlaid" were tested. In the tests, inflation of both boots resulted in significant increases in the maximum coefficient of lift and the angle of the stall break (see Figure 2). Results of preliminary calculations based on the data from these tests suggest that it should be possible to achieve substantial increases in gross weight and reductions in stall speeds by use of faired circular-arc boots.

The use of inflatable leading-edge boots on GA airplanes would enable operation under known icing conditions and would thereby reduce the incidence of weather-related flight delays. High-lift features could be incorporated into de-




Figure 1. An Inflated Faired Boot installed on the leading edge of an airfoil can be used to increase lift and/or as a deicing actuator. A model with this configuration was used in wind-tunnel tests.

icing systems with very small increases in weight. Inflation of the boots for high lift would greatly extend angles of attack for maximum lift and would broaden the peaks of lift-vs.-angle-of-attack functions, thereby helping to prevent stall accidents.

This work was done by Kenneth G. Wernicke and Rodney K. Wernicke of Sky Technology Vehicle Design & Development Co. and Norbert A. Weisend, Jr., Consultant, for Glenn

Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16660.




Figure 2. Maximum Coefficients of Lift and Angles of Stall Breaks were increased by inflation of boots, in both the flaps-up and flaps-down conditions.

MICROWAY DELIVERS SUPERCOMPUTER PERFORMANCE IN NT, LINUX AND UNIX WORKSTATIONS

Since 1982, Microway's products and technical support have helped users get more done for less money. Starting with the concept that PCs could use more numeric power, we built a product line and customer base that is now worldwide. The motherboards and workstations we design today use Pentium- and Alpha-based processors that deliver 20,000 times the throughput of the 8087s we started with in 1982.

Microway has been building Linux Beowulf clusters since 1997. Our users employ either PVM or MPI to manage communications between processors in clusters from 8 to 200 Pentium or Alpha CPUs. We design systems

transputers. Following this, Microway built small supercomputers that featured up to 20 Intel i860 RISC processors. The 667-MHz dual Alpha motherboard, which

your favorite True 64 UNIX, and OpenVMS systems, yet also deliver NT and Linux. And we know how to take care of special situations, including rack-mounted industrial-

engineers take advantage of the IBM PC. Our first product was a library, which made it possible to use an 8087 in a PC. We bundled our libraries with 8087s and became one of Intel's largest customers.

Our hardware products included PC accelerators, coprocessor cards, and motherboards. In 1986, we introduced the first 32-bit Fortran to run on an Intel PC. The first PC to hit a megaflop used a Microway/Weitek coprocessor driven by NDP Fortran. Over the years, NDP Fortran has been used to port hundreds of popular mainframe applications, including MATLAB and ASPEN, to Intel-based PCs.

Microway's workstations have been purchased by university and NASA laboratories since 1989. *PC Computing Magazine* named our Alpha system "the fastest Windows NT workstation on the planet ... the performance leader."

For more information, contact Microway, Inc., Research Park, Box 79, Kingston, MA 02364; Tel: 508-746-7341; Fax: 508-746-4678; e-mail: info@microway.com; www.microway.com

Microway®

www.microway.com

we currently feature in our high-end workstations, delivers 2.6 gigaflops of throughput. If you have an application that is a big-time number-cruncher or a DSP application that needs 64 bits of precision, you should consider our solutions.


grade systems, RAID-controlled hard disk farms, and high bandwidth interprocessor communications

Microway's current software product line is anchored by NDP Fortran, which is available for Pentiums and generates Alpha code for Linux. Compaq and Intel's ten-year agreement insures that the Alpha 21264 and 21364 will continue to be performance leaders in the high-speed numerics market for years to come. Intel and Samsung will manufacture the Alpha, which Compaq engineers will design and market. This means that you can count on Microway to continue our tradition of designing state-of-the-art clusters, motherboards, and workstations.


Microway hardware products have always been popular with government, industry, and university researchers. Our i860 powered cards were used to search for oil, improve MRI resolution, do air flow studies on jet engines, and help the NASA SETI project search for extraterrestrial life. Microway high-end Alpha and Pentium workstations are currently in use throughout the US in major universities and research organizations like NASA, NIST, NIH, Lincoln Laboratory, Smithsonian, and CDC.

Company History

Microway was founded in 1982 to help scientists and



667MHz Alpha 21264 Daughtercard




**Dual Alpha
21264DP
Motherboard**

using 21264 dual Alpha motherboards, UP2000 dual motherboards, 21164-LX single Alpha motherboards, or Pentium processors for all price points.

Our expertise in parallel processing dates back to the mid-80s when we were Immos's largest customer for

Microway is known for giving excellent service. When you call us, you talk to a competent person. Because we appreciate the critical nature of your work, every one of our products comes with free tech support for two years. Our legendary tech support makes it possible for us to configure

Microway 24 Node Linux Beowulf Cluster




Bushing-Mounted Drag Chain

A drag chain can be wrapped to a smaller radius than was previously possible.

Lyndon B. Johnson Space Center, Houston, Texas

The figure illustrates a chair-base mechanism with a bushing-mounted drag chain. The bushing-mount design provides for one end of the drag chain to be free to pivot; this provision makes it possible to wrap the drag chain to a radius smaller than that achievable in mechanisms previously designed for the same purpose. The utility of mechanisms like this one lies in applications in which rotation of machinery involves significant turning radii, so that bending of cables that run through drag chains involve relatively tight arcs.

The bushing-mounted drag chain contains cables and wires for actuating controls on a mechanical chair that can be rotated through 280° by use of the chair-base mechanism. In addition to being bushing-mounted, the drag chain is bearing-mounted on the upper bearing block; because of this, the bend radius of the chain varies with rotation of the chair in such a way as to maintain an overall compact system. This design feature reduces the amount of external floor space needed for a given length of drag chain and limits the overall length of the drag chain.



The **Chair-Base Mechanism** is connected to a drag chain via a bushing mount that reduces the amount of space needed to accommodate the drag chain.

The chair-base mechanism with the bushing-mounted drag chain is in use at the Dexterous Robotics Laboratory at Johnson Space Center. The potential of this mechanism has not yet been fully realized; future applications could occur in Hurco (or equivalent) drill presses,

any similar rotating machinery in which drag chains are employed, and mechanisms for rotating gantry assemblies or other machinery.

This work was done by Myron A. Diftler of Lockheed Martin Corp. for Johnson Space Center. No further documentation is available. MSC-22732


RECORDING HEADS MAGNETIC SHIELDING MAGNETIC LEVITATION MAGNETRONS SWITCHGEARS MICROELECTROMECHANICAL SYSTEMS

INSULATORS TRANSFORMERS MRI LOUDSPEAKERS SOLENOIDS RELAYS MAGNETIC CIRCUITS MAGNETIC

(MEMS) ACCELEROMETERS ANTENNAS GENERATORS NON-DESTRUCTIVE TESTING COILS MAGNETIC

www.integrated.ca

SITE OF THE WORLD'S FINEST
ELECTROMAGNETIC SIMULATION
SOFTWARE



INTEGRATED
ENGINEERING SOFTWARE

204-632-5636

BEARINGS MAGNETIZING FIXTURES CHARGED PARTICLE AND BEAM ANALYSIS ACTUATORS MOTORS VCM'S SENSORS CRT'S HIGH VOLTAGE

You've got one chance to get it all.

**WHY RISK IT
ON ANYTHING LESS
THAN A SONY?**

SIR-1000W/SIR-1000i

Wideband Digital Data Recorder
/ICP® - video/analog/digital data

Sony digital data recorders give you incredible performance and superior reliability in lightweight, compact configurations that fit almost anywhere.

Our SIR-1000 series captures critical analog and digital data (or analog and synchronized video data with our optional video card) at speeds up to 160kHz and 24 Mb/sec for as long as 2 full hours (32 hours max. at lower bandwidths). Utilizing the Advanced Intelligent Tape standard, they can store up to 25 Gbytes (non-compressed) on a single AIT cartridge.

For situations demanding lower bandwidth, but equally rugged performance and reliability, Sony provides the PC200AX series.

These portable, DAT-based digital data recorders have bandwidth from DC to 20kHz, can be configured up to 128 channels, and allow recording times up to 6 hours.

Compact Size:

13.4" wide,
10.2" deep, 4.5" high

And with their easy-to-use WindowsNT®-based software, Sony digital data recorders make your data as

easy to analyze as it is to record.

So, if you only have one chance to get it right, get the digital data recorder that won't let you down. Call us at 1-949-770-8400, or visit us at www.sonypt.com.

ICP is a registered trademark of
PCB Piezotronics, Inc.

For More Information Circle No. 527



Improved Urine Preservative

This solution combines antibacterial and antioxidant properties.

Lyndon B. Johnson Space Center, Houston, Texas

An improved solution for preserving samples of urine has been formulated. This solution preserves a much broader spectrum of analytes in urine than do other urine-preservative solutions heretofore in use by NASA, and is safe for use by humans. When this solution is used, (1) refrigeration of urine samples is not necessary for preserving them and (2) the solution does not alter the pH values of the samples — two important considerations for collecting and storing urine samples in outer space. By eliminating the need to ship frozen samples, this preservative will enable the collection of urine samples — not only in outer space but also in terrestrial remote settings where it was previously not feasible.

Limits on overall available space and power aboard spacecraft include severe limits on available space for storing frozen biological fluids. Researchers at Johnson Space Center hoped to identify a way of preserving urine analytes at ambient temperature for long times to lessen the effects of these limits on biomedical research and monitoring of crew health. What they formulated is the present urine preservative, called "CPG," which is a solution that comprises equal parts of chlorhexidine gluconate and n-propyl gallate. CPG eliminates or reduces the primary causes of destruction of analytes in urine; these causes are bacterial contamination and oxidation. CPG does this without altering the pH of the urine. These characteristics make CPG an excellent candidate for use not only in outer space but also in the commercial medical field on Earth.

Chlorhexidine gluconate is a water-soluble, bactericidal compound used commercially as a topical anti-infective agent. N-propyl gallate, a commercial food additive, is an antioxidant. The Food and Drug Administration has ruled that both compounds are safe for use by humans at the concentrations necessary to maintain the integrity of urine samples.

To make CPG, one first prepares 20-percent solutions of n-propyl gallate and chlorhexidine gluconate, then mixes these solutions in equal parts. The resulting CPG solution is placed into aliquot tubes to yield a final concentration of 0.4 milligram of CPG per milliliter of urine.

Researchers tested CPG with 17 urine analytes during 12 months, using two separate pooled samples. Unpreserved aliquots from each pool were

stored at a temperature of -70°C as baseline samples. Both preserved and unpreserved aliquots from each pool were also stored at room temperature. Analytes were measured on days 1, 14, and 28 for the first month and then once a month for the next 11 months. The table gives the results of this study. The bold text within the table indicates the instances in which CPG provided extended room-temperature stability.

This work was done by Scott Smith of Johnson Space Center and Jeannie Nillen of Krug Life Sciences, Inc.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Johnson Space Center, (281) 483-4871. Refer to MSC-22695.

| Analyte or Property | Duration of Stability (Compared to That of Unpreserved Urine Stored at -70°C) | |
|-----------------------------------|--|-------------------------------------|
| | Room Temperature | Room Temperature (Preserved by CPG) |
| Urea | 28 days | 12 months |
| Ammonia | Unstable | 14 days |
| Calcium | Unstable | 3 months |
| Creatinine | Unstable | Unstable |
| Sodium | 7 months | 5 months |
| Potassium | 3 months | 7 months |
| Chloride | 4 months | 4 months |
| Osmolality | Unstable | Unstable |
| 3-Methylhistidine | 6 months | 3 months |
| Aldosterone | Unstable | 14 days |
| Cortisol | Unstable | 2 months |
| Cyclic Guanosine-5'-Monophosphate | Unstable | 7 months |
| Melatonin | 5 months | 8 months |
| Total Nitrogen | 2 months | 3 months |

Preliminary Data indicate that CPG preserves a number of urine analytes during prolonged storage at room temperature.

Noninvasive Determination of Pressure in Cerebrospinal Fluid

Spinal taps would no longer be necessary.

NASA's Jet Propulsion Laboratory, Pasadena, California

A technique for noninvasive determination of the pressure in the cerebrospinal fluid (CSF) has been proposed. This technique would involve two main steps: First, an optical coherence tomographic scanner would be aimed into an eye and used to image the optical disk (see figure). Next, the resulting tomographic imagery would be digitized and processed to determine the thickness of the neural fiber layer, which thickness is known to increase with the CSF pressure.


Heretofore, the spinal tap has been the standard technique for measuring the CSF pressure (also known as the intracranial pressure or "ICP"). Spinal taps are painful, dangerous, and expensive. The proposed technique could make it unnecessary to perform spinal taps.

Papilledema — swelling of the optic-nerve axons in the optic disk — is known from previous studies to be associated with an increase in the intracranial pressure beyond the normal limit of approximately 14 mm of Hg (about 1.9 kPa). The neural fiber layer can swell to as much as 20 times its normal thickness within hours after the onset of elevated intracranial pressure.

Papilledema can be seen through an ophthalmoscope. Stereoscopic fundus photography and optic-nerve-head analysis also reveal aspects of papilledema. The common limitation of these previously developed optical techniques is that they depend on changes in surface topography. The proposed version of optical coherence tomography would measure the thickness of the neural fiber layer regardless of changes in surface topography, and should be capable of revealing swelling of axons earlier than do the previously developed optical techniques.

By use of a previously constructed optical coherence tomographic scanner, it has been found that the thickness of the neural fiber layer in normal individuals varies by no more than 3 μ m. This instrument has also been found capable of revealing early thinning of the neural fiber layer associated with glaucoma. Thus, it has been reasoned, it should be possible to use optical coherence tomography to measure early neural-fiber-layer swelling associated with intracranial hypertension. If the instrument could be modified to achieve a tenfold refinement of its resolution, then the instrument would be correspondingly more sensitive as an indicator of intracranial pressure. The modified instrument could be used in research on the sequence of events in papilledema because it could also provide information on deep and surface changes in the optic disk, flows of blood in veins and arteries, and shifts in the spectral reflectance of the optic disk.

This work was done by Mark S. Borchert and James L. Lambert of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasa.gov under the Bio-Medical category. NPO-20079



The Optic Disk (known popularly as the "blind spot") is the spot where the fibers of the optic nerve leave the eye. The thickness of the neural fiber layer in the optic disk increases with the intracranial pressure. According to the proposal, this thickness would be determined optically to obtain an indirect indication of the intracranial pressure.

EMI/RFI SHIELDING

Accommodates All Electronic Enclosures

Quick Adhesive Or Clip-on Installation

Superior performance shielding gaskets
Electronic grade plating finishes
Many base metal variations
Hundreds of shapes & sizes
Custom modifications

Medical Diagnostics Telecommunications Computers
Aerospace/Military Instrumentation Electronic Enclosures

OMEGA SHIELDING
PRODUCTS

9 Emery Ave., Randolph, NJ 07869
tel: 973-366-0080 fax: 973-366-8232
E-mail: sales@omegashielding.com
web site: <http://www.omegashielding.com>
ISO 9002 Quality System Certified

For More Information Circle No. 424

Our Servers & Workstations are Going Places

Desktop workstation and server power has never been so portable or so rugged with industrial portables from BSI. With a combination of multi-slot, multi-drive bay design, a large flat panel display and dual Pentium III processor performance, our portables provide you with full-featured servers and workstations wherever your application takes you.

BSI
Broadax Systems, Inc.
1-800-872-4547
www.bsicomputer.com



Primers for Amplifying CMV DNA in Body Fluids and Tissue

A novel set of primers enables high-volume, rapid, inexpensive viral diagnostic testing.

Lyndon B. Johnson Space Center, Houston, Texas

A novel set of primers has been developed for use in a polymerase chain reaction (PCR) to amplify the deoxyribonucleic acid (DNA) of cytomegalovirus (CMV). The purpose of this development is to enable faster, more sensitive detection of CMV virus infecting body fluids and tissues.

Each year, in the United States, an estimated 40,000 infants are infected con-

genitally with CMV, which is a member of the herpesvirus family. CMV is the most common congenital viral infection in humans, and it is the leading infectious cause of mental retardation and nonhereditary sensorineural deafness. Studies show that CMV can survive from 2 to 48 hours in saliva and on environmental surfaces. Healthy adults usually experience unrecognized mild infec-

tions of this latent virus. For spaceflight crews, the pre-spaceflight quarantine period does not lessen the infectious-disease risks associated with latent viruses. Resulting viral illnesses can seriously affect the health of a crew.

The tissue-culture methods used heretofore for detecting CMV infections are labor-intensive, are subject to variability among technicians, lack sensitivity and specificity, and are time-consuming (taking 4 to 21 days in each case). The present PCR method with the novel primers overcomes these deficiencies of tissue-culture methods. The first primer — the sense strand — is a 21-base-pair oligonucleotide; the second primer — the antisense strand — is an 18-base-pair oligonucleotide. The use of these primers makes it possible to detect CMV infections directly from specimens of urine, saliva, blood, cerebrospinal fluid, and feces. These primers and the PCR method satisfy requirements with respect to preparation of specimens, sensitivity relative to traditional methods, and clinical significance of results. Applications also include detection of relapse of infection and testing the effectiveness of the antiviral therapy.

The development of this set of primers to amplify viral DNA by PCR offers a rapid, high-volume, and less expensive means (relative to tissue-culture methods) of viral diagnostic testing. Patients who have AIDS or cancer, transplant recipients, and others who are susceptible to CMV infections would receive the most benefit from this method of rapid detection.

This work was done by Duane L. Pierson of Johnson Space Center and Raymond P. Stowe of KRUG Life Sciences, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Bio-Medical category.

Title to this invention has been waived under the provisions of the National Aeronautics and Space Act (42 U.S.C. 2457(f)), to KRUG Life Sciences, Inc. Inquiries concerning licenses for its commercial development should be addressed to

*Raymond P. Stowe
KRUG Life Sciences, Inc.
1290 Hercules Drive
Suite 120
Houston, TX 77058
(281) 212-1200*

Refer to MSC-22694, volume and number of this NASA Tech Briefs issue, and the page number.



Pressure controls made your way!

For over 35 years, Tescom has provided a diverse range of quality pressure control solutions that meet or exceed customer expectations. Whether it's one of our 60+ standard models, a simple modification or a one-of-a-kind custom control, we'll build a regulator, valve or system that meets your unique requirements.

Control styles: pressure reducing and back pressure, hydraulic or pneumatic, electronic, miniature, cartridge, tracking, vaporizing, vacuum or changeover.

Choices: loading and sensing styles, venting options, materials of construction, seals, porting configurations and more. Pressure ranges: vacuum to 20,000 PSIG. Flow: $C_v = 0.00005$ to 8.0.

Our application specialists will find or create a control solution for you. Give them a call.

TESCOM
CORPORATION

INDUSTRIAL CONTROLS DIVISION

ISO 9001 Quality System Certified

MITI/KHK Product Certification

12616 Industrial Blvd., Elk River, MN 55330 800 447-9643 www.tescom.com



GFSSP — Program for Analyzing Flows in a Complex Network

Marshall Space Flight Center, Alabama

The Generalized Fluid System Simulation Program (GFSSP) version 2.01 is a general-purpose computer program for analyzing steady-state and time-dependent flowrates, pressures, temperatures, and concentrations in a complex flow network. The program is capable of modeling phase changes, compressibility, mixture thermodynamics, and external body forces, such as gravity and centrifugal.

The program contains subroutines for computing "real fluid" thermodynamic and thermophysical properties for 12 fluids. The fluids are helium, methane, neon, nitrogen, carbon monoxide, oxygen, argon, carbon dioxide, fluorine, hydrogen, water, and kerosene (rocket propellant 1). The program also provides the options of using any incompressible fluid with constant density and viscosity.

Seventeen different resistance/source options are provided for modeling momentum sources or sinks in the branches. These options include: pipe flow, flow through a restriction, noncircular duct, pipe flow with entrance and/or exit losses, thin sharp orifice, thick orifice, square edge reduction, square edge expansion, rotating annular duct, rotating radial duct, labyrinth seal, parallel plates, common fittings and valves, pump characteristics, pump power, valve with a given loss coefficient, and a Joule-Thompson device.

GFSSP employs a finite volume formation of mass, momentum, and energy conservation equations in conjunction with the thermodynamic equations of state for real fluids. Mass, energy, and specie conservation equations are solved at the nodes; the momentum conservation equations are solved in the branches. The system of equations describing the fluid network is solved by a hybrid numerical method that is a combination of the Newton-Raphson and successive substitution methods.

The computer program has three major parts. The first part consists of the subroutines for the preprocessor. The preprocessor allows the user to interactively create the flow network

model consisting of nodes and branches. All of the input specifications, including the boundary conditions are specified through the preprocessor. The second major part of the program consists of the subroutines that provide the initial conditions and then develop and solve all of the conservation equations in the flow network. The third part of the program consists of the thermodynamic-property programs that provide the necessary thermodynamic- and thermophysical-property data required to solve the resulting system of equations.

GFSSP has been developed, tested, and documented by Sverdrup Technology for Marshall Space Flight Center (MSFC). GFSSP is currently being used at MSFC, and its predictions showed good agreement when compared with test data. GFSSP runs on an IBM-


PC compatible computer under Windows 95 and Windows NT and under UNIX operating systems.

This program was written by Alok Kumar Majumdar, John W. Bailey, Paul Alen Schallhorn, and Todd E. Steadman of Sverdrup Technology for Marshall Space Flight Center. NASA seeks companies interested in licensing this technology to make it available as a commercial product or for their own use. Licensing inquiries should be directed to Larry Gagliano, MSFC Software Release Authority at (256) 544-7175 or larry.gagliano@msfc.nasa.gov.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Marshall Space Flight Center; (256) 544-0021. Refer to MFS-31303.

THE G-LOGGER™ PORTABLE VIBRATION AND SHOCK DATA ACQUISITION SYSTEM

- Battery Powered for up to 3 Weeks
- Tri-Axial Accelerometers
- 8 Mbytes Non-Volatile Memory
- Simple PC-based Mission Setup and Data Analysis
- Automatic Tracking Anti-Aliasing Filters
- Periodic or Triggered Event Recording
- User-Selectable Data Rates and Types
 - . 1 to 4000 samples per second
 - . AC and DC Acceleration
 - . AC and DC Peak Acceleration
 - . Peak Acceleration Events
 - . RMS Acceleration
 - . AC Velocity and Peak Velocity
 - . RMS AC Velocity
 - . Temperature



Portable data acquisition system with three accelerometers. Ideal for recording transportation shock, vibration and tilt, aircraft flight testing, unattended machinery monitoring, and automotive environmental testing.



SILICON DESIGNS, INC.

1445 NW Mall Street
Issaquah, WA 98027

Phone: 425-391-8329
FAX: 425-391-0446

Visit our home page at www.silicondesigns.com

Telemetry "Toaster"



- Web/Java interface
- Serial: 6 channels, 10 Mb/s
- Analog: 64 channels, 200 KHz
- No programming necessary
- Supports all signal formats

Ethernet/Internet Telemetry from \$5495

NetAcquire™ publishes any type of serial or analog telemetry signal to your network. Its unique Web-based user interface makes setup a snap in any environment.

With over twenty features designed specially for telemetry handling, NetAcquire can help solve your gateway challenges without expensive custom solutions. Its extensible software and hardware environment supports hundreds of measurement and communications configurations.

Call Toll Free 888.675.1122 or 425.576.0822
Internet: info@realtimeint.com
<http://www.realtimeint.com>



For More Information Circle No. 427

Paroscientific, Inc. DigiQuartz® Pressure Instrumentation

Features:

- 0.01% Accuracy
- 1×10^{-8} Resolution
- Digital Output Signal
- Environmentally Rugged
- High Reliability & Stability
- ISO 9001 Quality System
- 5 Year Extended Warranty

Products:

- Barometers
- Transducers
- Transmitters
- Depth Sensors
- Portable Standards
- Fiber-Optic Systems
- Water Stage Sensors
- Meteorological Systems

4500 148th N.E., Redmond, WA 98052


Tel: (425) 883-8700 Fax: (425) 867-5407
Internet: <http://www.paroscientific.com>

Temperature Correction for Pressure-Sensitive Paint

One can extract pressure data from partially-temperature-dependent luminescence data.

John H. Glenn Research Center, Cleveland, Ohio

A temperature correction has been developed to enable the extraction of pressure images and corresponding pressure data from images of photoluminescence of pressure-sensitive paints (PSPs). These paints are used on wind-tunnel models for mapping surface pressures associated with supersonic flow fields. PSP has been successfully used in wind-tunnel test ranging from 60 mi/h (97 km/h) to the supersonic range >3 . The photoluminescence of an ideal PSP would depend on pressure only, but the photoluminescence of a real PSP depends on temperature also. In order to extract a pressure image, one must be able to invert the luminescence-image data on the basis, not only of the pressure dependence but also of the temperature dependence and of the distribution



A Family of Calibration Curves clearly depicts the effect of temperature. The temperature correction collapses the family of curves to a single curve, so that it suffices to perform the pressure calibration at one temperature only.

of temperature on the painted surface; in other words, one needs to incorporate a temperature correction into the pressure calibration of the luminescence of the paint.

A PSP contains luminophores (basically, dye molecules), that luminesce in a suitable wavelength range in response to photoexcitation in a shorter wavelength range. The photoluminescence is quenched by oxygen at a rate proportional to the partial pressure of oxygen and thus proportional to the pressure of air. As a result, the intensity of photoluminescence varies inversely with the pressure of air, and the basic equation for calibrating a photoluminescence image is the following:

$$P/P_{REF} = A + BI_{REF}/I,$$

where P is the unknown pressure that one seeks to determine under the test condition (e.g., in the presence of wind), P_{REF} is the pressure under a reference condition (e.g., in the absence of wind), I_{REF} is the intensity of luminescence under the reference condition, and I is the intensity of luminescence under the test condition. The need for temperature correction arises because A and B depend on temperature.

The temperature correction is based on the experimental observation that in the above equation for P/P_{REF} , the combined effects of pressure and temperature can be expressed by use of a corrected intensity ratio; that is,

$$P/P_{REF} = A + B[I_{REF}/I]_{CORR}$$

The corrected intensity ratio is given by

$$[I_{REF}/I]_{CORR} = (I_{REF}/I)(CT^2 + DT + E),$$

where T is the absolute temperature and C , D , and E are constants obtained via a least-squares best fit to calibration data acquired by use of a PSP test rig. Alternatively, calibrations usually use a combination of PSP calibration cell data and conventional pressure taps. The taps are used as truth points to help set an absolute level since this is a delta (change) pressure measurement and the largest error is typically the absolute pressure level. The figure presents calibration plots for a PSP, as they appear before and after the application of the temperature correction.

Of course, in order to be able to apply the temperature correction to PSP images of a model in a wind-tunnel test, one must know the temperature distribution on the model during the test. A temperature image can be ac-

quired by coating the model with a temperature-sensitive paint (TSP) and testing it under the same conditions as those used when it is coated with PSP. Alternatively, this can help for a uniform temperature change but does not help for correcting for temperature gradients on the test article. Large temperature gradients exist on thermally conductive models that need full field temperature measurements to fully compensate for the temperature sensitivity of PSP.

This work was done by Timothy J. Bencic of Glenn Research Center. For

further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.


Inquiries concerning rights for the commercial use of this invention should be addressed to:

NASA Glenn Research Center
Commercial Technology Office
Attn: Steve Fedor
Mail Stop 4-8
21000 Brookpark Road
Cleveland, Ohio 44135.

Refer to LEW-16915.

T H E E V A N S

Hybrid® Capattery® MegaCap®



Smaller, lighter, and more powerful capacitors.

EVANS

The Evans Capacitor Company
P. O. Box 14158
East Providence, RI
02914-0158
(401) 434-5600
Fax (401) 434-6908

The Evans Hybrid® is an electrochemical-electrolytic capacitor with incredible properties:

- As little as 1/10 vol. of aluminum electrolytics
- 1/2 the weight of aluminum electrolytics

In two design styles, a hermetic tantalum package and a polypropylene package, Evans Hybrids are excellent for avionics, power supplies, power filtering, communications, weapons systems, medical applications, auto auxiliary systems and many very special uses. 3-125v, <.5 F•V, 20-100g, 5-15cc.

The **MegaCap®** is a newly developed aqueous carbon electrochemical capacitor with capacitance up to 100 F, low resistance (RC=0.6) and currents over 500 amps.

The **Capattery®**, a high reliability aqueous carbon electrochemical capacitor, has 10 years field experience without a failure. Up to 1.5 F, -55°C to +85°C, and 5.5 or 11v. Custom ratings and shock-hardened Capatteries are available.

www.evanscap.com

For More Information Circle No. 429



Further Developments in Web Interactive Training

Displays, simulations, and quizzes are customized for each trainee.

John F. Kennedy Space Center, Florida

Three innovative computer programs for training and testing personnel at Kennedy Space Center have been developed under the aegis of the Web Interactive Training (WIT) project. The WIT project exploits the capabilities afforded by the Internet and by state-of-the-art multimedia data-presentation techniques. The World Wide Web is used to deliver training from server computers to client desktop computers on demand. Training can involve multimedia data of various types (text, audio, graphics, and animated video images). Training can be interactive, enabling trainees to tailor lessons to their individual needs; a trainee can select a lesson or segment any time, anywhere, and can repeat a segment as many times as necessary. In-

teractivity can also be exploited to provide for testing and recording of a trainee's progress.

One of the innovative programs provides a simulation of the International Organization for Standardization (ISO) 9000 certification process. By use of standard Hypertext Markup Language (HTML) pages and forms, the program creates an interactive system for ISO 9000 training. The client-side requirements for using the system are minimal; any popular Web-browser software can be used.

Each time the simulation is run, the events are slightly different. That is to say, the HTML pages are not static like ordinary Web pages; they are generated dynamically to create a more realistic


representation of the simulated process.

The code on the server is highly object-oriented. The system can be expanded and new functionality can be added without disrupting the system. The user-interface part of the program is separate from the application part of the program; because of this architecture, new user interfaces can be created without modification of the main application code. Similarly, rules of a simulation can be changed without affecting the user interface.

Another of the innovative programs generates tests that are integral parts of a training course on techniques of non-destructive evaluation. The course is presented to each trainee in modules. Each module includes (1) a video

NEW FOR 2000

A Fusion of Forces.

With Industrial Strength  Numerics

Harness the power of the two most impressive forces in technical computing — Maple intelligent symbolic computation, and NAG industrial-strength solvers. Maple 6, the newest version of the most respected and trusted integrated technical computation system, delivers the combined power and flexibility of these revolutionary technologies in a single, easy-to-use, tightly integrated system.

Complementing the unrivalled math engine is a suite of new productivity features, including seamless connectivity to Microsoft® Excel 2000, enhanced matrix computation, and a new generation of programming facilities. Maple 6 delivers the most cost-effective productivity platform for managing all of the mathematical information in modern engineering, science, mathematics, and application development.

Practical fusion is now a reality. Contact Waterloo Maple for information on how soon you can access the most significant new product in the history of technical computation.

To order in North America

1/800-267-6583

Outside of North America, call (519) 747-2373
or visit www.maplesoft.com for a local distributor



maple 6
Performance Innovation

Waterloo Maple
ADVANCING MATHEMATICS

© 2000 Waterloo Maple Inc. Maple is a registered trademark of Waterloo Maple Inc.
All other trademarks are property of their respective owners.

overview of a technique in action, (2) text and graphics that explain the theory and application, (3) an interactive simulation of an application of the technique (generated by the program described in the next paragraph), and (4) a quiz generated by random selection of questions from a data base of questions. Immediately after submitting answers, the trainee is presented with the test score, a brief explanation of the correct answers, and a link to the place in the course where the topic was covered. It is more difficult for a student to cheat because the program generates a different version of the quiz for each student and makes it impossible for any given student to take the same version of the quiz twice.

Still another innovative program is the one that generates the interactive simulations in the training modules. Each simulation is designed to give practice in one of a number of nondestructive testing processes: visual inspection, liquid-penetrant testing, magnetic-particle testing, eddy-current testing, leak testing, ultrasonic testing, or radiography. The simulations incorporate learning by example, repetition, and positive feedback. For example, in a simulation of the use of computed x-ray tomography of a solid cylinder, the student moves a scanner head along the cylinder while observing the scan on a simulated computer screen. Upon identifying a potential discontinuity, the trainee clicks on it; if the identification is correct, the simulation is immediately reset with the discontinuity scattered randomly to one or more different position(s). The trainee can repeat the simulation as many times as needed.

The advanced technology features of the WIT project contributed to the project winning a Gold Award in the 1997 multimedia and Internet Training Awards.

This work was done by Roger Wright, Thomas Brubaker, Angela Smibert, David Metcalf, and Tracy Bierman formerly of I-NET, Inc., for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category or visit the WIT Web site at <http://wit.hsc.nasa.gov>.





Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Programs and Commercialization Office, Kennedy Space Center, (407) 867-6373, or for information regarding commercialization of this technology contact: Merrimac Interactive Media Corporation, 200 Willard, Suite 1A, Coca, FL, 32922, telephone: (407) 638-4118. Refer to KSC-11962.

imaging@work

Slow the motion Show the motion

Encore PCI High-Speed Video

Pinpoint and solve high-speed equipment problems by digitally recording split-second events. Variable-speed, slow-motion, instant replay shows you exactly what takes place. Digitally record events with multiple cameras simultaneously. Store the images on PCs. Measure speed, distance, acceleration, displacement and elapsed time.



Call 1-800-446-5260

fax 516-844-5620

e-mail info@olympusipg.com

www.olympusipg.com

**OLYMPUS
INDUSTRIAL**

CRYOGENIC ADHESIVES

Designed To Your Specifications

MASTER BOND EP29LPSP EPOXY

- Two-part system ■ Convenient mix ratio ■ Flexible cure schedules
- Service down to liquid helium temperatures
- Outstanding thermal shock resistance
- Superior dimensional stability ■ Convenient packaging

www.masterbond.com



For information, call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983

Master Bond Inc.
Adhesives, Sealants & Coatings

For More Information Circle No. 430

Developmental Software for Exploiting Hyperspectral Imagery

Evolutionary computing techniques are used.

American GNC Corporation, Chatsworth, CA

A unique state-of-the-art process for exploiting hyperspectral satellite imagery, based on evolutionary computing methods, has been developed and a proof-of-concept demonstration has been conducted. This development is projected to lead to several important commercial products, including a fully integrated, high-payoff, user-friendly software package — the Integrated Hyperspectral Imagery Analysis Toolbox. This software would be capable of end-to-end processing of industrial and governmental hyperspectral satellite image data with extensions to several popular commercial software products like ENVI from Research Systems, Inc., and ESRI's ArcView Geographical Information System. The development of the end product will focus on accurate detection and identification of natural and artificial materials and objects, the use of large libraries of laboratory reference data, and ease of use. Potential commercial applications include assessment of crops (including estimation of crop yields), exploration for minerals and oil, planning of military missions and automated identification of military targets, urban planning, environmental assessment, and search-and-rescue operations.

The process effected by the proof-of-concept version of the software is the following: A spectral band signature is extracted from a hyperspectral satellite image and filtered to remove noise. It is then normalized to remove global gain differences. Next, an artificial neural network identifies those categories of objects and materials that correlate with the sensed data. The categories are expressed as orthonormal feature vectors derived from training signatures that were preprocessed in a manner similar to that of the sensed data. Finally, an evolutionary algorithm processes the output of the artificial neural network, detects the relevant materials, and estimates the amounts of the materials.

A computer program that performs an end-to-end computational simulation of the process has been developed. This program is capable of accepting real hyperspectral image data, performing the requisite processing on the data, and providing a graphical display of the results. The ENVI software, which provides a computational environment for rapid prototyping of other software, was used to facilitate the development of the simulation program. In the simulation, high performance in detecting and identifying materials in the terrain, including materials with spectrally mixed signatures, was demonstrated. Terrain-classification maps were generated, illustrating how signature variations can be handled, given terrain variations. Also demonstrated was an excellent capability to discriminate between strongly similar, but different, types of vegetation.

Further efforts are planned to accomplish the following:

- Development and execution of a data-collection plan (which would include the collection of ground-truth data) involving commercial and governmental sensors.
- Extension of public-domain atmospheric-compensation methods to include terrain topography.
- Updating of algorithms for improved performance against mixed spectral signatures, including signatures of unknown materials.

This work has been and will be undertaken by the American GNC Corporation, 9131 Mason Avenue, Chatsworth, CA 91311, an SBA 8(a) certified Small Disadvantaged Business concern, as part of a NASA Small Business Innovation Research (SBIR) project monitored



Air Gap

Large air gaps with a low cost ferrous proximity sensor* using reed technology. Available in custom designs. Call, fax or e-mail today for more information.

* patent pending

Power Components
OF MIDWEST, INC.

56641 TWIN BRANCH DRIVE • MISHAWAKA, IN 46545
FAX (219) 256-6643 • E-MAIL TWebster@pcmidwest.com

(800) 221-9257

by Stennis Space Center. The NASA SBIR Contract Number is NAS13-98208; Topic: 97-1 14.06; Topic Title: Measurement and Enhancement of Satellite Scientific Data Quality and Applicability. For further information, contact Dr. Ching-Fang Lin, American GNC Corporation, at tel: (818) 407-0092, fax: (818) 407-0093, or e-mail: cflin@americangnc.com. SBIR0007

2 Expert System To Develop Job Standards

John F. Kennedy Space Center, Florida

The Job Standards Development System is a user-friendly expert system that (1) helps users select an appropriate work measurement methodology to develop job standards (or the less formal job time estimates) and (2) leads the users through the steps necessary to use a work time estimating technique to develop job standards for long-duration, low-repetition work. The computer program comprises three parts, the first being a system-administration subprogram, in which an administrator sets values of parameters that are not changeable by a job standards developer. The second part is a subprogram that assists the job standards developer in the selection of an appropriate work measurement technique. The third part supports the application of a work time and resource requirement estimating technique that relies on domain expertise to describe human work, collects work time and resource requirement data from the domain expert, and computes a job standard. The program is expected to be useful for the management of organizations devoted to performing functions consisting of long-duration, low-repetition work. Illustrations of this type include facility and equipment maintenance and the knowledge work of service firms and federal, state, and local governments. The program is written for use with the Windows operating systems on IBM PC and compatible computers.

This work was done by Neal F. Schmeidler and John D'Avanzo of OMNI Engineering & Technology, Inc., for Kennedy Space Center.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to: Neal Schmeidler, OMNI Engineering & Technology, 7921 Branch Drive, Suite 530, McLean, VA 22102. Telephone No: (703) 827-8976. Web site: www.omni-engineering.com

Refer to KSC-12072, volume and number of this NASA Tech Briefs issue, and the page number.

POSITION + PRESSURE SENSORS FOR EXTREME HEAT + COLD

RUGGED + RELIABLE

- Laser-welded hermetic construction using nickel chrome alloy materials
- Continuous operation from -320°F to +1000°F (+1200°F short term)

POSITION SENSORS

- Environments up to 5000 psi
- Excellent linearity

PRESSURE SENSORS

- Static + high-frequency dynamic
- Ranges from 5 to 5000 psi
- Absolute, gauge or differential

800-552-6267

www.kamaninstrumentation.com

KAMAN

Nuclear Reactors
Rocket Engines
Steam/Gas Turbines
Cryogenic Testing
High-Radiation + Corrosives

+1200°F

-320°F

For More Information Circle No. 433

This logger has the battery life to last To Mars and back! ... and then some!

ACR SmartReader Plus 7 features:

- ▶ 7 voltage and current channels
- ▶ +/-0.5% FS accuracy
- ▶ Up to 1.5 MB memory
- ▶ 12-bit resolution
- ▶ Sample rates as fast as 25 readings per second
- ▶ Weighs less than 4 oz
- ▶ 10-year battery life (guaranteed)
- ▶ Free technical support on our 800 number
- ▶ 3-year warranty
- ▶ Year 2000 compliant



Downloading information is simple: Connect an ACR interface cable to the logger and the Com port of a PC and run the ACR software. View data graphically or statistically. Loggers are accessible remotely by modem and can be networked.



Without data, it's just an opinion

For more information on the complete ACR family of data logging instruments, please contact us. Telephone: 604.591.1128 • Toll free (CDA & USA): 1.800.663.7845
Fax: 604.591.2252 • Web: www.acrsystems.com • E-mail: acr@acrsystems.com
Bldg 210 - 12960 84th Avenue Surrey BC V3W 1K7 Canada

Dealer enquiries welcome!

1698/A

Marketplace

To Advertise —
Call (212) 490-3999

Gapman

ELECTRONIC GAP GAGE

- Assembled parts
- Extruders
- Coaters
- Laminating presses
- Composite structures
- Automotive alignments
- Printing press roller gaps
- Plastic injection molds, cold gap clearances




Capacitec

tel: 978.772.6033 fax: 978.772.6036

For More Information Circle No. 590

POSITIONING SLIDES AND X-Y TABLES

Modular linear and
rotary slides for
scanning and indexing



VELMEX, INC.

www.velmex.com

Fax: 716 657-6153

For your free Catalog M

Call: 800 642-6446
or 716 657-6151 in NY

For More Information Circle No. 435



Books & Reports

Update on Electrolytes for Low-Temperature Lithium Cells

A report presents results of research on carbonate-based electrolytes to improve the low-temperature-performances of lithium-ion rechargeable electrochemical cells. The loss of performance with decreasing temperature is attributable largely to a decrease of ionic conductivity and the increase in viscosity of the electrolyte. What is needed to extend the minimum operating temperature from 20 °C down to -40 °C is a stable electrolyte solution with relatively large low-temperature conductivity, relatively small low-temperature viscosity, a large electric permittivity, adequate coordination behavior, and appropriate ranges of solubilities of liquid and salt constituents.

This work was done by Marshall Smart, Ratnakumar Bugga, Chen-Kuo Huang, and Subbarao Surampudi of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Rechargeable Lithium-Ion Cells with Improved Low-Temperature Performance with Novel Carbonate-Based Electrolyte," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category. NPO-20407

Techniques for Controlling Buoyancy of Balloons on Titan

A report discusses alternative techniques for controlling the buoyancy, and thus the altitude and landings, of a balloon-borne instrumentation system that would be launched to explore the moon Titan of the planet Saturn. Some of the techniques are based on established concepts of heating or cooling gases in balloons. One technique involves the acquisition or release of gaseous ballast by compressing and liquefying atmospheric gas into a pressure vessel (or allowing the liquefied gas to vent back to the atmosphere); a similar technique involves compressing atmospheric gas into (or releasing it from) a bladder. The simplest and preferred buoyancy technique is to use con-

trolled heating of the helium balloon by means of diverting waste heat from a radioisotope thermoelectric power source.

This work was done by Jack Jones and Jay Wu of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Preliminary Study of Titan Balloon Buoyancy Techniques," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category. NPO-20656

Studies of Interaction Im- pedance in a TWT Helix

Two reports present further developments in the subject of "Computation of Characteristics of a Helical TWT Slow-Wave Circuit" (LEW-16571), NASA Tech Briefs, Vol. 22, No. 4 (April 1998), page 54. The subject is computation, by use of the MAFIA (Solution of MAXwell's Equations by the Finite-Integration-Algorithm) computer program, of the cold-test electromagnetic characteristics of the helix and surrounding structures in the slow-wave circuit of a traveling-wave tube (TWT). Special attention is given to the on-axis electron-beam/slow-wave interaction impedance, which cannot be measured directly. Heretofore, this impedance has been determined indirectly from cold-test measurement of the change in the resonance frequency resulting from the introduction of a dielectric rod on the axis.

This work was done by James A. Dayton, Jr., of Glenn Research Center and Carol L. Kory of Analox Corp. To obtain copies of the reports, "Computational Investigation of Experimental Interaction Impedance Obtained by Perturbation for Helical Traveling-Wave Tube Structures," and "Accurate Cold-Test Model of Helical TWT Slow-Wave Circuits," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16881.

www.nasatech.com

NASA Tech Briefs, January 2000



Special Coverage: Sensors

Nonintrusive Flow-Measurement System


Flow is measured ultrasonically, from outside the pipe.

John F. Kennedy Space Center, Florida

A nonintrusive flow-measurement system based on ultrasonics has been developed to replace a system based on turbine flowmeters. A turbine flowmeter must be mounted in line with a pipe; this raises the possibility of leakage at the flowmeter/pipe joints, and the flowmeter unavoidably perturbs the flow. Moreover, a turbine flowmeter is vulnerable to mechanical malfunction and can be vulnerable to corrosion or clogging, depending on the nature of the fluid. In contrast, the ultrasonic flow-measurement system does not contain any rotating or sliding mechanisms that could fail, and does not involve any penetration of the pipe, so that the flow is not perturbed and there is no risk of leakage, clogging, or corrosion.

The nonintrusive ultrasonic flow-measurement system includes two ultrasonic transducers that are clamped on the outside of a pipe, at positions upstream and downstream from each other (see figure). Each transducer serves as both a transmitter and a receiver of ultrasound. The transducers are connected to electronic signal-generating and -processing circuits and a digital data-acquisition and -processing subsystem.

The basic measurement principle is straightforward: ultrasonic signals are transmitted in both directions between the transducers. The intervals between transmission and reception (transit times) are measured for signals propagating both upstream and downstream. When the fluid in the pipe is not flowing, the transit times in both directions are equal. When the fluid is flowing, the



Transit Times of Ultrasonic Signals propagating upstream and downstream between the two transducers are measured. The flow velocity is calculated from the difference between the transit times.

upstream transit time exceeds the downstream transit time. The difference between the transit times is proportional to the flow velocity and the volumetric flow rate. Accordingly, the direction and magnitude of flow are determined by use of digital signal-processing techniques and software that utilizes the known proportionality between transit times and flow velocity for the given fluid, physical conditions, and pipe size.

Unlike turbine flowmeters, the ultrasonic transducers can be easily and quickly relocated, and can be used to measure flow rates over a wide range without loss of accuracy at high or low rates. An additional advantage afforded by the ultrasonic system is the ability to detect partial or total loss of fluid from a pipe.

This technique was employed to accurately determine hypergol oxidizer and

fuel loading during preflight space-shuttle operations. Benefits of ultrasonics include flexibility, cost-efficiency, reliability, and hazard-free hyperol operation. This technology also proved valuable in the determination of extremely low flow rates through the space-shuttle water-coolant-loop floodlight cold plate used for cooling the crew compartment.

This work was done by Rudy J. Werlink of Kennedy Space Center and Ravi N. Margasahayam formerly of I-NET, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Programs and Commercialization Office, Kennedy Space Center, (407) 867-6373. Refer to KSC-11926.

High-Temperature Pressure Sensors Made From Silicon Carbide

Working temperatures range up to 500 °C.

John H. Glenn Research Center, Cleveland, Ohio

Pressure sensors that contain thin diaphragms made from the 6H polytype of silicon carbide (6H-SiC) have been developed. These are prototypes of pressure sensors for use at high tempera-

tures in engines, power plants, material-processing systems, and numerous other applications.

The wide band gap (3.0 V), high breakdown electric field (2.5 MV/cm),

and high electron saturation speed (2×10^7 cm/s) of 6H-SiC make it a superior candidate material for high-temperature electronic devices. In addition, SiC exhibits excellent thermal and mechanical

properties at high temperatures and large coefficients of piezoresistance — a combination of properties that makes this material suitable for high-temperature electromechanical sensors.

The prototype SiC pressure sensors were batch-fabricated by micromachining and demonstrated to work at temperatures from room temperature up to 500 °C. The 6H-SiC starting material (i.e., wafers) have micropipes in them. The processing conditions applied in this work plugged the micropipes, thereby making the 6H-SiC material useable.

The SiC pressure sensors offer the following five major advantages in addition to those mentioned above:

1. Junction leakage, which renders silicon semiconductor devices inopera-

tive at high temperatures, is insignificant because of the wide band gap of 6H-SiC.

2. The low hole mobility [$50 \text{ cm}^2/(\text{V}\cdot\text{s})$] of a lightly-p-doped diaphragm makes the diaphragm highly resistive to planar electric current.

3. Because the results of bulk micromachining are reproducible, batch production offers advantages of low cost, short processing time, and high yield.

4. Because of the homogeneity of bulk micromachined 6H-SiC, these pressure sensors are not subject to the adverse effects of thermal-expansion mismatches, which can be problematic in devices made from heterogeneous materials.

5. Plastic deformation of SiC is not

known to occur at the upper end of the temperature range of interest. Consequently, the diaphragms in these sensors remain effective force collectors, even at this high temperature.

This work was done by Anthony A. Ned, Anthony D. Kurtz, and Robert S. Okojie of Kulite Semiconductor Products, Inc., for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16772.

Piezoelectric Igniter/Pressure-Sensor Devices

These devices would supplant conventional spark plugs in internal-combustion engines.

John H. Glenn Research Center, Cleveland, Ohio

Piezoelectric devices that would serve as spark plugs, power generators for spark plugs, and/or pressure sensors have been proposed for use in internal-combustion engines. Unlike conventional spark plugs, these devices would function without need

for wire connections to external high-voltage sources. Also, unlike conventional spark plugs, these devices could function without need for external timing circuitry, and/or could function as parts of timing circuitry.

The most basic device of this type would be a self-timing, self-power-generating spark plug. The device would be mounted in a cylinder in an internal-combustion engine, in the manner of a conventional spark plug. The device would include a piezoelectric component with spark electrodes connected to its poles. The increase in pressure during the compression phase of the engine operating cycle would impose a strain on the piezoelectric component of the device and thereby give rise to a voltage between the electrodes. The voltage would increase with pressure until it was sufficient to cause a spark that would ignite the compressed fuel/air mixture in the cylinder. To increase the available voltage, the device could include a striker that would be driven by the increase in pressure to impinge on the piezoelectric component.

Immediately after ignition, the piezoelectric component would generate a voltage in response to the rapid increase in pressure associated with the combustion process. This voltage could be monitored to determine whether the engine is operating properly. The piezoelectrically generated voltage could also be monitored before as well as after sparking for more comprehensive monitoring of engine operation and, in particular, to detect such anomalies as pre-ignition, misfire, and knock.

The pressure-indicating piezovoltage could also be used, in conjunction with other indications of engine performance, to modify the spark timing. In a

| | | |
|--|--|--------------------------------|
| CADCommunications on any Windows PC | | ...NO CAD/CAM REQUIRED! |
| SolidView® is an easy to use, Windows program designed to communicate 2D and 3D data from virtually any CAD system. With any standard Windows PC, use CADCommunications to view, interrogate, dimension, red-line/mark up, create design reviews, E-mail and print CAD files | | |
| Office Automation Software MS Word, Excel, PageMaker... | CAD/CAM & 3D Modeling Systems Pro/E, AutoCAD, SolidWorks, Catia, UG... | |
| ↓ | ↓ | |
| ADOBE® ACROBAT® | SolidView/Pro | |
| ↓ | ↓ | |
| PDF | SFX | |
| ↓ | ↓ | |
| FREE Adobe Acrobat Reader | FREE SolidView/Lite | |
| ↓ | ↓ | |
| *Anyone can view & print formatted documents from any business application | *Anyone with a Windows PC can view, interrogate, and print CAD files from any CAD system | |
| Why CAD/CAM? . . . CADCOM! ONLY \$445 . . . 30 DAY MONEY BACK GUARANTEE. | | |
| C2C Technologies, Inc. | | |
| ...Your CADCommunications Provider | | |
| Toll FREE: 877-422-3266 for a Free CD fully operational for 15 days. | | |

variation of the basic concept, the piezovoltage generated during the compression phase would initially be used to charge a capacitor; subsequently, under control by a timing circuit, the capacitor would be discharged through the spark electrodes. The spark timing could be in response to any combination of (1) the engine

crank angle, (2) the pressure (as indicated by the piezovoltage), and (3) the rate of change of pressure.

This work was done by Jacob van Reenen Pretorius and Marthinus Cornelius van Schoor of Midé Technology Corp. for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the

Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16760.

Lightweight, Low-Power, Inexpensive Ozone Dosimeters

Ozonolysis of organic dyes would cause color changes, which would be measured.

NASA's Jet Propulsion Laboratory, Pasadena, California

Lightweight, low-power-consumption, inexpensive ozone sensors based on colorimetric chemical sensing would be developed, according to a proposal. Colorimetric chemical sensing is an established technique, but it has not been applied previously to sensing of ozone. The proposed ozone sensors could be incorporated into radiosondes for measuring tropospheric and stratospheric ozone concentrations; they could also be used to monitor ozone in a variety of indoor and outdoor environments near such ozone sources as electric-arc welding equipment, high-voltage laboratory instruments, photocopiers, laser printers, and electrostatic air cleaners.

An ozone sensor as proposed would include a transparent substrate (e.g., a glass or plastic slide) coated with an organic dye that changes color when it reacts chemically with ozone. The coated substrate would be illuminated by one or more light-emitting diode(s) or diode laser(s) of the appropriate wavelength(s), and the portion of incident light transmitted through the coated substrate at each wavelength of interest would be measured by a photodiode. The color change would manifest itself as a change in absorbance, and thus a change in the amount of transmitted light at each wavelength of interest. A change in absorbance at each wavelength of interest would be related to the degree of reaction and thus to the ozone dosage via the Beer-Lambert law:


$$A = \alpha lc = \ln(I/I_0),$$

where A is the change in absorbance, α is the dosage-dependent change in the absorption coefficient of the dye, l is the thickness of the layer that contains the dye, c is the concentration of the dye in the layer, I_0 is the intensity of transmitted light before exposure to ozone, and I is the intensity of transmitted light after exposure to ozone.

An ozone sensor should operate without interference by oxidizing substances

other than ozone (e.g., halogens, SO_2 , and NO_2). Therefore, the dye should be either one that does not exhibit color changes in the presence of the other substances, or else one for which the color change induced by ozone differs measurably from the color change(s) induced by the other substances. A promising dye of the latter type is chlorophyllin — a copper-containing, water-soluble derivative of chlorophyll.

Chlorophyllin exhibits an absorption peak at a wavelength of 630 nm. This peak diminishes in proportion to the degree of reaction (see figure), making it possible to quantify the ozone dosage via the Beer-Lambert law. In addition, the product of ozonolysis of an ethylene group on the chlorophyllin molecule gives rise to a smaller absorption peak at 500 nm; the corresponding absorption peaks induced by other oxidizing species occur at different wavelengths.



The Absorbance of a Chlorophyllin Film on a glass slide was measured before and after exposure to ozone. The fall of the 630-nm peak and the rise of the 500-nm peak can be interpreted in terms of ozone dosage.


Thus, one could use the 500-nm peak to verify that the observed color change was caused by ozone or, alternatively, one could identify the oxidizing species by measuring the different wavelength of this peak.

Because the color change would be irreversible and proportional to the cumulative exposure to ozone, a sensor of this type would be a dosimeter (as distinguished from a concentration meter). However, it may be possible to determine the instantaneous concentration of ozone from the rate of change of the absorbance.

This work was done by Margie Homer, Margaret A. Ryan, and Roger Williams of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category. NPO-20469




Special Coverage: Sensors



Penny + Giles Controls, Schaumburg, IL, has introduced the SLS190 **sealable linear sensor** that uses hybrid track technology, and features stroke lengths from 25 to 350 mm in increments of 25 mm. The sensor is designed for system designers requiring analog position feedback. It can be specified with a compact shaft option, which offers a reduced mounting dimension.

The sensor features a molded, one-piece rear bearing assembly with integral cable exit which, when used with the shaft seal option, provides sealing to IP66. A rotatable shaft with a mechanical stroke is 4 mm longer than the electrical stroke to simplify set-up and installation. A removable front slider bearing housing allows easy maintenance, and light weight makes it suitable for mobile applications. Options include a compact shaft, IP66 sealing, 10-m cable, and body clamp or flange mounting kits.

For More Information Circle No. 738




The Series U-222xxx **rotary position sensors** from Transicoil, a division of Horizon Aerospace, Norristown, PA, are available in sizes from 0.8" (Size 8) to 1.5" (Size 15) in diameter. The Size 15 has a temperature range from -50 to +275°F, excitation of 20V RMS, and frequency of 3000 Hz.

Its operating range is from 0 to 90° of rotation. At 0° displacement, its output voltage is 8.2 VRMS, and at 90°, it is 11.8 VRMS.

Constructed of 416 stainless steel with a 303 stainless steel shaft, the sensors operate with an ac voltage energizing a two-part winding surrounding a specially shaped rotor. As the position of the rotor changes, it changes the magnetic resistance of the winding. An output signal is measured across a portion of the winding, and its voltage is proportional to the position of the rotor and the shaft. Users can specify temperature and pressure ranges, shielding, and excitation and output parameters.

For More Information Circle No. 740



The Model BS-112 **miniature linear gauge sensor** from Ono Sokki Technology, Addison, IL, measures dimensions, thickness, curvature, eccentricity, displacement, height, depth, flatness, variation, runout, roundness, distortion, deflection, and position. It uses the linear glass scale technology to maintain accuracy through the entire measuring range of 10 mm.

The ultra-compact sensor is designed for extremely tight spaces, such as mounting inside machinery. A waterproof seal and dust bellow are provided for accurate measurement in harsh environments. An air or mechanical release cable may be used to raise and lower the measuring probe. The sensor comes with a 6-foot signal cable that can be connected to remote displays with various outputs.

For More Information Circle No. 737




Banner Engineering Corp., Minneapolis, MN, offers the R55F Series **fiber-optic color mark sensors** that can detect 16 levels of gray scale at up to 10,000 actuations per second. Models with glass fibers can be used in harsh environments; plastic fiber models are used in applications

requiring fiber flexing capabilities, such as in robotics. All adjustments are made to the sensor on the front panel. The sensors can detect all colors using a choice of red, green, white, or blue visible sensing beams.

A teach function provides two operator options: Static Teach and Dynamic Teach. Static Teach is used to set sensing conditions manually, and Dynamic Teach enables users to "teach" the sensor a series of conditions, average the sensing events, and set and periodically update the threshold between light and dark conditions. The sensors operate in temperatures from -10° to +55°C.


For More Information Circle No. 736



A self-teach **capacitive label sensor** from SIE Sensors, Toledo, OH, is a non-contact, non-infrared sensor with a tape speed averaging up to 500 meters per minute. A three-LED display allows for easy set-up. The sensor operates at 10-30 VDC and is available in PNP or NPN outputs, which are switchable from normally open to normally closed. The sensor detects transparent or color labels, and tears or splices.

The unit features temperature and humidity compensation, short circuit protection, and a static switching output. The sensor is offered in two versions with optional slot widths of 0.4 mm and 0.6 mm. The unit housing is made of nickel-plated aluminum, which separates for compact installation. For optional wiring purposes, an M8 quick-disconnect with an additional LED indicator is a standard feature.

For More Information Circle No. 739



Hyde Park Electronics, Dayton, OH, has introduced the Model CT-1000 Series of **ultrasonic counting sensors**, which feature a dual-transducer design. The sensor counts both separated and back-to-back containers at line speeds up to 2000 per minute. The sensor output can be used with most counters or totalizers. Containers may be of any shape, material, color, or style, and sized from 1" to 12" in diameter.

The sensing range, to the inside of the pass-line rail, is 2" to 2.75". Made of ULTEM® plastic, the sensor housing measures 4.45 x 2.54 x 3.10". During operation, a two-digit numeric display shows either counting activity or errors. The sensor provides both a sinking (NPN) and a sourcing (PNP) output. Available in either cable or connector style, the sensor is sealed to withstand dust, humidity, and high pressure.

For More Information Circle No. 735

New on the MARKET

Ultrasonic Flowmeter

The FD610 Series flowmeter from OMEGA Engineering, Stamford, CT, features trans-phase measuring technology designed for accurate flow-velocity assessments in closed piping systems. Its non-invasive, clamp-on transducer is placed on the outside of the pipe. Within seconds, the 18mm LCD provides readings in either feet or meters per second.

The meter works with either metal or plastic pipes containing liquids with more than 25 ppm of 30-micron (or larger) suspended solids or entrained gases. **Circle No. 701**

Threaded Inserts

Penn Engineering & Manufacturing Corp., Danboro, PA, offers SI ultrasonic threaded inserts for assembly and disassembly of electronics, automotive, aerospace, and communications equipment. The brass or stainless-steel inserts can be installed ultrasonically by pressing the fastener into a mounting hole while applying high-frequency vibration. A thermal press also may be used to create the heat necessary for installation. The inserts are available in a range of thread sizes and can be used in tapered and straight holes. **Circle No. 702**

Current Monitor


Ion Physics Corp., Atkinson, NH, has introduced the CM-001-ES current monitor, which measures peak currents at line frequencies up to 150 kilo-amperes, and RMS currents at 60 Hz up to 20 kilo-amperes. The monitor uses an

air-core design with an inner diameter of 2" and an outer diameter of 5". When placed around the current-carrying conductor, the monitor senses the magnetic field associated with the current, measuring the current without a direct connection. The CM-001-ES can be used wherever very high currents must be measured between 5 Hz and 1,000 Hz. **Circle No. 706**

Color Industrial Camera

Vision Components, Cambridge, MA, has introduced the VC65/C color industrial smart camera. The machine vision system features 24-bit RGB color capabilities and a progressive scan sensor. The camera, which measures 117 x 50 x 36 mm, includes up to 8 MB of RAM and 2 MB of Flash EPROM. Its CCD sensor provides 782 x 582 RGB pixels, shutter speeds from 1/100,000 to 20 seconds, and a DSP. Other features include optically isolated industrial I/O, an RS-232 serial interface, CCIR video output, and pixel-identical sensor read-out. **Circle No. 708**

Stress Strain



Strain Gage Data Acquisition Systems

Developed by Stress Engineering Services
Based on National Instruments Products

- High Channel Count Systems with Low Incremental Cost
- Quick and Easy Hardware and Channel Setup
- Quarter Bridge and Full Bridge Input Capabilities
- Extreme Application Flexibility with Variable Sample Rates
- Rugged Portable, Lab and Stand-Alone Designs



www.straindaq.com

Phone: (281) 955-2900 Fax: (281) 955-2638
E-mail: straindaq@hou.stress.com

For More Information Circle No. 437

Six-Axis Force/Torque Sensors

NEW High-Resolution ISA Bus Interface



Features Include:

- Six Axes of Force/Torque Sensing ($F_x, F_y, F_z, T_x, T_y, T_z$)
- High Overload Protection
- Intelligent Interfaces
- Sizes from 17mm dia. to 250mm dia.

Applications Include:

- Product Testing
- Biomedical Research
- Wind Tunnel Testing
- Fluid Flow Analysis
- Robotics



Engineered Products for Manufacturing Productivity

Tel: +1 919.772.0115 • Fax: +1 919.772.8259

Email: info@ati-ia.com • Web: www.ati-ia.com

Peachtree Center, 503-D Highway 70 East, Garner, North Carolina 27529 USA

Thermal-Ribbon RTD's fast response surface sensing

S17422
0.1 second response

S17624 Thin film RTD

S651 Miniature platinum RTD

Thin, flexible resistance temperature detectors • Wire wound or thin-film • Pt, Cu, Ni, Ni-Fe curves • 0.1 second time response • Rugged laminated construction • -200 to 220°C range • Many sizes & styles in stock

Stable, accurate, dependable measurement • Install with self-stick backing, tapes, or cements • Avionics • Process lines • Medical devices • Aircraft windows • Stator windings • Thermal processing equipment

MINCO

PRODUCTS, INC.

7300 Commerce Lane • Minneapolis, MN 55432-3177 U.S.A.
Telephone: (612) 571-3121 • FAX: (612) 571-0927

For More Information Circle No. 439

Attn: ENGINEERS

Tufoil®

Industrial Lubricants

have the uncanny ability
to keep your machinery running
at peak performance

www.tufoil.com
(It's worth the trip)



1-800-922-0075

For More Information Circle No. 440


New on DISK

Presentation Software

Canvas 7 from Deneba Software, Miami, FL, is an integrated vector illustration, image editing, Web design, page layout, and presentation application. The release introduces next-generation Sprite technology, called SpriteEffects™, and includes more than 150 new features, tools, and performance enhancements. SpriteEffects allows users to apply unlimited numbers of imaging filters to any object. Other features include new GIG and JPEG export capabilities, HTML support, new drawing tools, and multiple options for importing Photoshop files. **Circle No. 712**


FEA Integration for AutoCAD

CSA/Visual for AutoCAD from CSAR, Agoura, CA, is a FEA implementation for seamless 2D and 3D AutoCAD, AutoCAD LT, and Mechanical Desktop models. It is designed to integrate core FEA features such as beams and rigid elements with the AutoCAD interface. With seamless integration of CSA/NASTRAN and AutoCAD, complex assemblies and multiple materials can be analyzed within a common interface. Manual translation is eliminated by utilizing native geometry, which reduces training and analysis time. **Circle No. 713**



Application Development

BrainTech, North Vancouver, BC, Canada, has released version 3.0 of the ODYSSEY Development Studio, a drag-and-drop environment for application development. Features include an integrated environment with GUI builder; online debugging and optimization; ODYSSEY-wrap, a tool for integrating C/C++ functions; and a component-based architecture. Third-party libraries can be purchased with ODYSSEY, which enables users to leverage expertise from more than 3,000 functions. **Circle No. 714**



Piping Design and Analysis

Algor, Inc., Pittsburgh, PA, has released PipePak 7.0, a piping design and analysis software package featuring a new HTML Report Wizard, which creates formatted, customizable reports that can be displayed using any Web browser. PipePak 7.0 saves model images in formats such as JPEG, TIF, PCX, PNG, TGA, and BMP. Improved arc functionality allows users working in Superdraw III — Algor's single user interface and piping design tool — to export models to PipePlus, PipePak's ASME piping-analysis processor. An improved user interface ties all PipePak 7.0 elements into one menu accessible from within Superdraw III. **Circle No. 716**

Business Visualization

OpenViz™ from Advanced Visual Systems, Waltham, MA, provides dynamic, interactive, and scalable 2D and 3D representations of multiple data and chart types. This suite of components allows IT organizations and developers to Web-enable applications by creating lightweight applets and ActiveX controls. OpenViz supports both JavaBeans and COM/ActiveX with a single, common user interface. Interactive charting and graphing capabilities allow end users of OpenViz-developed applications to interact with data, rather than viewing it passively. Users can create "what-if" scenarios or manipulate axes and scales to create multiple displays for any data set. **Circle No. 717**

Genius. Visionary. Superhero.

(With the new Tecplot, your boss will be calling you names.)

NEW VERSION!

Tecplot®

Version 8.0

Tecplot is a plotting program that enables you to visualize large, complex data sets. Your data and calculations will be transformed into colorful 2-D and 3-D images. The version 8.0 upgrade allows you to:

- Easily publish your research findings on the web
- Create presentation-quality plots and grids
- Collaborate with colleagues throughout the world with the new packet files feature
- Customize Tecplot to your specific needs
- Interface with industry standard data formats
- Leverage solutions from C or FORTRAN code base
- Add I/O capabilities for unique data formats


Splendid graphics. Astounding presentations. And so easy to use. With Tecplot 8.0, you'll feel like a genius.

For More Information Circle No. 558




1.800.763.7022


Download a free demo today at www.amtec.com




Above:
Model of solar wind
magneto sphere coupling



Above:
Courtesy of Bruce Rosen, South Bay
Simulations, Inc. Computed results
by SPLASH free-surface flow code.



Above:
Aircraft turn rate performance
plot or "Dog House Plot."



Above:
Mechanical crankshaft

"...one of the strong points of TECPLOT for us is the high quality of graphic output..." - Lars Bornholt

Advertisers Index

Advertisers listed in bold-face type also have banner ads on the *NASA Tech Briefs* web site this month. Visit www.nasatech.com

| Company | Web Site | Circle Number | Page | Company | Web Site | Circle Number | Page |
|---|---|---------------|---------|--|---|---------------|----------------|
| ACR Systems Inc. | www.acrsystems.com | 434 | 55 | The MathWorks, Inc. | www.mathworks.com/ntbm , www.mathworks.com/ntbc | 502, 419 | 15, 41 |
| AeroSense | www.spie.org/info/or/ | | 17a | Melles Griot | www.mellesgriot.com/mgl36.htm | 461 | 4a |
| Agilent Technologies | www.agilent.com/find/bi | 538 | 27 | Microstar Laboratories | www.mstarlabs.com | 416 | 31 |
| Algor, Inc. | www.feaincad.com , www.algor.com | 521, 510 | 5, 39 | Microway | www.microway.com | 568 | 43 |
| Amtec Engineering, Inc. | www.amtec.com/tecplot | 558 | 63 | Mildex Inc. | www.mildex.com | 490 | 28a |
| Analog Modules, Inc. | www.analogmodules.com | 464 | 20a | Minco Products, Inc. | | 439 | 62 |
| Astro-Med, Inc. | www.astro-med.com | 518 | 9 | National Instruments Corporation | www.ni.com/daq , www.ni.com/info/cw , www.ni.com/vision | 500, 418, 486 | COV II, 37, 1a |
| ATI Industrial Automation | www.ati-ia.com | 438 | 61 | Newport | www.newport.com/wdm | 471 | 9a |
| Avimo Precision Polymer Optics | www.polymeroptics.com | 460 | 2a | Numerical Algorithms Group | www.nag.com | 420 | 32 |
| Boulder Instruments | www.boulderinstruments.com | 530 | 13 | NuSil Silicone Technology | www.nusil.com | 413 | 23 |
| BSI, Broadax Systems, Inc. | www.bsicomputer.com | 425 | 47 | Ocean Optics, Inc. | www.OceanOptics.com | 410 | 6 |
| C2C Technologies, Inc. | | 436 | 58 | Olympus Industrial | www.olympusipg.com | 445 | 53 |
| Cambridge Technology | www.camtech.com | 489 | 5a | Omega Engineering, Inc. | www.dasieee.com | 575-577 | 1 |
| Capacitec | | 590 | 56 | Omega Shielding Products Inc. | www.omegashielding.com | 424 | 47 |
| Chino Works America, Inc. | www.chinoamerica.com | 412 | 12 | Optical Research Associates | www.opticalres.com | 480 | 7a |
| Dewetron, Inc. | www.dewamerica.com | 533 | 25 | OptoSigma | www.optosigma.com | 482 | 25a |
| Digi-Key Corporation | www.digikey.com | 540 | 3 | Oriel Instruments | www.oriel.com | 462 | 14a |
| Engineering Synthesis Design | www.engsynthesis.com | 466 | 22a | OZ Optics Ltd | www.ozoptics.com | 476 | 15a |
| The Evans Capacitor Co. | www.evanscap.com | 429 | 51 | Paroscientific, Inc. | www.paroscientific.com | 428 | 50 |
| Federal Laboratory Consortium | www.federalabs.org | | 48A-D | Power Components of Midwest, Inc. | www.pcmidwest.com | 431 | 54 |
| FEI Communications, Inc. | www.frequel.com | 448 | 38 | Real Time Integration | www.realtimeint.com | 427 | 50 |
| Fluoramics, Inc. | www.tufoil.com | 440 | 62 | Research Systems, Inc. | www.rsinc.com/most | 526 | COV IV |
| Focus Software, Inc. | www.focus-software.com | 488 | 11a | RGB Spectrum | www.rgb.com | 411 | 8 |
| Gage Applied Sciences Inc. | www.gage-applied.com/ad/nasa100.htm | 509 | COV III | Rifocs Corporation | www.rifocs.com | 415 | 30 |
| Glendale/Daloz Safety | www.glendale-laser.com | 472 | 24a | Roper Scientific Princeton Instruments | www.roperscientific.com | 485 | COV IIa |
| G-S Plastics Optics, A Germanow-Simon Corporation | www.gsopics.com | 469 | 18a | Sony Precision Technology America | www.sonypt.com | 527 | 45 |
| Hitachi Denshi America, Ltd. | www.hdal.com | 465 | 21a | Spectral Instruments, Inc. | www.specinst.com | 463 | 19a |
| Integrated Engineering Software | www.integrated.ca.com | 422 | 44 | Spectrasource Instruments | www.spectrasource.com | 467 | 22a |
| IOtech, Inc. | www.iotech.com | 401-403 | 32A-B | Spectrumastro | www.spectrumastro.com | 555 | 19 |
| Kaman Instrumentation | www.kamaninstrumentation.com | 433 | 55 | Stress Engineering Services | www.straindaq.com | 437 | 61 |
| Keithley Instruments, Inc. | www.keithley.com | 548 | 35 | Synrad, Inc. | www.synrad.com | 417 | 36 |
| Kingston Technology Company | www.kingston.com/storage | 570 | 11 | Tescom Corporation | www.tescom.com | 423 | 48 |
| L3 Communications, Celerity Systems | www.csdaq.com | 536 | 7 | Velmex, Inc. | www.velmex.com | 435 | 56 |
| Lambda Physik | www.lambdaphysik.com | 487 | 3a | Visionary Design Systems, Inc. | www.ironcad.com | 504 | 29 |
| Laser Marking Technologies | www.lasermarking.net | 468 | 23a | Waterloo Maple Inc. | www.maplesoft.com | 432 | 52 |
| LaserMax Inc. | www.lasermx-inc.com | 470 | 26a | Wolfram Research, Inc. | www.wolfram.com/mathematica4/ntb | 505 | 2 |
| LaVezzi Precision, Inc. | www.lavezzi.com | 513 | 21 | ZC&R | www.zcraoatings.com | 475 | 13a |
| Master Bond Inc. | www.masterbond.com | 430 | 54 | | | | |

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright ©2000 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years. Single copies \$5.00. Foreign subscriptions one-year U.S. Funds \$195.00.



Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to *NASA Tech Briefs*, PO Box 10523, Riverton, NJ 08076-9023.

2 Gigabyte

On-Board Acquisition Memory For PCI Scope Cards

- On-Board Acquisition Memory
Up to 2 Gigabytes with
500 MS/s Sample Rate
- 8 bit, 500 MS/s A/D Sampling
- 12 Bit, 100 MS/s A/D Sampling
- 16 bit, 2.5 MS/s A/D Sampling
- 32 bit, 100 MHz Digital Pattern Acquisition
- Supports PCI Bus Transfers
- Compatible with Win NT, Win 95/98, Win 2K, DOS



GageScope for Windows

World's Most Powerful Oscilloscope Software

- ✓ No Programming Required
- ✓ No Need to Write C Code
- ✓ No Need to Draw Diagrams
- ✓ Just Click Your Mouse & Go

For Free Application Engineering


Call: 1-800-567-GAGE

www.gage-applied.com/ad/nasa100.htm

GaGe

GAGE APPLIED SCIENCES INC.

The Power of IDL



Searching for powerful data analysis and advanced graphics?

Do you need a complete processing and visualization solution? Look to IDL®, the *Interactive Data Language*.

IDL combines a robust cross-platform environment for the access, analysis, and visualization of any data with a full-featured suite of development tools. With its object oriented 4GL, hardware accelerated graphics system and powerful analysis, IDL is the ideal platform for technical application development.



Download IDL today at
www.rsinc.com/most



IDL®

IDL combines all of the tools you need for any type of project — from “quick-look,” interactive analysis and display to large-scale commercial programming projects. This easy-to-learn, cross-platform, application development software is relied upon by analysts and engineers around the globe.

Research Systems offers off-the-shelf software packages built with IDL that deliver analysis and results with point-and-click ease.




ION™

ION brings the power of IDL to the internet allowing you to collaborate across networks and the Web.




VIP™

Delivers the power of IDL data analysis and visualization without programming.




ENVI™

ENVI, the Environment for Visualizing Images, is the leader in remote sensing data analysis.



NOeSYS™

Access, edit, organize and visualize large multi-dimensional data — without programming.



RiverTools™

The most powerful DEM tool for analysis of terrain and river networks.



RESEARCH
SYSTEMS
Software = Vision.

tel: 303.786.9900 email: info@rsinc.com